



J. I. Case

Service Manual

646 & 446

Lawn & Garden Tractor

S/n 0-9742952

JENSALES.COM

or Call 800-443-0625



THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
J.I. CASE OR IT'S SUCCESSORS. J.I. CASE AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

Service Manual

CA-S-646+



Ingersoll

BF, B43M, B48M AND CCKA
ONAN ENGINES
Service Manual 9-51393

MANUAL PREVIEW

JENSALES®

purchase full manual at

JENSALES.COM

or Call 800-443-0625



QUALITY IN THE AMERICAN TRADITION

Ingersoll Equipment Co., Inc.

Winneconne, Wisconsin 54986-9576

TABLE OF CONTENTS

CLICK ANYWHERE FOR MORE DETAILS

TITLE	PAGE
General Information	3
Specifications	4
Dimensions and Clearances	5
Assembly Torques and Special Tools	5
Engine Troubleshooting	8
Oil System	9
Fuel System for BF, B43M, B48M	11
Fuel System for CCKA	15
Engine Disassembly and Assembly	18

purchase full manual at

JENSALES.COM
or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

TABLE OF CONTENTS

A. Engine Fails To Start - Fuel Related (Engine Cranks Properly)	3
B. Engine Fails To Start - No Spark (Engine Cranks Properly)	4
C. Engine Fails To Start - Compression Related	5
D. Engine Misfires	6
E. Engine Lacks Power	7
F. Engine Overheats	8
G. Engine Surges, Runs Unevenly Or Stops After A Short Time	8
H. Engine Vibrates Excessively Or Normal Vibration Transmitted To Tractor Frame	9
I. Breather Passing Oil (Pressure In Crankcase - High Oil Consumption)	10
J. Engine Knocks	11
K. Engine Overspeeds	11

INTRODUCTION

This service manual section, "Troubleshooting the Engine" contains a concise listing of Symptom--Possible Cause--Probable Remedy for many engine problems.

Use an orderly process of elimination when troubleshooting. First eliminate the possible causes that are easy to check or test. Then move into the more complex areas that may require disassembly or more difficult tests.

Refer to the appropriate service manual for proper repair procedures. Refer to the electrical system service manual for troubleshooting the tractor electrical system. (The ignition system is the only electrical area covered in this service manual.)

TABLE OF CONTENTS

A. Engine Fails To Start - Fuel Related (Engine Cranks Properly)	3
B. Engine Fails To Start - No Spark (Engine Cranks Properly)	4
C. Engine Fails To Start - Compression Related	5
D. Engine Misfires	6
E. Engine Lacks Power	7
F. Engine Overheats	8
G. Engine Surges, Runs Unevenly Or Stops After A Short Time	8
H. Engine Vibrates Excessively Or Normal Vibration Transmitted To Tractor Frame	9
I. Breather Passing Oil (Pressure In Crankcase - High Oil Consumption)	10
J. Engine Knocks	11
K. Engine Overspeeds	11

INTRODUCTION

This service manual section, "Troubleshooting the Engine" contains a concise listing of Symptom--Possible Cause--Probable Remedy for many engine problems.

Use an orderly process of elimination when troubleshooting. First eliminate the possible causes that are easy to check or test. Then move into the more complex areas that may require disassembly or more difficult tests.

Refer to the appropriate service manual for proper repair procedures. Refer to the electrical system service manual for troubleshooting the tractor electrical system. (The ignition system is the only electrical area covered in this service manual.)

TABLE OF CONTENTS

Safety Messages	3
Introduction	4
Test Equipment	4
Wiring Diagrams	5-9
Troubleshooting Chart	10-12
Battery Care and Maintenance	13-16
Battery Check Sheet	16
Starter Motor Repair	17-24
For Models 226, 446, 448, 648	17-19
For Model 646	20-24
Flywheel Alternator	25
Ignition	25-28
Breaker Points Service	25
Ignition Timing Procedure	26
Coil Service	27
Condenser Service	27
Spark Plug	28

JENSALES
purchase full manual at

JENSALES.COM
or Call 800-443-0625

STARTER MOTOR REPAIRS – MODEL 646




FIGURE 13 Starter Assembly

STARTER DISASSEMBLY

1. Loosen the M terminal nut on the magnetic switch and remove the connector. Remove the magnetic switch.

NOTE: The packings for the magnetic switch are mounted so that the steel packing is located in the front bracket side.




FIGURE 14 Magnetic Switch Removal

2. After removing the thru bolts, the starting motor can be divided into three parts — the front bracket, housing and rear bracket.

The spacing washers shown in Figure 15 are used for adjustment of the thrust gap of the armature shaft. They are between the rear bracket and the commutator.

NOTE: These washers are inserted so the steel washer is located in the commutator side.




FIGURE 15 Removing Through Bolts

3. Remove the armature from the front bracket. Be careful not to miss a small steel washer used in the end of the armature shaft. Remove the shift lever along with the armature. In this case, the spring holder, lever springs and retainer can be taken out before the lever.




FIGURE 16 Removing Armature

TABLE OF CONTENTS

Attachment Drive Clutch – One piece hub shaft and snap ring located between cams.	4
Attachment Drive Clutch (Intermediate Style) – Two piece hub shaft and hub assembly retained by bolt, no snap ring.	8
Attachment Drive Clutch (Early Style) – One piece hub shaft and front cam retained by snap ring.	9



This safety alert symbol indicates important safety messages in this manual. When you see this symbol, carefully read the message that follows and be alert to the possibility of personal injury or death.

JENSALES.COM
or Call 800-443-0625

TABLE OF CONTENTS

Introduction	2
Removal	3
Disassembly	4
Inspection	4
Assembly	4
Installation	9
Axle and Axle Seal Replacement Only	9
Hydraulic Motor Replacement Only	10

INTRODUCTION

This manual covers service procedures for the hydraulically driven two-speed transmission used on:

200 and 400 series compact tractors
3000 and 4000 series compact tractors
3100 and 4100 series compact tractors
600 and 6000 series compact loaders



This safety alert symbol indicates important safety messages in this manual. When you see this symbol, carefully read the message that follows and be alert to the possibility of personal injury or death.

JENSALES.COM
or Call 800-443-0625

TABLE OF CONTENTS

Hydraulic Pump Specifications	3-4
Relief Valve Specifications	5-6
Use of the Hydraulic Flowmeter	7
Pump Test Flowmeter Connections	8-9
Flowmeter Connections Chart	10
Tee Test Flowmeter Connections	11-12
Flowmeter Test Procedure	
Circuit Flow Tests	
I. Warming the Hydraulic Oil	13
II. Suction Line Test	13
III. Pump Efficiency Test	13
IV. Drive Circuit Leakage Test	14
V. Hydraulic Attachment Lift Circuit Leakage Test	15
VI. Hydraulic PTO Valve Leakage Test	15
VII. Loader Lift Circuit Leakage Tests	16
VIII. Loader Bucket Circuit Leakage Test	16
Relief Valve Test with Flowmeter	
I. Travel Relief/Main Relief Valve Test	17
II. Attachment Lift Relief Valve Test	18
III. PTO Relief Valve Test	18
IV. Power Steering Relief Valve Test	18
V. Loader Bucket Relief Valve Test	18
Relief Valve Tests with Pressure Gauge	
I. Travel Relief/Attachment Lift Relief Tests	19
II. PTO Relief Valve Tests	19
III. Power Steering Relief Valve Tests	20
IV. Loader/Backhoe Relief Tests	20
Flowmeter Test Interpretation	20
Drive System Retard Adjustment	22
Hydraulic System Diagnosis Worksheet	23

purchase full manual at

JENSALES.COM
or Call 800-443-0625

TABLE OF CONTENTS

Definitions of Major Components	2-3
Explanation of Coding Key	4
Basic Tractor Hydraulic Systems	
200-400 Series Tractors with Hydraulic Lift	5
3000-4000 Series Tractors	6-7
3000-4000 Series Tractor with Power Steering prior to PIN 14167800	8-9
3100-4100 Series Tractors	10-11
600 Series Tractors with Loader	
Neutral Drive, Neutral Bucket Tilt, Raise Loader Lift	12-13
Forward Drive, Rollback Loader Bucket, Neutral Loader Lift	14-15
600 Series Tractors with Loader and Backhoe	16-17
6018 Series Tractors with Loader	18-19
6018 Series Tractors with Loader and Woods Backhoe	20-21
6018 Series Tractors with Loader and Ameriquip Backhoe	22-23
Ground Travel Circuits	
Forward Ground Travel - Neutral Lift Circuit	24
Reverse Ground Travel - Neutral Lift Circuit	25
Forward Ground Travel - Dynamic Braking/Downhill mode	26
Travel Control Valve	
Neutral	27
Forward	28
Reverse	29
Forward Drive - Deceleration or Dynamic Braking	30
Neutral - 600 Series Loader	31
Hold Valve	32
Attachment/3 Point Hydraulic Lift Circuits	
Raise Circuit	33
Float Circuit	34
Lower Circuit	35
Travel Control Valve	
Raise Mode - Neutral Drive	36
Lower Mode - Neutral Drive	36
Raise Mode - Forward Drive	37
Float Mode - Forward Drive	37
Hydraulic PTO Circuits	
200-400 Series Tractors/	
3000-4000 Series Tractors prior to PIN 14167800	
Neutral PTO Circuit	38-39
PTO Engaged Circuit	40-41
3000-4000 Series Tractors with Power Steering prior to PIN 14167800	
Neutral PTO Circuit	42-43
PTO Engaged Circuit	44-45
3000-4000 Series Tractors PIN 14167800 & Up	
Neutral PTO Circuit	46-47
PTO Engaged Circuit	48-49
3100-4100 Series Tractors	
Neutral PTO Circuit	50-51
PTO Engaged Circuit	52-53
3000-4000 Series Tractors with Power Steering PIN 14181900 & Up	
Neutral PTO Circuit	54-55
PTO Engaged Circuit	56-57
Hydraulic PTO Valve	
Neutral - PTO Off Mode	58
Engaged/PTO On Mode	58
Flow Control Valve	
Full Speed Flow Control Circuit	
200-400 Series Tractors/	
3000-4000 Series Tractors prior to PIN 14167800	60-61
3000-4000 Series Tractors PIN 14167800 & Up/	
3100-4100 Series Tractors	62-63
Reduced Speed Flow Control Circuit	64-65
Off Flow Control Circuit	64-65
Flow Control Valve	
Off Mode	66
Reduced Speed Mode	66
Full Speed Mode	67
Loader Bucket Control Valve	
Neutral Tilt - Raise Lift	68
Rollback Tilt - Neutral Lift	68

TABLE OF CONTENTS

SECTION 1	
Pump Removal	2-4

SECTION 2	
Pump Installation	4

SECTION 3	
Pump Disassembly, Inspection and Assembly Procedures	6-28
Wooster Pump (C14243 and C14244)	7
Parker Hannifin Pump (C15481 and C19045)	8-10
Borg Warner Pump (C20757, C19743 and C22771)	12-13
Parker Hannifin Pump (C24828, C24868, C25053, C26278, C31958 and C33579)	14-17
Cessna Pump (C25179)	18-19
Borg Warner Pump (C19176, C20025, C20122 and C23951)	20-21
Cessna Pump (25287)	22-23
Cessna Pump (C28370)	24-25
Parker Hannifin Pump (two stage) (C32170, C36905, C42854)	26-29

INTRODUCTION

This manual has service information for the hydraulic pumps used on hydraulic tractors.

See your parts catalog for the part number of the pump.

See your "HYDRAULIC TEST PROCEDURES" service manual section for pump performance specifications and testing procedures.

JENSALES.COM
or Call 800-443-0625

SINGLE ACTING THREE POINT HITCH CYLINDER

REMOVAL

1. Retract the cylinder and stop the engine. Remove the hose (4) from the lift valve at fitting (3). Cover or plug the exposed fittings to keep out dirt.
2. Remove the two mounting pins and remove the cylinder assembly from the hitch.
3. Remove the hose from the elbow (5) at the base of the cylinder. Clean paint and/or rust from inside the base end of the cylinder tube.

DISASSEMBLY

1. After draining the cylinder, push or tap the piston assembly (10) and end cap (13) through the base end of the cylinder.
2. Remove and discard wiper ring (8), back up washers (11) and "O" rings (12).

INSPECTION

1. Thoroughly clean and air dry all parts before inspection.
2. Inspect the cylinder tube and piston rod assembly for score marks or scratches. Light scratches may be removed with a hone or crocus cloth. If scratches cannot be polished out, the affected part must be replaced since the "O" rings will be quickly damaged and leakage will result.

3. To protect the piston and end cap "O" rings during assembly, break the inside sharp edges of the two mounting pin holes in the cylinder tube with crocus cloth. Also check the base of the tube for burrs or sharp edges.

ASSEMBLY

1. Dip all new seals in clean oil.
2. Install new wiper seal (8) into cylinder tube, lip side out.
3. Install new "O" ring (12) and back up washers (11) on piston.
4. Place new "O" ring (12) on end cap.
5. Apply a light coat of grease to the inside of the cylinder tube and the O.D. of the piston with particular attention to the area of the mounting pin holes and the "O" ring.
6. Carefully install the rod and piston assembly into the cylinder tube making certain the "O" ring is not nicked by the mounting pin holes.

NOTE: If an "O" ring particle is observed in either of the cylinder tube mounting pin holes following installation of the piston assembly, the piston must be removed, a new "O" ring installed and step 3 under "Inspection" repeated.




FIGURE 2