



CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

J.I. Case

Operator's Manual

4490 Diesel

purchase full manual at

Operator's Manual

JENSALES.COM
or Call 800-443-0625



CLICK ANYWHERE FOR MORE DETAILS

THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
J.I. CASE OR IT'S SUCCESSORS. J.I. CASE AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

CA-O-4490 DSL

TABLE OF CONTENTS

TO THE OWNER III

SAFETY IV-XVI

Safety Rules IV

Before Starting IV-V

Operation VI-XIII

Service XIV-XVI

HAND SIGNALS XVII-XVIII

DECALS XIX-XXII

SERIAL NUMBERS 1

DIESEL ENGINE SPECIFICATIONS ... 2,3

GENERAL SPECIFICATIONS 4-7

APPROXIMATE TRACTOR SPEEDS .. 8,9

APPROXIMATE OVER ALL

MEASUREMENTS 10

APPROXIMATE TRANSPORT WEIGHT . 10

OPERATOR'S CAB 10

TIRE AND WHEEL EQUIPMENT 11

WHEEL TREAD POSITIONS 12-16

DUAL WHEELS 17

FUEL SPECIFICATIONS 18,19

LUBRICATION 20-31

Engine Hourmeter 20

Diesel Engine 21

Lubrication Chart 22,23

Engine Oil Change 24,25

Engine Oil Filters 25

Rear Steering Valve Filter 26

Transmission Oil Level

Check & Change 27

Hydraulic Oil Filters 27,28

Planetary Oil Level Check & Change . 29

Differential Oil Level Check & Change . 30

Tractor Brakes 31

ALTERNATOR CHARGING SYSTEM .. 32

OPERATING INSTRUCTIONS 33-118

Run-In Procedure 33

Before Starting the Engine 34

Towing 35

Operating Instruments 36-41

Operating Controls 42-75

Steering Console 42-45

Operator's Console 46-57

Hand Brake Control 57

Steering Column Tilt 58

Moving the Telescopic

Steering Column 58

Heater Stop Valve 59

Fuel Tank Water Traps 59

Cab Headliner Controls 60,61

Cab Air Flow Control 62

Cab Defroster Control 62

Cab Air Flow Arrangements 63-65

Air Conditioner Operation 66

Cab Door Lock 66

Ash Tray 66

Rear View Mirrors 67

Cab Window Lever 67

Operator's Seat 68-70

Seat Belts 71

Amber Warning Lamps, Direction

Turn Signals & SMV 72,73

Implement Warning Lamps &

SMV Symbol 74

Auxiliary Outlet Socket 75

Starting Procedure 76-78

Stopping The Engine 78,79

Cold Temperature Operation 79

Preparing Tractor For Operating in

Cold Temperatures 80

Cold Temperature Starting 81-84

Coolant Heater 81

Operating Cold Start Assist 82,83

Starting Fluid

Container Replacement 84

Power Shift Transmission 85,86

Power Takeoff 87-89

Operating PTO 87

Guards 88

PTO Operating Safety 89

Drawbar 90

Three Point Hitch System 91

Hitch System Adjustments 92-94

TABLE OF CONTENTS

OPERATING INSTRUCTIONS

Hitch Operation	95,96
Hitch Control Lever	95
Hydraulic Float Control	96
Anti-Sway Chain	96

Hitch Coupler - Category III	97
Remote Hydraulic Control	98-104
Remote Control Levers	98,99
Variable Flow Control	100,101
Operating the Remote System	102
Hydraulic Hose Couplers	103
Hydraulic Hose Coupling	104
Remote Cylinder	105
Hydraulic Cylinder Jack Pads	106
Wheel Rim Adjustment & Mounting	107
Wheel Spacing and Clamp Adjustment	108
Dual Wheel Mounting	109-111
Tire Mounting	112
Loads Matched to Tractor	112
Tractor Ballast	113
Measuring Slip	113
Tractor and Equipment Weight	114
Front End Weights	115
Wheel Weights	116
Tire Liquid Weight	117
Hood and Side Panels	118

PREVENTIVE MAINTENANCE ... 119-173

Cooling System	120-128
Pressure Cooling System	120
Coolant Solutions	121
Radiator Cleaning	121
Cooling System Service	122
Thermostat Check	123
Thermostat Replacement	123-125
Fan Belt Adjustment	126
Fan Belt Replacement	127
Water Filter and Conditioner	128
Fuel System	129-134
Service Intervals	129
Fuel Filter Replacement	130,131
Primary Fuel Filter	132,133
Air Removal	133,134

Air Induction System	135-144
Air Filter Service Interval	136
Final Air Filter Service	137-140
Aspirated Strata Tube Service	141-143
Tubes and Hoses	144

Neutral Start Switch Adjustment	145,146
---------------------------------------	---------

Parking Brake Adjustment	147
--------------------------------	-----

Three Point Hitch Adjustments	148,149
-------------------------------------	---------

Electrical System	150-154
Head Lamps	150
Flood Lamps	150
Flashing Amber Warning Lamps	151
Rear Flood and Tail Lamp	151
Instrument Cluster Lamps	152
Lamps Fuse Holder	153
Head Lamp Adjustment	154

Storage Battery	155-157
When Batteries Are Not in Use	155
Battery Cables and Terminals	155
Battery Water	156
Vent Caps	156
Removal & Installation of Batteries	156
Auxiliary Battery Connections	157

Roll Over Protective Structure (ROPS)	158,159
Tractor Roll Over	159
Safety Rules	159
Maintenance and Inspection	159

Operator's Cab	160-173
Preventive Maintenance	160,161
Air Filter Removal	162
Air Filter Service	163,164
Seat Belt Inspection and Maintenance	164
Operator's Seat	165,166
Compressor Belt Adjustment	167
Compressor Belt Replacement	168
Compressor Belt Alignment	169
Refrigerant Check	170,171
Dome Lamp	172
Console Lamp	173

CASE TECHNICAL MANUALS 175

TO THE OWNER OF A CASE TRACTOR

Use this manual as your guide. If you follow the instructions given in this manual, your Case Tractor will work well for many years.

Your Authorized Case Dealer can assist you with J I Case Company made parts and persons with special training that know the best methods of repair and maintenance for your tractor.

Call your Authorized Case Dealer if you need any assistance or information.

Your Authorized Case Dealer



Figure 1

NOTE: When you are in the tractor seat looking forward, the right hand and left hand of the tractor are the same as your right and left hand.

REMOTE HYDRAULIC CONTROL

No. 3 Remote Control Lever (If Equipped)





Figure 64

No. 4 Remote Control Lever (If Equipped)



Figure 65

or Call 800-443-0625

REMOTE HYDRAULIC CONTROL

Variable Flow Control

The No. 1 remote circuit has a variable flow control. The tractor can have a total of four variable flow controls. Use the variable flow control to increase or decrease the rate of flow of hydraulic fluid to the remote couplings. The flow can be adjusted from 24 GPM (90.8 litres/min) maximum to 3.5 GPM (13.3 litres/min) minimum. To decrease the rate of flow, turn the flow control clockwise. Variable flow controls are also located on the remote control valve. The normal flow control setting is 1/4 turn open.




Figure 66

REMOTE HYDRAULIC CONTROL


FRONT OF TRACTOR




REMOTE CONTROL LEVERS
ON OPERATORS CONSOLE



VARIABLE FLOW CONTROLS
ON OPERATORS CONSOLE



REMOTE VALVE



REMOTE COUPLINGS AT REAR OF TRACTOR

Figure 67

REMOTE HYDRAULIC CONTROL

Operating the Remote Hydraulic Circuits

Connect the implement hoses to the remote couplings so that the implement lowers when the control lever is pushed forward and lifts when the lever is pulled to the rear.

NOTE: If there is too much restriction in the implement cylinders or other attachments, the restriction can cause a back pressure in the remote valve which will cause the remote lever on the console to return to neutral before the cylinder reaches full stroke. If this condition occurs, use the flow control to decrease the amount of fluid going to the implement. It is normal for the control lever to return to neutral when the cylinders reach full stroke.

FLOAT OPERATION



Figure 68



Figure 69

To operate the remote hydraulic control in a float condition, turn the control lever stop out of the lever slot. Push the control lever completely forward.

NOTE: Single action cylinders can be operated in a float or no float operation at the same time that the hitch is operated.

HYDRAULIC MOTORS

When operating hydraulic motors with the remote system, put the remote control lever in the forward position to run the motor and in the float position to stop the motor. Do not put the control lever in neutral position when the motor is in operation because damage to the motor and hoses can occur. Change hoses in the remote couplings to change the direction of turn of the motor.

REMOTE HYDRAULIC CONTROL

Hydraulic Hose Couplers

The tractor has ASAE R366 Standard Female couplings that fit any ASAE R366 and SAE J1036 Standard male hose coupler.

Your Authorized Case Dealer has ASAE Standard Male couplers, part number A147889 with 7/8"-14 UNF ASAE Standard threads, and A160937 with 1/2"-14 NPTF threads. See Inset A.

If the implement hoses do not have ASAE Standard 7/8"-14 UNF threads, use adapters to change the hoses. You can get the adapters from your Authorized Case Dealer. See Inset B. To adapt a John Deere male hose coupling to the tractor standard female coupling, use coupling adapter A160879. For adapting International Harvester male hose couplers, use coupling adapter A160880.



Figure 70

AIR INDUCTION SYSTEM

Tubes and Hoses

Check all hoses and tubes for cracks or wear. Replace if needed. Wash the induction system tubes in Case Filter Element Cleaner. Replace the vacuator valve if the valve is worn or damaged. Replace the air cleaner gasket if needed. When you assemble the parts, make sure the hoses are installed on the parts a minimum of 1-11/16 inches (42.9 mm).

NOTE: When the turbocharger intake hose is removed from the engine, check the inside of the hose for dust. If dust is found, completely wash the air intake system and the intake manifold. Check for leaks in the air intake system and the safety element.




Figure 94

NEUTRAL START SWITCH ADJUSTMENT

If the engine does not start with the range shift lever in Neutral position, or starts with the range shift lever in a gear position, use the following procedure to adjust the switches.

IMPORTANT: If the neutral start switches are loose, do not tighten the switches because the engine can then start with the transmission gears engaged. You must fully adjust the switches as shown below.

STEP 1




STEP 3



Put the range shift lever in Neutral position. Transmission gear shift levers will be in a vertical position.

Install neutral start switches without shims.

STEP 2



STEP 4



Remove neutral start switches and shims.

Connect a battery operated test lamp across the terminals of the top switch. Turn the top switch into the transmission until the test lamp illuminates.