



CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

Caterpillar
Operator's Manual
977 Traxcavator
S/n 53A1 & up

Operator's Manual

purchase full manual at

JENSALES.COM
or Call 800-443-0625



CLICK ANYWHERE FOR MORE DETAILS

THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
CATERPILLAR OR IT'S SUCCESSORS. **CATERPILLAR** AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

CT-O-TRAX 977

Table of Contents

	Page
LUBRICATION INSTRUCTIONS	6-24

Service Meter — General Lubricating Information —
Description of Lubricants — Lubrication Chart

OPERATION INSTRUCTIONS	25-53
------------------------	-------

Preparation For Use — Starting The Engine — Oper-
ating Starting Aids — After Starting — Driving The Trax-
cavator — Bucket Operation — Operating Procedure —
Methods of Filling Bucket — Operating Suggestions —
Stopping The Traxcavator — Stopping The Diesel En-
gine — Daily Care — Starting in Cold Weather —
Storage — Altitude Operation


MAINTENANCE INSTRUCTIONS	55-101
--------------------------	--------

Air Cleaners — Washing The Crankcase — Fuels —
Care Of The Fuel Supply — Care Of The Diesel Fuel
Tank — Fuel Filtering System — Priming the Fuel Sys-
tem — Fuel Injection Equipment — Starting Engine Fuel
System — Cooling System — Radiator Sealed Pressure
Overflow Unit — Radiator Fan Belts — Generator Belt
Adjustment — Diesel Engine Valve Clearance Adjust-
ment — Starting Engine Valve Clearance Adjustment —
Spark Plug Adjustment — Starting Engine Clutch And
Clutch Brake — Starting Engine Magneto — Steering
Clutches And Brakes — Bucket Kickout Lever Adjust-
ment — Bucket Positioner — Tracks — Final Drive
Sprocket Hub Bearings — Washing Gear Compartments
— Care Of The Hydraulic System — Electrical System
Electric Starter — Seat Adjustment

ATTACHMENT INSTRUCTIONS	103-110
-------------------------	---------

Buckets — Log And Lumber Fork — Top Clamp — Pulp-
wood Fork — Bulldozer Blade — Crankcase Guard —
Lighting Systems — Glow Plugs — Ether Starting Aid —
Fuel Priming Pump — Side Dump Bucket — Multi-Pur-
pose Bucket

INDEX	111-112
-------	---------



WARNING

When it is necessary to perform any work on the machine with the bucket raised, extend the lift arm support pins to prevent the bucket from accidentally dropping.



977 TRAXCAVATOR — RIGHT FRONT VIEW

1-Diesel fuel tank filler cap. 2-Bucket tilt control lever. 3-Bucket lift control lever. 4-Bucket lift kickout lever. 5-Lift arm support pin. 6-Bucket. 7-Hydraulic control tank. 8-Bucket positioner. 9-Bucket tilt hydraulic cylinder. 10-Bucket lift hydraulic cylinder. 11-Bucket lift arm. 12-Bucket tilt control linkage.

Identification of Points Of Lubrication, Lubricant To Apply And Interval Of Service


Point and Identification	Lubri- cant	SERVICE HOURS		
		10	50	2000
A SIDE DUMP BUCKET PIVOT POINTS	BR	X		
B SIDE DUMP BUCKET LATCH ASSEMBLY	CO		X	
C AUXILIARY HYDRAULIC CONTROL LEVER	BR			X
D MULTI-PURPOSE BUCKET HYDRAULIC CYLINDER AND PISTON ROD BEARINGS	BR	X		
E MULTI-PURPOSE BUCKET BOWL BEARINGS	BR	X		

CO Crankcase Lubricating Oil

B

SIDE DUMP BUCKET LATCH ASSEMBLY

Every 50 service hours check and refill if necessary. Fill through the opening of plug (1) until oil appears at opening of plug (2).



BR Ball and Roller Bearing Lubricant

A

SIDE DUMP BUCKET PIVOT POINTS

Lubricate the pivot points every 10 service hours.




C

AUXILIARY HYDRAULIC CONTROL LEVER

Lubricate every 2000 service hours. One fitting.





POSITIONING EXHAUST PIPE
1—Approximately 30°.



**SEAT CUSHION TIPPED
TO PROTECT PADDING**

moisture entering the padding under the covering. If the cushion is turned bottom side up in rainy weather the padding under the water proof covering may become damp. This moisture with accumulated dirt and heat will shorten the life of the cushion.

STARTING IN COLD WEATHER

If the starting engine and the diesel engine are both in good mechanical condition, and the precautions necessary for cold weather operation are taken, ordinary cold weather will not cause difficulty in starting or loss of efficiency.

Lubricants: As the atmospheric temperatures become lower, where warm housing facilities are not available, lubricants of lower viscosity should be used. See the topic, TYPE OF LUBRICANTS AND SAE GRADES TO USE.

Coolant: When the temperature is below freezing, sufficient anti-freeze solution should be used in the cooling system to prevent freezing. See the topic, COOLING SYSTEM.

The liquid in the cooling system may be warmed to make starting easier and quicker. When warming anti-freeze solutions, keep away from flames, as some of these solutions may be inflammable. Avoid getting the solution hot, and even a warm solution should be poured very slowly into a cold system to prevent damage by sudden expansion.

Hydraulic System: In temperatures below freezing, extra precaution should be taken to insure adequate pump lubrication. Before starting the engine, remove the filler cap on the hydraulic tank to relieve any vacuum which might be in the tank. Replace the filler cap. Do not allow the engine to run over half engine speed until after five minutes when the oil in the

Steering Clutch Brake Adjustment: After the first 10 service hours and every 250 service hours thereafter, check and adjust the steering clutch brakes as follows:

1. Remove the brake adjusting screw cover, taking care not to damage the gasket.
2. Turn the adjusting screw (1) in (clockwise) until the brake band is tight on the brake drum.
3. Turn the adjusting screw out (counterclockwise) $1\frac{1}{2}$ turns to provide proper clearance between the brake lining and the brake drum.

When properly adjusted, the brake pedals should have approximately 3 to 4 inches (7.6 to 10.2 cm.) free movement between the released and applied positions when checked by hand.



STEERING CLUTCH BRAKE
ADJUSTMENT


1-Adjusting screw.

Machines Before 53A1907

The steering clutches should be kept in proper adjustment to insure full engagement of the clutches when the levers are in the free forward

**STEERING CLUTCH CONTROL LEVER
FREE MOVEMENT**

- 1-There should be $2\frac{3}{8}$ to $2\frac{5}{8}$ inches (6.04 to 6.67 cm.) free movement at this point.



CLICK ANYWHERE FOR MORE DETAILS

5430354

5430354

CLICK ANYWHERE FOR MORE DETAILS

Index

	Page		Page
Air Cleaners	55	Electric Starting	31
Alternator	96	Electrical System	93
Altitude Operation	53	Electric Starter	101
Attachment Instructions	103	Ether Starting Aid	107
		Excavating	46
Ball and Roller Bearing		Fan Belt Adjustment	72
Lubricant	7-24	Final Drive Sprocket Hub	
Battery	94	Bearings	91
Bucket Control Levers	40	Fuel Filter Elements	63
Bucket Installation	101	Fuel Filter	
Bucket Kickout		Primary	62
Lever Adjustment	86	Final	62
Bucket Operation	40	Fuel Injection Equipment	66
Bucket Positioner	87	Fuel Injection Pumps	68
Bucket Teeth	101	Fuel Injection Valves	66
Bucket Tilt Control Lever	41	Fuel Pressure Gauge	35
Buckets	103	Fuel Priming Pump	108
Bulldozer Blade	105	Fuel Supply, Care of the	60
		Fuel Filtering System	62
Capacities	Inside Back Cover	Fuel System, Priming the	64
Carburetor	69	Fuel System, Starting Engine	69
Care of the Diesel Fuel Tank	61	Fuels	59
Care of the Fuel Supply	60	Gasoline Engine Starting	27
Care of the Hydraulic System	93	Gauges	35
Carrying Loads	46	Ammeter	36
Charging Alternator	96	Fuel Pressure	35
Circuit Breaker	98	Oil Pressure	35
Clutch, Starting Engine	75	Torque Converter Temperature	36
Coolants	70	Transmission Oil Pressure	36
Cooling System	70	Water Temperature	36
Crankcase Guard	105	Generator	95
Crankcase Lubricating Oil	7-10	Generator Belt Adjustment	73
Crankcase Lubricating Oil		Generator Regulator	95
Change Period Chart,		Glow Plugs	106
Diesel Engine	9		
Daily Care	49	Hose Replacement	93
Description of Lubricants	7	Hydraulic System, Care of the	93
Diesel Engine Crankcase		Leveling	46
Lubricating Oil Change		Lighting Systems	105
Periods	9	Loading From Stock Pile	43
Diesel Engine Valve		Loading Trucks	46
Clearance Adjustment	73	Log and Lumber Fork	104
Diesel Fuel Tank, Care of the	61	Loose Dry Materials	46
Diesel Fuel Tank Filler Cap	61	Lubricating Grease	7
Digging Below Ground Level,		Lubrication Information, General	6
In Hard Ground	45	Lubrication Chart	9A
In Soft Ground	44	Lubrication Instructions	6
Draining the Cooling System	70	Lubrication of Attachments	22
Draining the Steering Clutch		Lubrication of Miscellaneous	
Compartment	85	Points	6
Driving the Traxcavator	37		

INDEX—Continued

	Page		Page
Magneto	77	Starting Aid Chart	33
Maintenance Instructions	55	Starting Engine Clutch and Clutch Brake	75
Methods of Filling Bucket	42	Starting Engine Fuel System	69
Model Views	4-5	Starting Engine Magneto	77
Multi-Purpose Bucket	109	Starting Engine Valve Clearance Adjustment	74
Multi-Purpose Bucket Position Indicator and Bowl Indicator	110	Starting in Cold Weather	50
Oil Pressure, Lubricating	35	Starting the Engine	25
Oil Specification Chart	8	Starting the Diesel Engine	29
Oil Viscosity Recommendations	8	Starting the Starting Engine	28
Operating In Deep Mud or Water	39	Steering Clutches and Brakes	80
Operating Over an Obstruction	39	Stopping the Diesel Engine	48
Operating Procedure	42	Stopping the Traxcavator	47
Operating Starting Aids	32	Storage	52
Operating Suggestions	47	Stripping or Leveling	46
Operation Instructions	25	Temperature, Operating, Diesel Engine	35
Operator's Responsibility	25	Top Clamp	105
Polarizing	95	Torque Converter Temperature	36
Position Controls for Starting	27-31	Tracks	88
Preparation for Use	25	Transmission Oil Pressure	36
Primary Fuel Filter	62	Transporting	47
Priming Pump	106	Traxcavator Initial Service	25
Priming the Fuel System	64	Traxcavator Recheck	25
Pulpwood Fork	105	Type of Lubricants and SAE Grades to Use	8
Pumps, Fuel Injection	68	Valve Clearance Diesel Engine	74
Radiator Fan Belts	72	Starting Engine	74
Radiator Sealed Pressure Overflow Unit	71	Valve, Fuel Injection	66
Recheck	25	Valve Rotators	74
Seat Adjustment	101	Washing Gear Compartments	92
Sediment Bowl Filter	69	Washing the Final Drive	92
Serial Number Location	Inside Back Cover	Washing the Crankcase	59
Service Meter	6	Washing the Range Selector and Bevel Gear Compartment	92
Shifting Gears	37	Water Temperature	35
Side Dump Bucket	110	Wiring	97
Spark Plug Adjustment	75	Wiring Diagram	98
Starter, Electric	99		

or Call 800-443-0625