

CLICK ANYWHERE FOR MORE DETAILS



MANUAL PREVIEW

Caterpillar

Service Manual

3208 Engine

S/n 75V1 & 90N1

purchase full manual at

Service Manual

JENSALES.COM

or Call 800-443-0625



CLICK ANYWHERE FOR MORE DETAILS

THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
CATERPILLAR OR IT'S SUCCESSORS. CATERPILLAR AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

CT-S-ENG 3208

FORM NO. SENR7105

FOR USE IN SERVICE MANUALS:
3208 ENGINE, REG01658
V160 THRU V300 LIFT
TRUCKS, REG01275

CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

JENSALES®

purchase full manual at

JENSALES.COM

DISASSEMBLY AND ASSEMBLY

or Call 800-443-0625

3208 INDUSTRIAL
& MARINE ENGINES

CLICK ANYWHERE FOR MORE DETAILS

SERIAL NUMBERS

75V1-UP

90N1-UP

CLICK ANYWHERE FOR MORE DETAILS

INTRODUCTION

This publication has instructions and procedures for the subject on the front cover. The information, specifications, and illustrations in this publication are on the basis of information that was current at the time this issue was written.

Correct operation, maintenance, test and repair procedures will give this product a long service life. Before starting a test, repair or rebuild job, the serviceman must read the respective sections of the Service Manual, and know all the components he will work on.

Your safety, and the safety of others, is at all times very important. When you see this symbol  or this symbol  in the manual, you must know that caution is needed for the procedure next to it. The symbols are warnings. To work safely, you must understand the job you do. Read all instructions to know what is safe and what is not safe.

It is very important to know the weight of parts. Do not lift heavy parts by hand. Use a hoist. Make sure heavy parts have a good stability on the ground. A sudden fall can cause an accident. When lifting part of a machine, make sure the machine has blocks at front and rear. Never let the machine hang on a hoist, put blocks or stands under the weight.

When using a hoist, follow the recommendation in the manual. Use correct lift tools as shown in illustrations to get the correct balance of the component you lift. This makes your work safer at all times.

JENSALES.COM

40400X3

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

SYSTEMS OPERATION

Air Inlet and Exhaust System (Marine Engines)		Starting Motor	35
With Turbocharger	19	Wiring Diagrams	37, 38
Turbocharger	20	Fuel System (75V1-Up, 90N6121-Up)	10
Air Inlet and Exhaust System	16	Automatic Timing Advance Unit	14
Basic Block	34	Constant Bleed Valve	13
Crankshaft	34	Flow of Fuel Using the Priming Pump	13
Cylinder Block	34	Fuel Temperature Compensated Torque	
Cylinder Head	34	Control Group	13
Pistons, Rings and Connecting Rods	34	Function of Fuel Junction Block	15
Vibration Damper	34	Operation of 9L6969 & 9N3979 Fuel	
Cooling System (Industrial Engines)	27	Injection Nozzle	14
Cooling System (Marine Engines)		Operation of Fuel Injection Pumps	13
Without Turbocharger	30	Water Separator	16
Cooling System (Marine Engines)		Fuel System (90N1-90N6120)	4
With Turbocharger	32	Automatic Timing Advance Unit	8
Cylinder Head and Valves (75V1-75V1446, 90N1-90N6120)	21	Constant Bleed Valve	6
Cylinder Head and Valves (75V1447-Up, 90N6121-Up)	22	Flow of Fuel Using the Priming Pump	6
Electrical System	35	Function of Fuel Junction Block	7
Alternator	35	Operation of 9L7883 Fuel Injection Nozzle	7
Circuit Breaker	36	Operation of Fuel Injection Pumps	6
Regulator	35	Lubrication System (Engines With Oil Filter	
Solenoid	36	Bypass Valve in Oil Filter)	23
		Lubrication System (Engines With Oil Filter	
		Bypass Valve in Oil Cooler Base)	25

TESTING AND ADJUSTING

For INDEX see page 39.

SPECIFICATIONS

NOTE: For Specifications with illustrations, make reference to SPECIFICATIONS FOR 3208 INDUSTRIAL & MARINE ENGINES Form No. REG01684. If the Specifications in Form No. REG01684 are not the same as in the Systems Operation and the Testing and Adjusting, look at the printing date on the back cover of each book. Use the Specifications given in the book with the latest date.

INTRODUCTION

CLICK ANYWHERE FOR MORE DETAILS

This publication has instructions and procedures for the subject on the front cover. The information, specifications, and illustrations in this publication are on the basis of information that was current at the time this issue was written.

The "Alphabetical and Service Index" is a list of all components and service operations found in this manual. It gives page numbers and also an operation number for each component.

All operations in the column "Component Operation" are removal and installation instructions, unless other descriptions are given for the operations. The numbers under the column "Operation" are numbers given to each operation for use under the column "Other Needed Operations" which gives all other component operations by number that are necessary to do the respective job.

Correct operation, maintenance, test and repair procedures will give this product a long service life. Before starting a test, repair or rebuild job, the serviceman must read the respective sections of the Service Manual, and know all the components he will work on.

Your safety, and the safety of others, is at all times very important. When you see this symbol  or this symbol  in the manual, you must know that caution is needed for the procedure next to it. The symbols are warnings. To work safely, you must understand the job you do. Read all instructions to know what is safe and what is not safe.

It is very important to know the weight of parts. Do not lift heavy parts by hand. Use a hoist. Make sure heavy parts have a good stability on the ground. A sudden fall can cause an accident. When lifting part of a machine, make sure the machine has blocks at front and rear. Never let the machine hang on a hoist, put blocks or stands under the weight.

When using a hoist, follow the recommendation in the manual. Use correct lift tools as shown in illustrations to get the correct balance of the component you lift. This makes your work safer at all times.

44300x3

CLICK ANYWHERE FOR MORE DETAILS

CRANKSHAFT PULLEY

REMOVE CRANKSHAFT PULLEY
(INDUSTRIAL ENGINE)

11-1205

Tools Needed		A
5F7465	Puller Assembly	1
8B7560	Step Plate	1
5M2894	Washer	1
S1590	Bolt	1

1. Remove alternator belts.

2. Remove bolt (1) and washer (2).

3. Install tooling (A) on crankshaft pulley (3) and remove the crankshaft pulley.

INSTALL CRANKSHAFT PULLEY
(INDUSTRIAL ENGINE)

12-1205

Tools Needed		A
1F7464	Bolt 1"-14 NF x 4" long	1


1. Put clean engine oil on the lip of the front crankshaft seal and sealing surface of the crankshaft pulley.

2. Put crankshaft pulley (1) in position on end of crankshaft.

3. Install a standard washer and tool (A) in pulley and tighten bolt until the pulley makes contact with the crankshaft gear. Remove tool (A) and the standard washer.

4. Install the original washer and bolt in the end of the crankshaft. Tighten the bolt to a torque of 460 ± 60 lb. ft. (63.6 ± 8.3 mkg).

5. Install the alternator belts. Make an adjustment to the belt tension. See FAN AND ALTERNATOR BELTS in LUBRICATION AND MAINTENANCE GUIDE.



CAMSHAFT AND GEARS

INSTALL CAMSHAFT AND GEARS

12-1210 & 1212

Tools Needed		A
3P1544	Timing Pin	1

1. Put clean engine oil on the camshaft lobes and journals. Install camshaft (1) and the gears as a unit. Make sure the timing marks on the crankshaft gear and camshaft gear are in alignment.

2. Install the thrust pin. Tighten the pin to a torque of 35 ± 5 lb.ft. (4.8 ± 0.7 mkg).



3. Put gear (3) in position and install tachometer drive adapter shaft (2). Tighten the shaft to a torque of 80 ± 5 lb. ft. (11.1 ± 0.7 mkg).

NOTE: See Step 2 and NOTE on Pages 13 and 16 for earlier and later tachometer drive shaft torques.

4. After valve lifters and timing gear cover have been installed, check the timing as follows:

- a) Remove timing pin (A).
- b) Turn the crankshaft clockwise as seen from the front of the engine approximately $1/2$ turn. Install timing pin (A) again.
- c) While turning the crankshaft clockwise, push on timing pin (A) until it slides into the groove (slot) in the fuel injection pump camshaft.
- d) Remove the plug from the timing hole in the front cover and install a $5/16''$ -18 NC bolt (4) $2\ 1/2$ in. long. The cover bolt from hole (5) can be used. Turn the crankshaft clockwise until bolt (4) can be installed into the timing gear and is in the center of the timing hole. The camshaft for the fuel injection pump is now in correct time with the engine.

- e) Remove the bolt and install the plug. Remove timing pin (A) and install the plug.



FUEL INJECTION PUMP

Firing order (injection sequence) 1, 2, 7, 3, 4, 5, 6, 8
 Injection timing before TC (top center) 16°

Torque for the nuts that hold the fuel lines (Use
 5P144 Fuel Line Socket) 30 ± 5 lb. ft. (4.1 ± 0.7 mkg)

4N605 Spring for bypass valve:

Length under test force 1.231 in. (31.27 mm)
 Test force 1.41 ± 0.14 lb. (0.639 ± 0.006 kg)
 Free length after test 1.504 in. (38.21 mm)
 Outside diameter531 in. (13.49 mm)

- (1) Bore in the rear bearing for the camshaft (new) 2.3750 ± .0005 in. (60.325 ± 0.013 mm)
 Diameter of rear bearing surface (journal) of the camshaft (new) 2.3720 ± .0005 in. (60.249 ± 0.013 mm)
 Maximum permissible clearance between the bearing and the camshaft bearing surface (journal) (worn)006 in. (0.15 mm)
- (2) Torque for screws that hold sleeve control levers 24 ± 2 lb. in. (27.7 ± 2.3 cm.kg)
- (3) Bore in the housing for the fuel control shaft (new)3543 ± .0005 in. (8.999 ± 0.013 mm)
 Diameter of sleeve control shaft (new)3530 ± .0003 in. (8.966 ± 0.008 mm)
 Maximum permissible clearance between the bore in the housing and the sleeve control shaft (worn)003 in. (0.07 mm)

- (4) End play for camshaft with sleeve installed (new)023 ± .018 in. (0.58 ± 0.46 mm)

NOTE: When installing sleeve on end of camshaft, support the camshaft to prevent damage to parts inside of injection pump and governor housing.



- (5) Bore in the front bearing for the camshaft (new) 1.0005 ± .0005 in. (25.413 ± 0.013 mm)
 Diameter of front bearing surface (journal) of the camshaft (new)9990 ± .0005 in. (25.375 ± 0.013 mm)
 Maximum permissible clearance between the bearing and the camshaft bearing surface (journal) (worn)004 in. (0.10 mm)

- (6) Torque for bushing 70 ± 5 lb. ft. (9.7 ± 0.7 mkg)
- (7) Distance from top of pin (11) to top of shafts (9 and 10) with 3P1546 Calibration Pin installed0828 in. (2.103 mm)

- (8) Torque for screws that hold crossover levers 24 ± 2 lb. in. (27.7 ± 2.3 cm.kg)

(12) 4N4318 Spring for injection pump:

Length under test force 1.348 in. (34.24 mm)
 Test force 12.5 ± 1.3 lb. (5.67 ± 0.58 kg)
 Free length after test 1.566 in. (39.78 mm)
 Outside diameter728 ± .010 in. (18.49 ± 0.25 mm)



NOTE: FOR TORQUE VALUES NOT GIVEN, SEE THE FIRST PAGE OF SPECIFICATIONS FOR GENERAL TIGHTENING TORQUES

MANIFOLD AND VENTILATION VALVE
(Industrial Engines)




Put 8H5137 Form A Gasket on threads of adapter and plug.

- (1) Torque for adapter 108 ± 36 lb. in. (125 ± 44 cm.kg)
- (2) Torque for plug 108 ± 36 lb. in. (125 ± 44 cm.kg)
- (3) Torque for bolts holding the exhaust manifold 32 ± 5 lb. ft. (4.4 ± 0.7 mkg)

Locks must be bent on a flat side of the bolt head. Bolts must be turned no more than 30° of a turn for the alignment of locks with a flat side of the bolt head.

MANIFOLD AND VENTILATION VALVE
(Marine Engines)




Put 8H5137 Form A Gasket on threads of adapter and plug.

- (1) Torque for adapter 108 ± 36 lb. in. (125 ± 44 cm.kg)
- (2) Torque for plug 108 ± 36 lb. in. (125 ± 44 cm.kg)
- (3) Torque for bolts holding the exhaust manifold 32 ± 5 lb. ft. (4.4 ± 0.7 mkg)

JENSALES.COM

or Call 800-443-0625

AIR INLET MANIFOLD



Tighten bolts (3) and (4) to 15 ± 5 lb. ft. (2.0 ± 0.7 mkg)

Tighten all bolts in number

sequence to 32 ± 5 lb. ft. (4.4 ± 0.7 mkg)