



CLICK ANYWHERE FOR MORE DETAILS

Cummins

Service Manual

V/VT-378, V/VT-504,

and V/VT-555

Engines

JENSALES.COM

or Call 800-443-0625

JENSALES

CLICK ANYWHERE FOR MORE DETAILS

THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
CUMMINS OR IT'S SUCCESSORS. **CUMMINS** AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

CUM-S-V-VT378PLUS

Service Manual



**V/VT-378, V/VT-504
and V/VT-555
C.I.D. Engines
Shop Manual**

CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

JENSALES®

purchase full manual at

JENSALES.COM

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

Shop Manual

**Cummins Diesel
V/VT-378, V/VT-504
and V/VT-555 C.I.D.
Engines**

VT-555

VT-504 "Big Cam"

V-378

V-504

Copyright © 1979
Cummins Engine Company, Inc.

Bulletin No. 3379069-03 Printed in U.S.A. 4-79

Table of Contents

Group 0 — Engine Disassembly	0-1
Group 1 — Cylinder Block	1-1
Cylinder Block, Liners, Crankshaft, Main Bearings, Connecting Rods, Pistons, Vibration Damper, Gear Cover, Camshaft and Front Cover	
Group 2 — Cylinder Head	2-1
Cylinder Head, Valve Seats, Injector Sleeves, Injector Tip Protrusion, Valve Guides, Springs, Crossheads and Guides	
Group 3 — Rocker Lever	3-1
Rocker Levers, Cover and Crankcase Breather	
Group 4 — Tappets	4-1
Tappets and Push Rods	
Group 5 — Fuel System	5-1
Group 6 — Injectors and Connections	6-1
Group 7 — Lubrication System	7-1
Oil Pump, Oil Pan, Oil Dipstick, Oil Filters, Oil Lines and Oil Coolers	
Group 8 — Cooling System	8-1
Engine Water Pump, Fan Hub, Fan, Thermostats and Housing, Heat Exchanger, Converter Cooler and Raw Water Pump	
Group 9 — Drive Units	9-1
Fuel Pump, Drive Pulley	
Group 10 — Air Intake System	10-1
Cold Starting Aids, Air Cleaners and Piping, Turbochargers	
Group 11 — Exhaust System	11-1
Group 12 — Air Equipment	12-1
Group 13 — Electrical Equipment	13-1
Group 14 — Engine Assembly and Testing	14-1
Group 15 — Instruments and Controls	15-1
Group 16 — Mounting Adaptations	16-1
Flywheel and Marine Gear	
Group 17	None
Group 18 — Specifications	18-1
Wear Limits, Lubricating Oil, Cooling, Grease and Torque Limits	
Group 19	None
Group 20 — Vehicle Braking	20-1
Exhaust Brake and Intake Suppressor	
Group 21 — Power Generator	None
Index	



Fig. 2-10, (V10226). Counterbore for valve seat.

4. Cut the counterbore 0.006 to 0.010 inch [0.15 to 0.25 mm] deeper than the insert thickness to permit staking or peening of the head to hold the insert. Allow the cutter to dwell upon reaching the proper depth to insure a flat seating surface.
5. Install the swirl plate in the intake valve seat counterbores with the locking tang in positioning groove.

Note: On engines certified by the Environmental Protection Agency and the California Air Research Board, the swirl plate is located 180 degrees from standard. See your local distributor for the correct replacement part.

6. Install the valve seat insert and stake the insert in the head using ST-1122 Tool Driver over the shaft of ST-1128 Insert Staking Tool. A 1/4 inch [6.35 mm] diameter round end punch may be used if a staking tool is not available.

Caution: Over staking around the insert may crack the cylinder head.

Grind Valve Seats

1. Use ST-685 Valve Seat Grinder and the correct arbor from ST-804 Valve Guide Arbor Set.
2. Check the valve seat width. It should be 0.063 to 0.125 inch [1.59 to 3.18 mm]. See 1 or 2, Fig. 2-3.
3. If the seating area (1, Fig. 2-3) is wider than 0.125 inch [3.18 mm] maximum, stock can be removed from above and below the valve seating area (1) with specially dressed stones. Narrowing should not extend beyond the chamfer or the valve seat insert. The chamfer provides metal for staking or peening.

Table 2-1: Valve Seat Insert

Part No.	ST-Cutter	Oversize Diameter	Oversize Thickness	Insert Outside Diameter	Cylinder Head Inside Diameter	Insert Thickness	Counterbore Depth In Head Intake	Counterbore Depth In Head Exhaust
195001	ST-258-1	0.010 [0.25]	Std.	1.700/1.701 [43.18/43.21]	1.697/1.698 [43.10/43.13]	0.176/0.181 [4.47/4.60]	0.351/0.361 [8.92/9.17]	0.329/0.339 [8.36/8.61]
195002	ST-258-2	0.020 [0.51]	0.005 [0.13]	1.710/1.711 [43.43/43.46]	1.707/1.708 [43.36/43.38]	0.181/0.186 [4.60/4.72]	0.356/0.366 [9.04/9.30]	0.334/0.344 [8.48/8.74]
195003	ST-258-3	0.030 [0.76]	0.010 [0.25]	1.720/1.721 [43.69/43.71]	1.717/1.718 [43.61/43.64]	0.186/0.191 [4.72/4.85]	0.361/0.371 [9.17/9.42]	0.339/0.349 [8.61/8.86]
195004	ST-258-4	0.040 [1.02]	0.015 [0.38]	1.730/1.731 [43.94/43.97]	1.727/1.728 [43.87/43.89]	0.191/0.196 [4.85/4.98]	0.366/0.376 [9.30/9.55]	0.344/0.354 [8.74/8.99]
154391	ST-258-1	0.010 [0.25]	Std.	1.700/1.701 [43.18/43.21]	1.697/1.698 [43.10/43.13]	0.196/0.201 [4.98/5.11]	0.351/0.361 [8.92/9.17]	
154392	ST-258-2	0.020 [0.51]	0.005 [0.13]	1.710/1.711 [43.43/43.46]	1.707/1.708 [43.36/43.38]	0.201/0.206 [5.11/5.23]	0.356/0.366 [9.04/9.30]	
154393	ST-258-3	0.030 [0.76]	0.010 [0.25]	1.720/1.721 [43.69/43.71]	1.717/1.718 [43.61/43.64]	0.206/0.211 [5.23/5.36]	0.361/0.371 [9.17/9.42]	
154394	ST-258-4	0.040 [1.02]	0.015 [0.38]	1.730/1.731 [43.94/43.97]	1.727/1.728 [43.87/43.89]	0.211/0.216 [5.36/5.49]	0.366/0.376 [9.30/9.55]	

Be sure to measure insert **before** machining head or installing insert in head.

Crankshaft Pulley/Vibration Damper

V/VT-378 and V/VT-504

1. Clean the crankshaft and vibration damper mating faces thoroughly with a wire brush or abrasive cloth. Install the pulley/vibration damper combination to the crankshaft. Torque the capscrews alternately in 30 to 35 ft-lb [41 to 47 N•m] increments to a final torque of 110 to 120 ft-lb [149 to 162 N•m].
2. With a dial gauge mounted to the front cover check the vibration damper eccentricity and wobble as shown in Fig. 14-22 and Fig. 14-23. Wobble must not exceed 0.006 inch per 1 inch of radius [0.15 mm per 25 mm]. Eccentricity must not exceed 0.004 inch per 1 inch of diameter [0.10 mm per 25 mm].



Fig. 14-22, (V114161). Check eccentricity.



Fig. 14-23, (V114162). Check wobble.

3. When an accessory drive pulley is mounted in front of the vibration damper the pulley must also be checked. Readings taken with an indicator gauge mounted to the gear case cover must not exceed the values given above.
4. On Marine engines secure the sea water pump drive pulley to the vibration damper. Torque the capscrews to 30 to 32 ft-lb [41 to 43 N•m].

V/VT-555

1. Clean the crankshaft and vibration damper mounting surface. Position the vibration damper to the crankshaft and secure it with hardened washers and capscrews. Tighten alternately in 30 to 35 ft-lb [41 to 47 N•m] increments to a final torque of 135 to 140 ft-lb [183 to 190 N•m].
2. With a dial gauge mounted to the front cover check the vibration damper eccentricity and wobble as shown in Fig. 14-22 and Fig. 14-23. The run-out must not exceed values given for V-378 and V-504.
3. Install the drive pulley (if removed) to the vibration damper. The pulley must also be checked. Readings taken with an indicator gauge mounted to gear cover must not exceed the values above. Torque the capscrews in 20 ft-lb [27 N•m] increments to a final torque of 90 to 100 ft-lb [122 to 136 N•m].

Cylinder Heads

1. Make sure the breather vent tube assemblies on the naturally aspirated cylinder heads are in place. On turbocharged engines check to see that the vent holes are plugged.

Note: Resurfaced blocks require thicker head gaskets than new blocks. They are available in 0.010 inch [25 mm] and 0.020 inch [0.51 mm] oversize. Oversize head gaskets still have grommets and O-rings.

2. Install the head gasket over the oil ring dowels so the word "Top" on the gasket is visible. Install the guide studs in the block.

Caution: When assembling the new style cylinder head gasket to the engine make sure the two (2) end cap gaskets are properly located. The block and head surfaces must be clean and dry and oil or adhesive must never be used.

3. Use an ST-862 Head Lifting Bracket to lift the cylinder head with a hoist and lower it into place over the ring dowels.

Index

Accessory Drive	9-1	Camshaft, Assemble	1-18
Assemble	9-1	Bushing, Replace	1-4
Disassemble	9-1	Bushings, Inspect	1-2
Inspect	9-1	Disassemble	1-18
Install	14-23	Inspect	1-18
Pulleys	9-2	Install	14-11
Remove	0-5	Key Data	14-12
Specifications	9-3, 18-11	Remove	0-9
Acid Cleaning	0-11	Capacity, Lubricating Oil Pan	7-4
Adapter Assembly, Spin-On Lube Oil Filter	7-6	Capscrew Torques	18-1
Adapter Inspect, Spin-On Lube Oil Filter	7-6	Chassis Dynamometer Testing	14-39
Adapter, Crankshaft, Install	14-19	Cleaning, Bead Blast	0-11
Adapter, Flywheel, Remove	0-6	Solvent and Acid	0-11
Air Cleaner Restriction Indicator	10-2	Steam	0-11
Air Cleaners, Service	10-1	Clearance, Valve	14-28
Air Compressor	12-1	Cold Starting Aids	10-1
Install	14-22	Cold Weather Starting Procedure	14-35
Remove	0-5	Compressor, Air	12-1
Air Connections, Remove	0-3	Install	14-22
Cranking Motor	12-1	Remove	0-5
Equipment	12-1	Connecting Rod and Piston Assemblies, Remove	0-9
Intake Connections and Manifolds, Remove	0-4	Assemble to Piston	1-17
Intake Manifolds, Install	14-24	Clean	1-12
Manifold Crossover, Install	14-24	Inspect	1-13
Restriction	18-12	Nuts, Torque	14-6
Starter	12-1	Repair	1-14
Alignment, Marine Gear	16-1	Connecting Rods and Piston, Install	14-5
Alternator, Install	14-31	Controls, Nason Safety	16-1
Arctic Operations	18-2	Converter Cooler	8-7
Assembly Specifications, Engine	14-41, 18-13	Coolant, Engine	14-37
Back Pressure, Exhaust	18-12	Coolant Recommendations	18-4
Bead Blast Cleaning	0-11	Cooling Fans	8-5
Bearing Caps, Inspect	1-2	Cooling System Specifications	18-11
Shell, Inspect	1-12	Corrosion	1-2
Shells and Thrust Ring	1-12	Counterbore, Inspect	1-2
Belt Tension, Adjust	14-26	Crack Detection, Cylinder Head	2-2
Belts, Install	14-26	Crankcase Breathers, Clean and Inspect	3-2
Belts, Remove	0-3	Cranking Motor	12-1
Block, Clean	1-1	Cranking Motor, Install	14-32
Disassemble	1-1	Crankshaft Adapter, Install	14-19
Exploded View	1-1	and Main Bearings, Install	14-1
Inspect	1-1	and Main Bearings, Remove	0-10
Service Tools	1-19	Assemble	1-11
Specifications	1-20, 18-7	Clean	1-10
Brakes, Exhaust	20-1	Disassemble	1-10
Braking, Vehicle	20-1	Inspect	1-11
Break-In Oil	18-1	Pulley, Install	14-10
Breathers, Clean and Inspect	3-2	Thrust Ring, Inspect	1-12
By-Pass Filter	7-6	Crosshead Guides and Crosshead, Inspect	2-3
Assembly	7-7	Crosshead Guides, Replace	2-5
Disassemble	7-6	Crossheads, Adjust	14-28
Inspect	7-7	Inspect	2-3
		Install	14-15

Cylinder Block, Clean	1-1	Firing Order	14-27
Disassemble	1-1	Installation	14-34
Exploded View	1-1	Storage	14-39
Inspect	1-1	Storage, Permanent	14-39
Service Tools	1-19	Storage, Temporary	14-39
Specifications	1-20, 18-7	Test Procedure	14-35
Water Cover Plate, Install	14-9	Testing	14-33
Cylinder Head, Assemble	2-9	Exhaust Back Pressure	18-12
Capscrew Torque	14-16	Brakes	20-1
Clean	2-1	Manifolds, Install	14-29
Cover, Install	14-29	Manifolds, Remove	0-2
Crack Detection	2-2	System	11-1
Disassemble	2-1	System Specifications	18-12
Exploded View	2-1	Exploded View, Cylinder Block	1-1
Resurface	2-5	Cylinder Head	2-1
Service Tools	2-10	Engine	14-1
Specifications	2-11, 18-9	Lubricating Oil Pump	7-1
Test	2-1	Rocker Lever and Shaft	3-1
Water Hole Repair	2-4	Tappet	4-1
Cylinder Heads, Install	14-10	Water Pump	8-1
Cylinder Heads, Remove	0-6	Fan Hub and Fan, Install	14-25
Cylinder Liner Bore, Inspect	14-5	Assemble	8-4
Clean	1-10	Disassemble	8-3
Counterbore, Inspect	1-2	Inspect	8-4
Inspect	1-10	Remove	0-3
Lower Bore, Inspect	1-3	Fan, Remove	0-3
Lower Bore, Repair	1-4	Fans, Radiator	8-5
Protrusion, Inspect	14-5	Filter and Adapter Assembly	7-6
Cylinder Liners, Install	14-4	Firing Order	14-27
Cylinder Liners, Remove	0-11	Flywheel Adapter, Remove	0-6
Damper, Clean	1-12	Housing, Install	14-19
Inspect	1-12	Housing, Remove	0-6
Install	14-10	Install	14-21
Remove	0-4	Remove	0-6
Vibration	1-12	Ring Gear, Replace	16-1
Dataplate	0-1	Front Cover, Install	14-7
DCA Water Filter	8-8, 18-4	Oil Seal, Install	14-7
Delco-Remy Equipment	13-1	Remove	0-8
Dipstick	7-3	Front Engine Supports, Install	14-24
and Tube, Install	14-30	Front Engine Supports, Remove	0-4
and Tube, Remove	0-2	Front Lifting Bracket, Remove	0-3
Disassembly Service Tools	0-12	Front Water Connections, Remove	0-3
Dye Penetrants	1-2	Crossover, Install	14-9
Dynamometer	14-34	Crossover, Remove	0-4
Dynamometer Testing, Chassis	14-39	Fuel Connections, Remove	0-3
Electrical Components	13-1	Fuel Lines, Install	14-24
Electrical Equipment	13-1	Fuel Lines, Remove	0-3
Engine Assembly and Testing	14-1	Fuel Oil Filter, Install	14-30
Assembly Service Tools	14-40	Fuel Oil Recommendations	18-3
Assembly Specifications	14-41, 18-13	Fuel Pressures	14-38
Coolant	14-37	Fuel Pump Drive, Install	14-23
Dataplate	0-1	Remove	0-6
Disassembly	0-2	Specifications	18-11
Dynamometer	14-34	Fuel Pump, Install	14-23
Exploded View	14-1	Nameplate	5-1
		Remove	0-5

Fuel System	5-1	Lower Bore, Inspect	1-3
Fuel System Priming	14-33	Lower Bore, Repair	1-4
		Protrusion, Inspect	14-5
Gear Cover Spacer Plate, Install	14-7	Liners, Install	14-4
Gear Cover Spacer Plate, Remove	0-9	Liners, Remove	0-11
Gear Housing, Install	14-17	Lubricating Oil Coolers, Assemble	7-10
Grease Recommendations	18-2	Coolers, Disassemble	7-9
		Coolers, Inspect	7-9
Head, Assemble	2-9	Coolers, Install	14-4
Capscrew Torque	14-16	Coolers, Repair	7-10
Clean	2-1	Dipstick	7-3
Cover, Install	14-29	Filter and Adapter	7-6
Disassemble	2-1	Filter and Adapter, Assembly	7-6
Exploded View	2-1	Filter and Adapter, Inspect	7-6
Resurface	2-5	Filter, Assemble	7-5
Service Tools	2-10	Filter, Install	14-4, 14-30
Specifications	2-11, 18-9	Filters	7-4
Heads, Install	14-10	Filters, Inspect	7-5
Heads, Remove	0-6	Hose Size	7-7
Heat Exchanger, Assemble and Test	8-6	Hose Specifications	7-7
Clean	8-6	Lines	7-7
Disassemble	8-6	Lines, Assemble	7-8
Inspect and Repair	8-6	Pan	7-3
Install	14-31	Pan Capacity	7-4
Remove	0-2	Pan, Inspect	7-3
Hose Specifications	7-7	Pan, Repair	7-3
		Pump, Assemble	7-2
Injection Timing	14-11	Pump, Disassemble	7-1
Injection Timing Specifications	14-13	Pump, Exploded View	7-1
Injector Recess Surface Repair	2-7	Pump, Inspect	7-1
Sleeves	2-2	Pump, Install	14-7
Sleeves, Replace	2-7	Pump, Remove	0-8
Tip Protrusion	2-2	Pump, Repair	7-2
Injectors	6-1	Pump Specifications	7-11
Adjust	14-28	System Service Tools	7-10
Install	14-17	Lubricating System, Prime	14-33
Remove	0-6	Lubricating System Specifications	18-10
Installation, Engine	14-34		
Instrument and Control	15-1	Main Bearing Bore, Inspect	1-4
Intake Air Restriction	18-12	Caps, Inspect	1-2
Air System	10-1	Capscrew Torque	14-2
Air System Specifications	18-12	Main Bearings, Install	14-1
Connections and Manifold, Remove	0-4	Main Bearings, Remove	0-10
Manifolds and Connections, Clean and Inspect	10-1	Marine Gear Alignment	16-1
Manifolds, Install	14-24	Install	14-32, 16-1
Suppressors	20-1	Oil Cooler, Install	14-32
		Oil Cooler, Remove	0-2
Key Data	14-12	Oil Coolers	7-10
Leece-Neville Equipment	13-1	Marine Rear Accessory Drive, Install	14-23
Left Bank Water Header Cover Plate, Install	14-29	Mechanical Controls, Remove	0-3
Lifting Bracket, Remove	0-3	Mount Cylinder Block to Engine Stand	14-1
Lifting Eye, Install	14-24	Mount Engine on Engine Stand	0-3
Liner Bore, Inspect	14-5	Mounting Adaptations	16-1
Clean	1-10		
Counterbore, Inspect	1-2	Nameplate, Fuel Pump	5-1
Inspect	1-10	Nason Safety Controls	15-1, 16-1
		Normal Starting Procedure	14-34

Oil, Break-In	18-1	Priming the Fuel System	14-33
Cooler, Remove	0-8	Priming the Lubricating System	14-33
Coolers, Assemble	7-10	Protrusion, Cylinder Liner	14-5
Coolers, Disassemble	7-9	Protrusion, Injector	2-2
Coolers, Repair	7-10	Push Rod Specification	4-4
Dipstick	7-3	Push Rods	4-2
Filter and Adapter	7-6	Install	14-16
Filter and Adapter, Assemble	7-6	Remove	0-6
Filter and Adapter, Inspect	7-6	Radiator Fans	8-5
Filter Assembly	7-5	Raw Sea Water Pump, Assemble	8-8
Filter, Install	14-4, 14-30	Disassemble	8-7
Filters	7-4	Inspect	8-8
Filters, Inspect	7-5	Install	14-32
Hose Size	7-7	Raw Water Pump, Remove	0-2
Hose Specifications	7-7	Rear Accessory Drive, Install	14-23
Lines	7-7	Rear Gear Cover, Inspect	1-18
Lines, Assemble	7-8	Rear Gear Cover, Remove	0-8
Pan	7-3	Rear Gear Housing, Install	14-17
Pan Capacity	7-4	Rear Lifting Eye, Install	14-24
Pan, Inspect	7-3	Rear Oil Seal, Install	14-17
Pan, Install	14-22	Recommendations, Coolant	18-4
Pan, Remove	0-8	Fuel Oil	18-3
Pan, Repair	7-3	Grease	18-2
Performance Specifications	18-1	Oil Viscosity	18-1
Pressure Gauge	15-1	Restriction	18-12
Pump, Assemble	7-2	Restriction Indicator	10-2
Pump, Disassemble	7-1	Ring Gear, Replace	16-1
Pump, Exploded View	7-1	Rocker Lever and Shaft, Exploded View	3-1
Pump, Inspect	7-1	Assemblies, Install	14-16
Pump, Install	14-7	Covers, Clean and Inspect	3-2
Pump, Remove	0-8	Service Tools	3-3
Pump, Repair	7-2	Specifications	3-3
Pump Specifications	7-11	Rocker Levers and Shaft Specifications	18-10
Seal, Install	14-7, 14-17	Assemble	3-2
Temperature Gauge	15-1	Disassemble	3-1
Viscosity Recommendations	18-1	Inspect	3-1
Overspeed Stop	14-38	Remove	0-6
Paint Engine	14-39	Repair	3-1
Pan	7-3	Safety Control	16-1
Capacity	7-4	Sea Water Pump, Assemble	8-8
Inspect	7-3	Disassemble	8-7
Install	14-22	Inspect	8-8
Remove	0-8	Install	14-32
Repair	7-3	Service Tools, Cylinder Block	1-19
Permanent Engine Storage	14-39	Cylinder Head	2-10
Pipe Plug Torque Specifications	18-5	Disassembly	0-12
Piston Assemblies, Remove	0-9	Engine Assembly	14-40
Clean	1-16	Lubricating Oil System	7-10
Inspect	1-16	Rocker Lever	3-3
Install	14-5	Tappet	4-3
Pin Bushings, Replace	1-14	Water Pump	8-9
Ring, Inspect	1-16	Solvent and Acid Cleaning	0-11
Rings, Install	14-5	Spacer Plate, Install	14-7
to Connecting Rod, Assemble	1-17	Spacer Plate, Remove	0-9
Preparing a Stored Engine for Service	14-40	Specifications	18-1
Pressure Gauge	15-1		

Accessory Drive	9-3, 18-11	Timing Specifications	14-13
Cooling System	18-11	Tip Protrusion, Injector	2-2
Cylinder Block	1-20, 18-7	Top Surface Refinishing	1-4
Cylinder Head	2-11, 18-9	Torque Specifications, Capscrew	18-1
Engine Assembly	14-41, 18-13	Torque Specifications, Pipe Plug	18-5
Exhaust System	18-12	Turbocharger	10-3
Fuel Pump Drive	18-11	and Connections, Inspect	14-29
Injection Timing	14-13	and Connections, Remove	0-2
Intake Air System	18-12	Oil Flow, Inspect	14-35
Lubrication Oil Hose	7-7	Vacuum Pump	12-1
Lubricating Oil Pump	7-11	Vacuum Pump, Install	14-22
Lubricating System	18-10	Valve Clearance	14-28
Oil Performance	18-1	Covers, Remove	0-6
Pipe Plug Torque	18-5	Guides, Inspect	2-3
Rocker Lever	3-3	Guides, Replace	2-5
Rocker Levers and Shaft	18-10	Seat, Grind	2-6
Tappet	18-10	Seat Insert, Replace	2-5
Tappet and Push Rod	4-4	Seat, Test	2-9
Water Pump	8-10, 18-11	Set Marks Location	14-26
Spin-On Lubricating Oil Filter	7-6	Springs, Inspect	2-9
Starter	12-1	Valves, Adjust	14-28
Starter, Install	14-32	Clean	2-3
Starting Aids	10-1	Grind	2-8
Starting Procedure, Cold Weather	14-35	Inspect	2-4
Starting Procedure, Normal	14-34	Vehicle Braking	20-1
Steam Clean Engine Exterior	0-2	Vibration Damper	1-12
Steam Cleaning	0-11	Clean	1-12
Storage, Engine, Permanent	14-39	Inspect	1-12
Storage, Engine, Temporary	14-39	Install	14-10
Suppressors, Intake	20-1	Remove	0-4
Tachometer	5-1, 15-1	Viscosity Recommendations, Oil	18-1
Tappet and Push Rod Specifications	4-4	Water Connections, Install	14-24
Assemble	4-1	Connections, Remove	0-3
Assembly, Inspect	4-2	Filter, DCA	8-8, 18-4
Bores, Inspect	1-3	Filter, Install	14-32
Cover Plates, Remove	0-6	Filter, Remove	0-2
Disassemble	4-1	Pump, Assemble	8-2
Exploded View	4-1	Pump, Assemble, Raw Sea	8-8
Inspect	4-1	Pump, Disassemble	8-1
Service Tools	4-3	Pump, Disassemble, Raw Sea	8-7
Specifications	18-10	Pump, Exploded View	8-1
Tappets, Install	14-15	Pump, Inspect	8-1
Tappets, Remove	0-7	Pump, Inspect, Raw Sea	8-8
Temperature Gauge, Oil	15-1	Pump, Install	14-9
Temperature Gauge, Water	15-1	Pump, Install, Raw Sea	14-32
Temporary Engine Storage	14-39	Pump, Remove	0-4
Test Procedure, Engine	14-35	Pump, Remove, Raw Sea	0-2
Testing, Chassis Dynamometer	14-39	Pump Service Tools	8-9
Testing, Engine	14-33	Pump Specifications	8-10, 18-11
Thermostat and Housing, Assemble	8-6	Temperature Gauge	15-1
Disassemble	8-5	Wear Limits	18-1
Inspect	8-5	Wiring Diagrams	13-1
Thermostat Housing, Install	14-23		
Thermostat Housing, Remove	0-3		
Thrust Ring, Inspect	1-12		
Timing, Injection	14-11		