



CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

International Harvester Operator's Manual No. 46 Baler

purchase full manual at

Operator's Manual

JENSALES.COM
or Call 800-443-0625



CLICK ANYWHERE FOR MORE DETAILS

THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
INTERNATIONAL HARVESTER OR IT'S SUCCESSORS. INTERNATIONAL HARVESTER AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

IH-O-46 BLR

TABLE OF CONTENTS

CLICK ANYWHERE FOR MORE DETAILS

INTRODUCTION

Facts about your baler	4
Preparing the crop for baling	6

OPERATION

Preparing your baler for work

Lubrication	7
Hitching	7-9
Threading tying mechanism	10-11
Safety devices	12-15
Safety suggestions	16

Operation of your baler

Direction of travel	17
Operating speed	17
Pickup height	17
Pickup cover	18-19
Packer fingers	19
Bale chamber tension	19
Twine tension	20
Knotter hook tension	20-21
Bale length	21
Bale counter	21

CARE OF YOUR BALER

Lubrication	22-27
Pickup	28
Feeder	29-30
Bale chamber and plunger	30-31
Tying mechanism	32-33
Timing	34-36

FINDING TROUBLE

Finding Trouble	37-43
---------------------------	-------

STORAGE, SPECIAL EQUIPMENT, SPECIFICATIONS

Storage	44
Special equipment	45-47
Specifications	52

CLICK ANYWHERE FOR MORE DETAILS

PREPARING YOUR BALER for work

CLICK ANYWHERE FOR MORE DETAILS



A-29764

GET ACQUAINTED WITH

THE Safety Devices THAT PROTECT YOUR BALER

Your baler is equipped with safety devices to protect it from damage resulting from obstruction or overloads. Acquaint yourself with these devices before operating your baler.

SHEAR BOLTS

NOTE: The shear bolts used in the flywheel, needle, and packer fingers as a safety device are identical. They are 5/16NF x 2" long hex-hd. cap screws (type 2) with nuts and lock washers. Regular bolts (type 1) are too soft and shear too easily. Special bolts (type 3) are too hard and won't shear easily enough to prevent damage to the machine.

When replacing the shear bolt in the flywheel, needle or packer fingers, always duplicate the original bolt by obtaining one from your IH dealer. When replacing shear bolts, see that they are securely tightened and checked regularly for tightness. See Illustr. 12A.



Illustr. 12A — Shear bolts must have this marking to be the correct hardness.

Flywheel Shear Bolt


The purpose of the shear bolt (Illustr. 12B) is to protect the baler against damage from stones or other materials picked up accidentally.

The shear bolt makes a loud noise when it shears. This is your warning to stop the tractor immediately and determine the cause of the shearing. See the "Trouble Finding Chart" for possible causes. When the cause of shearing has been determined and eliminated, replace the shear bolt as follows:

1. Knock out the remaining pieces of sheared bolt, if any, from the shear bolt bushings. The flywheel hub may be rotated to a convenient location by inserting the new shear bolt in the flywheel and turning the flywheel by hand until the bolt engages the side of the hub shear plate.


2. Check the shear bolt bushings to see that they are tight.

Illustr. 12B — The flywheel shear bolt is located in the flywheel at the front of the bale chamber.



Special Equipment

CLICK ANYWHERE FOR MORE DETAILS



Illustr. 50A

SAFETY LIGHTING

When transporting your baler at night, be sure that your baler is equipped with the safety light "A" and "Scotchlite" reflective material "B" as shown in Illustr. 50A and 50B.

Illustr. 50B



HYDRAULIC BALE DENSITY CONTROL

See Illustr. 51A.

The hydraulic bale density control automatically controls the density of the bales being formed in the bale chamber.

This is obtained by the variation of penetration of the floating star wheel under spring tension. When the bales are tight, the star wheel cannot penetrate as deeply as normal; this causes the wheel to raise allowing the hydraulic jack to release fluid until the neutral position is reached. When the bales are loose, the star wheel penetrates deeper, changing the valve setting, and thereby causing the pump to force fluid to the hydraulic jack to bring the density of the bales back to normal. Normal baling variations are controlled by a constant pumping and releasing of fluid at neutral position. To obtain the desired density of the bale, tighten or loosen the spring adjusting nut. To increase the density, turn the spring adjusting nut clockwise; to decrease, turn the nut counterclockwise. **NOTE:** When starting to bale with an empty bale chamber, the spring adjusting nut must be left loose and brought down as tension builds up in the bale chamber.