



CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

International Harvester

Service Manual
V800 Diesel
Engine

purchase full manual at

Service Manual

JENSALES.COM

or Call 800-443-0625



CLICK ANYWHERE FOR MORE DETAILS

THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
INTERNATIONAL HARVESTER OR IT'S SUCCESSORS. INTERNATIONAL HARVESTER AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

IH-S-ENG V800

INTERNATIONAL HARVESTER

MANUAL PREVIEW

JENSALES[®]

SERVICE MANUAL

purchase full manual at

JENSALES.COM

or Call 800-443-0625

V800 ENGINE

CLICK ANYWHERE FOR MORE DETAILS

CLICK ANYWHERE FOR MORE DETAILS

SECTION INDEX

This manual is divided into major sections covering various components of the V-800 Diesel Engine.

These sections are also indexed by title with thumb index tabs as shown below and to the right.

To use this manual, grasp the right-hand side of book between thumb and fingers. Bend book back and find the pages containing the corresponding section index tab.

Section identification is also contained in the upper corner of each page.

SECTION 1 — GENERAL

SECTION 2 — MANIFOLDS, CYLINDER HEADS AND VALVES

SECTION 3 — CONNECTING RODS, PISTONS, RINGS AND SLEEVES

SECTION 4 — CRANKSHAFT, REAR OIL SEAL, CRANKCASE, MAIN BEARINGS AND FLYWHEEL

SECTION 5 — TIMING GEAR TRAIN, FRONT COVER AND CAMSHAFT

SECTION 6 — LUBRICATING OIL PUMP OIL FILTER AND OIL COOLER

SECTION 7 — WATER PUMP, THERMOSTATS, FAN BEARING HOUSING, FAN PULLEY AND IDLER

SECTION 8 — TURBOCHARGER

SECTION 9 — AIR COMPRESSOR AND GOVERNOR

SECTION 10 — INJECTION PUMP AND NOZZLES

SECTION 11 — STORAGE BATTERIES



JENSALES.COM
or Call 800-443-0625

TABLE OF CONTENTS

PAGE I

	Page
INTRODUCTION	V
SAFE WORK RULES	VI
METRIC CONVERSION	VIII
SERVICE INFORMATION SYSTEM (S.I.S.)	X
SECTION 1. GENERAL	1
Par. 1. DESCRIPTION	1
2. SPECIFICATIONS	3
3. SERVICE DIAGNOSIS	13
4. PROBLEM ANALYSIS USING DIAGNOSTIC GUIDELINES	15
5. BATTERY TESTING CHART	20
6. TUNE-UP	22
7. MOUNTING ENGINE ON STAND	23
8. SPECIAL SERVICE TOOLS REQUIRED	24
SECTION 2. MANIFOLDS, CYLINDER HEADS AND VALVES	1
MANIFOLDS	1
Par. 1. DESCRIPTION	1
1A. REMOVAL	1
2. INSPECTION & REPAIR	1
3. INSTALLATION	2
CYLINDER HEADS AND VALVES	2
4. DESCRIPTION	2
5. VALVE LASH ADJUSTMENT	2
5A. VALVE TIMING (CAMSHAFT)	4
6. REMOVAL	4
7. DISASSEMBLY	5
8. INSPECTION AND REPAIR	8
9. VALVE RECONDITIONING	13
10. REASSEMBLY	22
11. INSTALLATION	23
SECTION 3. CONNECTING RODS, PISTONS, RINGS AND SLEEVES	1
CONNECTING RODS, PISTONS AND RINGS	1
Par. 1. DESCRIPTION	1
2. REMOVAL	1
3. DISASSEMBLY	1
4. INSPECTION & REPAIR	2
5. REASSEMBLY	6
6. INSTALLATION	6
7. BEARING FITTING PROCEDURE	7
CYLINDER SLEEVES	9
8. DESCRIPTION	9
9. REMOVAL	9
10. INSPECTION AND REPAIR	10
11. INSTALLATION	11
12. ENGINE RUN-IN SCHEDULE	13
13. PRIMING LUBRICATING SYSTEM	14
14. CRANKCASE COUNTERBORE RESURFACING	14

TABLE OF CONTENTS

SECTION 4. CRANKSHAFT, REAR OIL SEAL, CRANKCASE MAIN BEARINGS AND FLYWHEEL	1
CRANKSHAFT, REAR OIL SEAL, CRANKCASE AND MAIN BEARINGS	1
Par. 1. DESCRIPTION	1
2. REMOVAL	1
3. INSPECTION & REPAIR	3
4. CRANKSHAFT GRINDING	4
5. INSTALLATION	7
6. CRANKSHAFT BEARING CAPS	10
7. CRANKCASE LOWER BORE INSERT	11
FLYWHEEL	12
8. DESCRIPTION	12
9. REMOVAL	12
10. INSPECTION AND REPAIR	12
11. INSTALLATION	16
SECTION 5. TIMING GEAR TRAIN, FRONT COVER AND CAMSHAFT	1
TIMING GEAR TRAIN AND FRONT COVER	1
Par. 1. DESCRIPTION	1
2. REMOVAL	2
3. INSPECTION & REPAIR	4
4. INSTALLATION	5
CAMSHAFT	6
5. DESCRIPTION	6
6. REMOVAL	7
7. INSPECTION AND REPAIR	8
8. BEARING REMOVAL AND INSTALLATION	8
9. INSTALLATION	10
SECTION 6. LUBRICATING OIL PUMP, OIL FILTER AND OIL COOLER	1
LUBRICATING OIL PUMP	1
Par. 1. DESCRIPTION	1
2. REMOVAL	1
3. DISASSEMBLY	1
4. INSPECTION AND REPAIR	3
5. REASSEMBLY	4
6. INSTALLATION	5
OIL FILTER	5
7. DESCRIPTION	5
8. REMOVAL	6
9. DISASSEMBLY	7
10. INSPECTION AND REPAIR	8
11. REASSEMBLY AND INSTALLATION	8
OIL COOLER	8
12. DESCRIPTION	8
13. REMOVAL	8
14. INSTALLATION	10
SECTION 7. WATER PUMP, THERMOSTATS, FAN BEARING HOUSING, FAN PULLEY AND IDLER	1
WATER PUMP	1
Par. 1. DESCRIPTION	1
2. REMOVAL	1
3. DISASSEMBLY	1
4. INSPECTION AND REPAIR	3
5. REASSEMBLY	4

CLICK ANYWHERE FOR MORE DETAILS

	THERMOSTATS	6
Par.	6. DESCRIPTION	6
	7. REMOVAL	6
	8. INSPECTION AND REPAIR	6
	9. REASSEMBLY AND INSTALLATION	6
	FAN PULLEY	7
	10. DESCRIPTION	7
	11. REMOVAL	7
	12. DISASSEMBLY	7
	13. INSPECTION AND REPAIR	7
	14. REASSEMBLY	7
	15. INSTALLATION	9
	WATER PUMP BELT AND FAN BELT IDLER	9
	16. REMOVAL AND DISASSEMBLY IDLER WITH FRONT & REAR ROLLER BEARINGS	9
	17. INSPECTION AND REPAIR IDLER WITH FRONT & REAR ROLLER BEARINGS	9
	18. REASSEMBLY AND INSTALLATION IDLER WITH FRONT & REAR ROLLER BEARINGS	10
	19. REMOVAL AND DISASSEMBLY IDLER WITH FRONT & REAR ROLLER BEARINGS	11
	20. INSPECTION AND REPAIR IDLER WITH FRONT BALL BEARING AND REAR ROLLER BEARING	12
	21. REASSEMBLY AND INSTALLATION IDLER PULLEY WITH FRONT BALL BEARING AND REAR ROLLER BEARING	12
	CLEANING PROCEDURE — ETHYLENE GLYCOL (ANTI-FREEZE) CONTAMINATION	15
SECTION	8. TURBOCHARGER	1
Par.	1. DESCRIPTION	1
	2. GENERAL HANDLING AND MAINTENANCE	1
	3. REMOVAL	2
	4. INSTALLATION	2
SECTION	9. AIR COMPRESSOR AND GOVERNOR	1
Par.	AIR COMPRESSOR	1
	1. DESCRIPTION	1
	2. REMOVAL	2
	3. DISASSEMBLY	4
	4. INSPECTION AND REPAIR	6
	5. REASSEMBLY	8
	6. TESTING REBUILT COMPRESSOR	9
	7. INSTALLATION	10

CLICK ANYWHERE FOR MORE DETAILS


CLICK ANYWHERE FOR MORE DETAILS

GOVERNOR	11
8. DESCRIPTION	11
9. REMOVAL	11
10. DISASSEMBLY	12
11. INSPECTION AND REPAIR	13
12. REASSEMBLY	13
13. INSTALLATION AND ADJUSTMENT	14
14. LEAKAGE TEST	14
SECTION 10. INJECTION PUMP AND NOZZLES	1
INJECTION PUMP	1
Par. 1. DESCRIPTION	1
2. REMOVAL	2
3. INSTALLATION AND TIMING, PUMP-TO-ENGINE	3
INJECTION NOZZLES	6
Par. 4. INJECTION NOZZLE TESTING	6
FUEL RATOR AND DYNAMOMETER HOOK-UP FOR MEASURING FUEL CONSUMPTION	7
5. FUEL TRACTOR (4786 TRACTOR)	7
6. DYNAMOMETER (AW MODEL SHOWN)	9
7. FUEL RATOR	13
SECTION 11. STORAGE BATTERIES	1
Par. 1. GENERAL	1
2. COMMON CAUSES OF BATTERY FAILURE	1
3. BATTERY VISUAL INSPECTION	1
4. SPECIFIC GRAVITY TEST	2
5. FREEZING POINTS OF ELECTROLYTE	2
6. EFFECT OF LOW TEMPERATURE ON BATTERY PERFORMANCE	3
7. BATTERY TEST INDICATIONS AND RECOMMENDATIONS	3

JENSALES.COM
or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

6. Measure the OD of the valve stems (Fig. 18) at various locations along the guide bearing area, and at each location take several readings around the circumference. If the readings are below the minimum permissible stem diameter dimension shown in "SPECIFICATIONS" in Section 1, discard the valve.




IPA-56524

Fig. 18. Checking Valve Stem OD

7. Check valve stem straightness (Fig. 19). If the stem "runout" is more than .025 mm (.001 inch), discard the valve.

8. Set the valve refacing machine to grind the correct valve face angle (Fig. 20). (Refer to "SPECIFICATIONS," in Section 1.) Dress the grinding stone.

9. Insert a valve in the chuck. When it is precisely centered, take a light cut across its face. This is a check to determine whether or not the valve can be reconditioned to service standards with a correct amount of margin maintained. Warpage that may not be apparent in the visual inspection will be clearly definable (Fig. 21).



CE-92373

Fig. 19. Checking Valve Stem Straightness and Face Runout

IPA-23839

Fig. 20. Locating Valve and Grinding Stone to the Specified Angle

CYLINDER SLEEVES

8. DESCRIPTION

The cylinder sleeves are the wet type. The bottom of the sleeve is sealed in the crankcase by three "O" rings (Fig. 16). A flange at the top of each sleeve fits into a counterbore in the top of the crankcase and serves to position the sleeve correctly. Shims may be used between the sleeve flange and crankcase counterbore to provide the correct cylinder sleeve protrusion. The wet type sleeve is water cooled over its entire length. Matched or fitted sleeves and pistons are available for service.



Fig. 17. Removing Piston Cooling Tube (Crankshaft Removed for Clarity)

4. Remove the cylinder sleeves using the universal wet sleeve puller No. PLT-502 (1, Fig. 18).




Fig. 16. Cylinder Sleeve

9. REMOVAL

1. Remove the cylinder heads. (Refer to Section 2, "MANIFOLDS, CYLINDER HEADS AND VALVES.")
2. Remove the connecting rods and pistons. (Refer to Par. 2 in this section.)

NOTE: It is advisable to wrap an oil-soaked cloth around the crankshaft connecting rod bearing journals to keep them as clean as possible. Wrap the piston and connecting rod assemblies in clean cloth also to protect them until installation.

3. Remove the piston cooling tubes and rubber seals (Fig. 17). Keep them in order so they may be installed in the same bore as removed from.




Fig. 18. Universal Wet Sleeve Puller

1. Universal Wet Sleeve Puller



Fig. 6. Removing Water Pump Shaft Seal



Fig. 7. Removing Seal Seat and Bushing



Fig. 8. Removing Bearing from Water Pump Shaft

11. Using a chisel and hammer, remove the wear sleeve (11) from pulley adapter (18).

NOTE: Be careful not to damage the hub surface when performing the chiseling operation.

12. Support the water pump shaft (7) with bearings in a press and remove the front bearing (Fig. 8).

13. Turn water pump shaft end for end in the press and remove rear bearing in the same manner.

4. INSPECTION AND REPAIR

1. Wash all metal parts thoroughly in solvent and dry with compressed air. Check the drain cock and be sure it is clean and operative.

2. Check the pump housing and bearing housing for cracks and be sure any loose scale or rust is removed.

3. Inspect all hoses and water passages. Discard hoses that show any signs of wear or deterioration.

4. Discard all seals and procure new ones for reassembly.

5. Inspect the impeller vanes, remove any nicks, burrs and roughness especially from around the edges.

6. Inspect the front and rear ball bearings. If there is any question as to serviceability, obtain new ones for reassembly. Any signs of roughness, rust or pitting indicate early bearing failure and future problems.

7. Inspect the pump shaft for damage or excessive wear, especially at the bearing surfaces. Hone out any scratches or nicks especially in the area occupied by the impeller.

8. Check the "tell-tale" hole in the pump body for evidence of water or oil leakage. Presence of water indicates a water seal leak; presence of oil indicates the oil seal is leaking. Replace the defective seal.

NOTE: In freezing weather, when draining the radiator and engine block, drain the water pump body also by removing the drain plug. This will protect the impeller blades from freezing in and later being damaged when the engine is started.