



CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

International Harvester

Operator's Manual

3088, 3288, 3488

& Hydro 3688

purchase full manual at

Operator's Manual

JENSALES.COM

or Call 800-443-0625



CLICK ANYWHERE FOR MORE DETAILS

THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
INTERNATIONAL HARVESTER OR IT'S SUCCESSORS. INTERNATIONAL HARVESTER AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

IH-O-3088+

INTERNATIONAL HARVESTER

MANUAL PREVIEW

OPERATOR'S MANUAL

purchase full manual at

JENSALES.COM

or Call 800-443-0625

**3088, 3288,
3488 HYDRO, 3688**

CONTENTS

TO THE OWNER

SERIAL NUMBERS

Inside
Front
Cover

5

WORK SAFELY—FOLLOW THESE RULES

Servicing and Before

6-9

Starting

6

During Operation

7

Transporting

7

Tractors with

7

Control Centers

8

Tractors without ROPS

8

Before Dismounting

8

Dismounting

8

After an Upset

8

Product Graphics

9

INCH-METRIC HARDWARE

10

ENERGY CONSERVATION — FOLLOW THESE RECOMMENDATIONS

11

INSTRUMENTS AND CONTROLS

12-30

Tractors Equipped with

Speedometer-Tachometer

12

Tractors Equipped with

Data Center

13,14

Seat

15

Power Take Off, Hitch,

Hydraulic Valves and

Transmission Controls

— Power Priority Hydraulic

System —

16

Power Take Off, Hitch,

Hydraulic Valves and

Transmission Controls

— Open Center Hydraulic

System —

17

Hydrostatic Transmission

Controls

18

Park Lock Control

18

Cab Interior

19

Engine Oil Pressure Gauge

20

Coolant Temperature Gauge

20

Fuel Gauge

20

Voltmeter

20

Tellites

20,21

Speedometer-Tachometer

21

Blower Control

21

Air Conditioner Control

21

Heater Control

21

Air Recirculation

22

Air Flow Control Louvers

22

Defroster

22

Windshield Wiper Control

22

Dome Light

22

Cigarette Lighter and Ash Tray

22

Refrigerant Pressure

23

Indicator Light

23

Radio

24

Data Center

25

Exhaust Gas Temperature

28

Seat Adjustments

29

BEFORE OPERATING YOUR TRACTOR

31

OPERATING THE TRACTOR

31-40

Neutral Starting Switch

31

Starting the Engine

31

Break-In Procedure

33

With the Engine Running

33

Stopping the Engine

34

Steering the Tractor

34

Driving the Tractor

34

(Gear Drive)

Hydraulic Powered

Clutch Control

34

Selecting Ground Speeds

35,36

(Gear Drive)

Stopping the Tractor

36

(Gear Drive)

Park

37

Driving the Tractor

(Hydrostatic Drive)

37

Foot-n-inch Pedal

(Hydrostatic Drive)

37

Selecting Ground Speeds

(Hydrostatic Drive)

37

Stopping the Tractor

(Hydrostatic Drive)

38

Park

39

Starting Procedure for

Hydrostatic Drive Tractors

After Transporting on

Truck or Flatcar

39

Towing the Tractor

39,40

CONTENTS

ENGINE AND FUEL SYSTEM 41-46

Engine Access Panels	43
Warrenty Notice	44
Fuel System	44
Fuel Injection Pump and Nozzles	46

COOLING SYSTEM 47-50

Coolants and Cooling System Conditioner	47
Checking the Coolant Level	47
Draining the Cooling System	49
Filling the Cooling System	49
Coolant System Filter Conditioner	49
Hoses and Clamps	50
Thermostat	50
Cleaning the Radiator, Transmission Oil Cooler and Condenser Core Fins	50
Water Pump, Alternator-Generator and Fan Belt Tension	50

AIR CLEANING SYSTEM 51-54

Aspirated Air Cleaner	51
Automated Dust Unloader	51
General Precautions	51
Removing and Cleaning the Primary Element	52
Inspection	53
Removing the Secondary Element	53

ELECTRICAL SYSTEM 55-60

Fuses	55
Instrument Light Dimmer Switch	56
Turn Signal Indicators	56
Charging System for Alternator-Generator	56
Cranking System	57
Lighting System	57
Lights	57
Combination Turn Signals and Warning Lights	57
Tellites	58
Batteries	58
Electrical Connector	60
Implement Auxiliary Wire	60

HYDRAULIC CONTROLS FOR THREE-POINT HITCH — OPEN CENTER HYDRAULIC SYSTEM 61-63

Position Control	61
Position Control Lock Lever	61
Adjustable Stop	62
Draft Control	62
Run Range	63

HYDRAULIC CCONTROLS FOR THREE-POINT HITCH — POWER PRIORITY HYDRAULIC SYSTEM 64-67

Position Control	64
Position Control Lock Lever	64
Adjustable Stop	65
Draft Control	65
Run Range	66
Raise Rate Control	66
Hitch Drop Rate Adjustment	67

THREE-POINT HITCH 68-78

Lift Links and Turnbuckles	68
Hitch Upper Link	69
-TELESCOPING LOWER LINKS-	69
Lateral Limiter	70
Lateral Limiter Adjustment Procedure	70
Coupling the Equipment	72
Uncoupling the Equipment	73
-CLAW LOWER LINKS-	74
Lateral Limiter	75
Lateral Limiter Adjustment Procedure	75
Coupling the Equipment	76
Uncoupling the Equipment	78

OPERATING THE THREE-POINT HITCH WITH DRAFT CONTROL 79

HITCHING TRAILING EQUIPMENT TO THE TRACTOR 80-84

Safety Chain	80
Swinging Drawbar for Tractors with Three-Point Hitch	81
Swinging Drawbar for Tractors without Three-Point Hitch	84

CONTENTS

AUXILIARY VALVES, REMOTE CYLINDERS AND HYDRAULIC OUTLETS OPEN CENTER HYDRAULIC SYSTEM-

85-88

Connecting Hoses to the Rear Hydraulic Outlets	86
Check Valves	87
Operating Double-Acting Cylinders	87
Operating Single-Acting Cylinders	87
Neutral Lock	87
Float Lockout	87
Adding Fluid After Connecting Cylinders and Hoses	88
Freeing the System of Trapped Air	88
Sequential Raise	88
Simultaneous Raise	88

AUXILIARY VALVES, REMOTE CYLINDERS AND HYDRAULIC OUTLETS— POWER PRIORITY HYDRAULIC SYSTEM-

89-93

Flow Control Lever	89
Color Code	89
Motor Valve	90
Hydraulic Motor Using the Motor Valve	90
Connecting Hoses to the Rear Hydraulic Outlets	91
Check Valves	92
Operating Double-Acting Cylinders	92
Operating Single-Acting Cylinders	92
Neutral Lock	92
Float Lockout	93
Adding Fluid After Connecting Cylinders and Hoses	93
Freeing the System of Trapped Air	93
Simultaneous Raise	93

POWER TAKE-OFF

95

Operating the Independent Power Take-Off	95
---	----

DIFFERENTIAL LOCK

95

ALL-WHEEL DRIVE

96

FRONT WHEELS

96-100

Adjustable Wide Tread	96
Front Axle	96
Farmall Hi-Clear, Adjustable	96
Front Axle	96
Adjusting the Toe-In	98
All-Wheel Drive	99
Adjusting the Toe-In	100

REAR WHEELS

101-

Adjusting the Tread Widths	101
Assembling the Rear Wheel with Double Beaded Rims	101
Reversing the Rear Wheels	101
Wheels with Double Beaded Rims	102
Tractors with Wedge Wheels	103
Tractors with Hub Clamp Wheels	107
Dual Rear Wheels	107

TIRES

110-

Inflation	110
Front Tire Inflation Pressures	111
Rear Tires Inflation Pressures	112

WEIGHTS

113 -

Front End Weights	115
Front End Weight Hold Down and Locking Device	113
All-Wheel Drive Tractors	114
Rear Wheel Weights	114
Weight Table	115

COLD WEATHER PRECAUTIONS

115

Fuel System	115
Electrical System	115
Lubrication	115
Cooling System	115

STORING THE TRACTOR

116

Storage	116
Removing From Storage	116

CONTENTS

LUBRICATION

Engine Oil	117-
Gear Lubricant	120
Lubrication Fitting Grease	117
Engine Oil Filter	117
Hydraulic Fluid Filters	118
Lubricating the Front Wheels	118
	120

LUBRICATION TABLE

121,
122

LUBRICATION GUIDE

123
130

PREVENTIVE MAINTENANCE GUIDE

131-
134

CONTROL CENTER EQUIPMENT PREVENTIVE MAINTENANCE

135-
139

Outside Air Filter	135
Recirculation Air Filter	135
Air Conditioner Condenser	135
Air Conditioner System Pressures	136
Evaporator Drain Valves	136
Adjusting the Compressor	136

Belt Tension-3088 and 3288 Tractors with Reciprocating Piston Compressors-	136
--	-----

Adjusting the Compressor Belt Tension-3088 and 3288 Tractors with Rotary Vane Compressors-	137
--	-----

Adjusting the Compressor Belt Tension-3488 Hydro & 3688	
---	--

Tractors with Reciprocating Piston or Rotary Vane Compressors	137
---	-----

Compressor Pulley and Clutch -Reciprocating Piston Compressors-	138
---	-----

Compressor Pulley and Clutch -Rotary Vane Compressors-	138
--	-----

Compressor Shaft Seal	138
-----------------------	-----

Compressor Oil Level	139
----------------------	-----

Heater Coolant Shut-Off	139
-------------------------	-----

Electrical	139
------------	-----

Floodlights	139
-------------	-----

Miscellaneous	139
---------------	-----

SPECIFICATIONS	140-
	149

OPTIONAL EQUIPMENT	150
--------------------	-----

JENSALES.COM

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

INSTRUMENTS AND CONTROLS

Air Recirculation



The air circulation control regulates the amount of fresh and recirculated air entering the control center.



For maximum fresh air, loosen the control knob and push it to the forward end of the slot, and tighten.



For maximum recirculation, loosen the control knob and push it to the rear end of the slot and tighten. Intermediate positioning of the control knob in the slot is available to the operator for delivery of fresh and recirculated air.

For maximum efficiency, clean the recirculation air filter at the recommended intervals. Refer to "Control Center Equipment Preventive Maintenance".

Air Flow Control Louvers

The majority of the conditioned control center air is discharged through three air control louvers found in the front headliner. These are adjustable up or down, to the left or right, and are closeable to allow the operator to control air flow direction as desired.

Defroster

Six non-adjustable, continuous defrost air discharge ports are found along the forward edge of the front headliner. The amount of defrost air flow over the windshield may be varied by the adjustment of the air flow control louvers and blower fan speed.

Windshield Wiper Control



The windshield wiper is controlled by a two speed switch. Turn the control knob clockwise to increase wiper speed. The wiper has an automatic park position for the blade at the left side of the windshield when the switch is turned to the off position. The wiper motor is protected from over load by a 6 amp circuit breaker, which is part of the switch.

DOME LIGHT



- 1 - Dome light
- 2 - "Door" position
- 3 - "Manual" position
- 4 - "Off" position


The dome light is located at the center of the rear headliner and is connected directly to the battery. It is controlled by a 3-position switch, which is a part of the dome light, and by door actuated switches located on each side of the control center. The dome light switch must be placed in the forward "DOOR" position when leaving the control center if light control by the door switches is desired.

NOTE: Do not leave the dome light switch in the center "MANUAL" position when leaving the tractor. By leaving the switch in the "MANUAL" position the light will continue to burn and run down the batteries.

Cigarette Lighter and Ash Tray

The cigarette lighter and ash tray are located to the left of the operator's seat near the side window.

COOLING SYSTEM



CAUTION! Pressure cooling system — REMOVE CAP SLOWLY.

MA-16869




- 1 - Top hood panel
- 2 - Panel support rod
- 3 - Radiator cap
- 4 - Air filter assembly
- 5 - Ether canister



CAUTION! Remove the radiator cap only when the coolant temperature is below the boiling point. The temperature gauge pointer should be between or below the two white lines in the green section.

Turn the radiator cap slowly counterclockwise to the pressure release point to allow the pressure or any steam to escape; then press down on the cap and continue to turn until the cap is free to be removed.

NOTE: Never pour coolant into the radiator if the engine is very hot. You may cause damage to the engine or steam may eject from the radiator.



MA-19314

- 1 - Radiator cap
- 2 - Filler cap gasket
- 3 - Top of radiator core
- 4 - Coolant level
- 5 - Upper tank
- 6 - 2-1/4-inches (57 mm)
- 7 - Overflow pipe
- 8 - Wire to warning light
- 9 - Coolant probe

COOLANT LEVEL IN THE RADIATOR

If the radiator cap is faulty, replace it with a new one of the same type and rating. Do not attempt to repair the cap.

FRONT WHEELS

ADJUSTING THE TOE-IN



Front view showing points of adjustment

The front wheels should have 1/4-inch (6.4 mm) ($\pm$ 1/16-inch) (1.5 mm) toe-in.

To check toe-in, the tractor should be on level ground with the front wheels in the straight ahead position.

Put a chalk mark on each rim at "G" and measure the distance between the marks. Move the tractor forward a distance equal to one-half revolution of the front tires. The chalk marks will now be at point "F". Measure the distance between "F". This measurement should be 1/4-inch (6.4 mm) ($\pm$ 1/16-inch) (1.5 mm) less than "G".

To adjust the toe-in, remove the cotter pins and tie rod end stud nuts "A". Loosen the tie rod end nuts "B". Remove the ends from the steering knuckles "C". Turn the tie rod ends in or out to obtain the proper adjustment. The tie rod ends should be adjusted by equal amounts, so that the steering gear arm will remain centered and not limit right or left turns.

Reinstall the tie rod ends into the steering knuckles. Tighten the tie rod end nuts. Tighten the tie rod end stud nuts and insert new cotter pins.