



CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

Owatonna Operator's Manual

320

Skid Steer

Operator's Manual

JENSALES.COM

or Call 800-443-0625



CLICK ANYWHERE FOR MORE DETAILS

THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
OWATONNA OR IT'S SUCCESSORS. OWATONNA AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

OW-O-320SS



mustang

CLICK ANYWHERE FOR MORE DETAILS

320

MANUAL PREVIEW



LOADER

Operator's Manual

purchase full manual at



JENSALES.COM

or Call **800-443-0625**

CLICK ANYWHERE FOR MORE DETAILS

Owatonna Manufacturing Company, Inc., Owatonna, Minnesota 55060

OW-O-320SS




TABLE OF CONTENTS

Delivery Report & 50 Hour Check	4
Safety Recommendations	13
Decal Locations	15
Specifications	16
General Information	19
Control Locations	20
Operating Instructions	21
Engine	24
Brakes	25
Driving	25
Loader Operation	26
Lift Arm Stops	27
Fast-Attach Hitch	28
Operating Tips	29
MAINTENANCE INSTRUCTIONS	31
Schedule of Periodic Maintenance	31
Engine — General Information	32
Air Cleaner	33
Fuels	35
Lubrication	35
Ignition System	36
Breaker Points — Timing	36
Spark Plugs	36
Coil	36
Battery Inspection	37
Fuel System	37
Carburetor	39
Fuel Pump	40
Crankcase Breather	41
Governor	42
Throttle & Choke Adjustment	43
Engine Removal	44
Cleaning Cylinder Heads	45
Battery Charging System	47
Starting System	52
BASIC MACHINE	53
Electrical Schematic	54
Loader Grease Points	55
Hydraulic Fitting Installation	56
Torque Values for Bolts and Cap Screws	56
Hydrostatic Drive	56
Belt Failure	56
Belt Alignment	57
Belt Tension Adjustment	57
Neutral Centering Adjustment	58
Hydrostatic Drive Failure	59
Replacing Hydrostatic Pump	59
Replacing Hydrostatic Motor	60
Chain Cases	60
Adjusting Chain Tension	61
Axle Seal or Bearing Replacement	62
Brakes	62
Checking Pads, Discs, & Linkage	62
Replacing Pads	62
Adjusting Brake Linkage	62

TABLE OF CONTENTS

CLICK ANYWHERE FOR MORE DETAILS

Hydraulic Fluid Filter – 10 microns	63
Hydraulic Fluid Reservoir	63
View Gauge	63
Pressure Cap	63
Strainer	64
Adjusting Hydraulic Control Linkage	64
Adjusting Hydraulic Gear Pump Drive Belt	64
TROUBLESHOOTING	65
Engine	65
Electrical System	67
Hydrostatic Drive	68
Loader Hydraulics	69
STORAGE & REMOVAL FROM STORAGE	70

MANUAL PREVIEW

JENSALES®


purchase full manual at

JENSALES.COM
or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

Owatonna® the  skid  steer  specialists

SPECIFICATIONS



A.	Overall Height-lift arms raised	125" (3175 mm)
B.	Height to Hinge Pin (Maximum)	98" (2489.2 mm)
C.	Overall Height	54" (1372 mm)
D.	Overall Length-with bucket	102" (2591 mm)
E.	Dump Angle	38°
F.	Dump Height	73" (1854.2 mm)
G.	Reach at Maximum Height	18" (457.2 mm)
H.	Specified Height	51 1/2" (1308.1 mm)
I.	Reach at Specified Height (H)	27" (685.8 mm)
I. 1	Reach-bucket on ground	26" (660.4 mm)
J.	Maximum Rollback at Ground	28°
K.	Carry Position	7" (177.8 mm)
L.	Maximum Rollback at Carry Position	29°
M.	Maximum Rollback Fully Raised	86°
N.	Digging Depth	9/16" (14.3 mm)
O.	Height to Seat	33 1/2" (851 mm)
P.	Wheel Base	30 3/4" (781 mm)
Q.	Overall Height-with operator guard	74" (1880 mm)
R.	Overall Length-less bucket	80" (2032 mm)
S.	Ground Clearance	6 3/4" (171.45 mm)
T.	Maximum Grading Angle-bucket	108°
U.	Angle of Departure	23°
V.	Bucket Width	47" (1194 mm)
W.	Clearance Circle Front-less bucket	35" (889 mm)
X.	Clearance Circle Front-with bucket	61" (1549.4 mm)
Y.	Clearance Circle Rear	47" (1194 mm)
Z.	Overall Width-less bucket	45 1/2" (1156 mm)
AA.	Tread 5.70-12 Tires	37" (940 mm)

OPERATING INSTRUCTIONS

SEAT BELTS

The seat belts are located on either side of the operator's seat. Keep them in good working order and use them. They may keep you from being injured.

! WARNING: Never start the engine unless you are in the operator's seat with your seat belt fastened.

ENGINE CONTROLS

1. **THROTTLE** – Move the hand throttle control forward to increase engine speed. Push the throttle control back to slow down.
2. **IGNITION SWITCH** – The ignition switch has three positions: Off, On, and Start. Turn the key clockwise to the spring loaded start position to start the engine. Release the key as soon as the engine starts. The key will then be in the On position. Turn the key to the Off position to stop the engine.
3. **CHOKE CONTROL** – Move the choke control forward to choke the engine. This provides a richer fuel mixture for starting the engine.



or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

DIAPHRAGM FUEL PUMP

Some engines use a diaphragm-type fuel pump. If fuel does not reach the carburetor, check the fuel pump before dismantling it.

1. Disconnect the fuel line at the carburetor.
2. Crank the engine and observe whether fuel comes from the line at the carburetor.

WARNING


Be sure to direct the fuel flow into a container so gasoline does not spill on ignition wires.

3. If there is enough fuel in the tank, and line does not have fuel flowing, the pump needs replacing.


Pump failure is usually caused by a leaking diaphragm, valve, or a weak or broken spring. Gasoline diluted oil may also indicate a faulty pump.

Pulsating diaphragm fuel pumps use a combination of crankcase and spring pressure to work a diaphragm thus pumping fuel.

On the downstroke of the engine piston, when the crankcase pressure is greatest, the pump diaphragm is forced back against the diaphragm spring compressing it and drawing fuel into the pump intake chamber. The fuel then passes through the intake reed valve into the output chamber side of the pump. On the compression stroke, when crankcase pressure is the lowest, the diaphragm spring forces the diaphragm out pushing fuel through the pump output reed valve into the output chamber and into the fuel line.



Pump mounts on engine enclosure.



PULSATING DIAPHRAGM FUEL PUMP (EXPLODED VIEW)

WHEEL DRIVE

CHAIN CASES

There is a chain case on either side of the frame under the floor panel which houses the final drive chains. These chain cases contain sufficient hydraulic fluid to lubricate the chains and bearings. This fluid should be maintained at the level of the upper check plug on the outside of the frame. Use the lower plug when it is necessary to drain the fluid from the chain case. Fluid may be added by removing the chain case breather on the top front of the chain case.

The final drive chains are special #60 roller chain. Use only OMC replacement parts for these chains. These chains should be checked and retightened as necessary at the 50 hour service and every 200 hours after that. To adjust chains, use the following procedure:

1. Block the machine securely and safely.
2. Remove wheels.
3. Drain chain case fluid into suitable container. Fluid is to be kept clean if it is to be re-used.
4. Remove side inspection covers.
5. Check tension of drive chains. Chains should have a total deflection of $1/4$ to $1/2$ inch, measured at the center of the span. Rotate the drive to check for high spots on the sprockets and check at the highest (tightest) point.
6. To adjust, loosen nut holding idler sprocket and move idler up or down as required.
7. Retighten idler nut securely. Repeat for all chains.
8. Replace inspection covers and drain plug.
9. Remove upper level check plug and chain case breather. Add fluid through breather port until fluid flows out check port.
10. Reinstall check plug. Clean breather by washing in solvent and blowing out with compressed air. Reinstall in breather port.
11. Reinstall wheels.
12. Remove blocks.

