



CLICK ANYWHERE FOR MORE DETAILS

Bobcat

Parts Manual

943

Parts Manual

JENSALES.COM
or Call 800-443-0625



CLICK ANYWHERE FOR MORE DETAILS

THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
BOBCAT OR IT'S SUCCESSORS. **BOBCAT** AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.



bobcat

943

MANUAL PREVIEW

PARTS MANUAL



PUBLICATION #	6570035 (5-89)
REPLACES #	6570035 (10-88)

943 ALPHABETICAL INDEX

AIR CLEANER G4, G6, I1
ALARM, BACKUP I7
ALTERNATOR F13, F16, F20, I22
AXLE B23
BALANCER I3
BATTERY F6, F10
BELT, ALTERNATOR G12
BELT, DRIVE G10
BLOCK HEATER I9
BOB-TACH B4, B6
BOB-TACH CONVERSION KIT ... I10
BOOT, RUBBER A12
BRAKES B22
CAB A16
CAB ENCLOSURE I16, I20
CABLE, BATTERY F6, F10
CAMSHAFT G22
CAP, FUEL B8, B12
CAP, HYD. OIL D2, D8
CAP, RADIATOR G4, G8
CHAIN, DRIVE B16
CHAINCASE B16
CRANKSHAFT H10
CYLINDER BLOCK H6
CYLINDER, LIFT C11, C13
CYLINDER, TILT C14
DECALS J2, J4
DIPSTICK, ENG. OIL H16
DOOR, CAB I14
DOOR, REAR B2
ENGINE G18
FAN, F10 G4, G6
FAN, MOTOR E18, E20, E22
FILTER, HYD. OIL D10
FILTER, AIR I1
FILTER, ENG. OIL H6
FILTER, FUEL H22
FILTER, HYD. OIL E23, E24
FIRE EXTINGUISHER J5
FLYWHEEL G10
FUEL SYSTEM B8
FUSE F2, F4
GAS SPRING A16
GASKET KIT ENG. G18
GAUGE, ENG. TEMP. F2, F4
GAUGE, FUEL F2, F4
GEARBOX B18
GREASE J24
HARNESS, CAB F2, F4
HARNESS, CHASSIS F6, F10
HARNESS, ENGINE F6, F10
HEAD, CYLINDER H2
HEATER, CAB J8, J9
HOURLY METER F2, F4
LEVER, STEERING D16
LIFT ARMS B4

LIGHTS F2, F4
LIGHTS, FLASHER J6
MAIN FRAME A12
MANIFOLD G20
MOTOR, HYDRO. D20
MOUNT, ENGINE G10
MOUNT, HYDRO. PUMP D2, D8
MUFFLER G4, G6, J13
OIL J24
OIL COOLER D4, D12
PAINT J24
PEDALS, CONTROL C19
PISTON H11
PORT BLOCK E17
PUMP, FUEL H20
PUMP, GEAR E15, E16
PUMP, HYDRO. E2, E8, E13
PUMP, INJECTION H24
PUMP, OIL I4
PUMP, WATER H17
QUICK COUPLERS C10
RADIATOR G3, G6
RENTAL KIT J16
RIM, WHEEL J19
RING GEAR G10
SEALANT J24
SEAT A21, A24
SEAT BAR A20
SEAT BELT A20
SENDER, ENG. TEMP. F6, F10
SENDER, FUEL B8, B12
SHORT BLOCK G18
SOLENOID F6, F10
SOLENOID, STARTER FLUID .. G4, G8
STARTER F21, F24
STOP, LIFT ARM J11
STROBE LIGHT J17, J18
SWITCH, ENG. OIL PRESS. ... F8, F12
SWITCH, HYDRO. PRESS. F6, F10
SWITCH, HYDRO. TEMP. F6, F10
SWITCH, IGNITION F2, F4
SWITCH, LIGHT F2, F4
TANK, COOLANT G4, G6
TANK, FUEL B8, B12
TANK, HYD. D2, D8
THERMOSTAT H19
THROTTLE G16
TIRES J18
VALVE COVER G23
VALVE, BUCKET POS. .. C20, C21, C23
VALVE, ENG. H2
VOLTMETER F2, F4
WINDOW, REAR A16
WINDOW, SIDE I21
WINDSHIELD WIPER I12

MAIN FRAME & ATTACHING PARTS	A11–B14
MAIN FRAME & ATTACHING PARTS	A11–A14
OPERATOR CAB	A15–A18
SEAT & SEAT BAR	A19–A20
SEAT	A21, A22
SUSPENSION SEAT	A23–A24
REAR DOOR	B2
LIFT ARMS & BOB–TACH	B3–B4
BOB–TACH	B5–B6
FUEL SYSTEM	B7–B14
DRIVE TRAIN	B15–B23
DRIVE TRAIN	B15–B16
GEARBOX	B17–B20
DISC BRAKE	B21–B22
AXLE	B23
HYDRAULIC CIRCUITRY	C1–C24
HYDRAULIC CIRCUITRY	C1–C10
LIFT CYLINDERS	C11–C13
TILT CYLINDERS	C14–C16
CONTROL VALVE	C17–C18
CONTROL PEDALS	C19
BUCKET POSITION VALVE	C20–C24
HYDROSTATIC CIRCUITRY	D1–E24
HYDROSTATIC CIRCUITRY	D1–D14
HAND CONTROLS	D15–D18
HYDROSTATIC MOTOR	D19–D20
HYDROSTATIC PUMP	E1–E14
GEAR PUMP	E15–E16
PORT BLOCK	E17
COOLING FAN MOTOR	E18–E22
HYDROSTATIC OIL FILTER	E23, E24
ELECTRICAL SYSTEM	F1–G2
CAB ELECTRICAL	F1–F4
ENGINE ELECTRICAL	F5–F12
ALTERNATOR	F13–F20
STARTER	F21–G2
POWER UNIT	G3–I1
ENGINE & ATTACHING PARTS	G3–G14
THROTTLE	G15–G16
PERKINS DIESEL ENGINE	G17–G18
MANIFOLDS	G20
TIMING GEARS	G21–G22
ROCKER ARM COVER	G23
ROCKER SHAFT	G24
CYLINDER HEAD	H1–H4
CYLINDER BLOCK	H5–H8
CRANKSHAFT & ASSOCIATED PARTS	H9–H10
CONNECTING ROD & PISTON	H11
BALANCER	H13–H14
LUBRICATION SYSTEM	H15–H16

POWER UNIT (CONT'D)	G3-I1
WATER PUMP	H17-H18
WATER OULET BODY	H19
FUEL PUMP	H20
FUEL FILTER	H21-H22
FUEL INJECTOR SYSTEM	H23-H24
AIR CLEANER	I1
ACCESSORIES & OPTIONS	I5-J22
AUXILIARY HYDRAULIC CIRCUITRY	I5-I6
BACK-UP ALARM KIT	I7, I8
BLOCK HEATER	I9
BOB-TACH CONVERSION KIT	I10
CAB DOOR	I11-I14
CAB ENCLOSURE	I15-I20
CAB WINDOWS	I21
CLOSED ALTERNATOR	I22-I23
COOLING KIT	I24
DECALS	J1-J4
FIRE EXTINGUISHER	J5
FLASHER LIGHTS	J6
HEATER	J7-J8
HEATER KIT	J9
INSECT SCREEN KIT	J10
LIFT ARM STOP	J11
LIFT EYE KIT	J12
MUFFLER/PURIFIER KIT	J13
EXHAUST PURIFIER KIT	J14-J15
RENTAL KIT	J16
STROBE LIGHT	J17, J18
TIRES & RIMS	J19-J21
WATER LEVEL SENSOR KIT	J22
BULK ITEMS	J23-J24
NUMERICAL INDEX	K1

JENSALES.COM
or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

HYDROSTATIC PUMP (Cont'd)
(Sunstrand)




NOTE: Ref. 1 is shown in a right rear view.
Ref. 2-61 are components of the left half of the
tandem pump shown in a left front view.

E-1816

HYDROSTATIC PUMP (Cont'd)

Ref. No.	Part Number	Description	Remarks	Serial Number	Qty.
59	6634427	SLEEVE	M91-46100		1
	NAP	SLEEVE	only for M91-46106R – Was 6640617 [A]		1
	6657315	SLEEVE	M91-46385, M91-46446		1
60	NSS	PLUG	Order Ref. 19		1
61	6631642	STUD			1
62	6634478	ORIFICE	.036" (0,914mm) – for M91-46100 & M91-46371		1
	6640619	ORIFICE	.036" (0,914mm) – for M91-46106		1
	6657320	ORIFICE	.156" (3,96mm) – For M91-46385 & M91-46446		1
63	6518510	PLUG	W/Ref. 25		1
64	6653728	NUT	locking		1
65	6659256	RING	Was 6653740 [A]		2
66	6666220	BOLT	.4375 (11,1) – Was 6656077 [A]		6
67	6660080	RETAINER			1
68	6661040	SERVO KIT	Ref. 22, 29, 38, 39, 45, 46, 57, 58 & 65 – Was 6720759 [A]		1
69	6660079	GUIDE			1
70	6661037	SEAL KIT	W/Ref. 4, 22, 25, 29, 38, 39, 43, 46, 47, 57, 58 & 65 on Page E8– NO TAG Ref. 4, 22, 25, 29, 38, 39, 44, 47, 54, 55, 58, 62, 63, 75, 77 & 81 – Was 6579425 [A]		1



STROBE LIGHT KIT
(Amber - 3414ALW)

Ref. No.	Part Number	Description	Remarks	Serial Number	Qty.
1	6587526	KIT	strobe light - Ref. 2 - 10		1
2	6665021	LENS	amber		1
	6665025	LENS	blue - Not in Kit		1
3	NSS	RETAINER			1
4	NSS	SCREW			3
5	NSS	SCREW			1
6	6665022	FLASH TUBE			1
7	NSS	POWER SUPPLY			1
8	NSS	BASE			1
9	6665023	GASKET			1
10	6720856	INSTRUCTIONS			1
11	6665024	BRANCH GUARD			1

NUMERICAL INDEX

Part No.	Description	Was	Code	Page
103522	NUT			B23, J19
208028	WASHER			B18, B20
223879	SNAP RING			B18
228744	CAP			D16, F8
234132	BEARING			H14
329884	FAN			F14
552433	VALVE			D2, D8
552914	SPACER			H18
562912	ADAPTER			C2
614142	SLEEVE			J6
619021	WASHER			B6
654299	BEARING			D20, E2, E8
658128	SNAP RING			D20, E2, E8
661415	SNAP RING			E14
661416	SNAP RING			E13
666842	ELBOW			J9
666867	ADAPTER			J9
668312	PIN			E10, E14
669053	BEARING			E14
669863	SNAP RING			D20, E2, E8
710779	SNAP RING			G10
710822	SNAP RING			E13
711215	CLAMP			G4, G6, J14
730963	ADAPTER			C2, D4, D12
731795	ADAPTER			C4, C10
742510	DOWEL PIN			G12
742666	SNAP RING			B22
763632	SNAP RING			C18
763906	BEARING			A18
784466	PIN			B22
791355	PIN			E2, E8
794584	WASHER			F14
850315	RETAINER			F14
859369	NUT			F14
859377	SCREW			F21
860669	BUSHING			F22
863995	WASHER			F22
866104	PLUG			G8
871610	BAND			G4, G6
874935	BUSHING			F22
878103	GASKET			F22
878608	COLLAR			F22
880603	HOLDER	6511626	A	F22
884576	STUD			F22
886527	WASHER			I1
887834	POLE SHOE			F22
889163	BEARING			I23
889269	HOSE			J9
889707	SPACER			C18
895771	BULB			F2, F4
896126	LEVER			F21

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
896539	BEARING			E14
896978	WASHER			I22
896979	NUT			I22
896984	BOLT			I23
896990	WASHER			I23
896992	RETAINER			I23
896996	WASHER			I23
897239	SLEEVE			I23
897245	INSULATOR			I23
897467	BOLT			F13
897719	INSULATOR			I23
897732	WASHER			I23
898127	COLLAR			F22
898131	GROMMET			F21
898731	BULB			F6, F10
899157	FAN			I22
899163	ROTOR			I23
899165	INSULATOR			I23
899167	SINK			I23
899169	INSULATOR			I23
899170	GASKET			I23
899373	SEAL			I23
899375	DIODE			I23
899376	WASHER			I23
899377	BOLT			I23
899378	DIODE			I23
905350	BEARING			F14
905351	BEARING			F13
905952	TERMINAL PKG			F14
905956	FRAME			F13
905957	HOUSING			F14
906028	MANIFOLD			G20
906910	SPRING			F21
907237	SPACER			G12
907238	BUSHING			G12
907768	THIMBLE	3490718	A	H13
907828	BUSHING			F22
907934	RING			G18, H2
907953	STATOR	908106	D	F14
908091	PIPE			H22
908221	ALTERNATOR			F13
909477	SOLENOID			F6, F10, H24
909558	DOWEL PIN			H14
909559	COVER			H14
909561	GEAR			H14
909566	HUB			H14
909567	GASKET			H14
909569	COVER			H14
909578	GASKET	909570	A	H14
909605	SPACER			G18, H24
909643	PULLEY			H10

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
909675	COVER			G22
909694	BUSHING			H13
909695	PLUG			H14
909697	WASHER			H14
909698	BEARING			H14
909699	BEARING			H14
909703	PLUG			H8
909831	COLLAR	905958	A	F14
941388	SNAP RING			G10
942142	RING			F22
942792	CLAMP			G4, G6
947088	RING			C11, C12, C13, C15, C16
947717	PLUNGER			C20
947737	SPRING			C20
948775	SPRING			C17
962170	PLUG			C18
991374	GASKET			F22
994378	BOLT			F14
994381	REGULATOR			F13
994383	DIODE			F14
994911	PIPE			G23
996653	VALVE			H2
996654	VALVE			H2
996655	VALVE			H2
997692	COVER			H6
998953	PISTON			H11
998954	PISTON			H11
999308	CAPICATOR			F14
999394	HOLDER			F13
999395	TERMINAL	6599774	A	F14
999396	BOLT			F13
999397	BOLT			F14
999472	PIN			F21
999672	BRACKET			G12
1300309	ELBOW			D4, D12
1303141	WASHER			B6
1304294	ADAPTER			D14
1305481	DOWEL			H6
1306637	PIN			C19, D16
1312337	ELBOW			D4, D12
1313116	BUSHING			G10
1319364	HOSE			D6
1319439	ROLL PIN			E14
1319451	FUSE			F2, F4
1550482	SPRING			C22
1550695	HANDLE			I20
1614765	STEM			J19
1715312	STA-STRAP			J16
1781096	NUT			H22, H24
1908806	EXTINGUISHER			J5
1990599	SEAL			G10

Code for disposition of old part number
A — Use up
B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales
D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
1991038	BEARING			I23
1992274	PLUG			C18
2356058	BOOT			F10
2512577	NUT			F8
2518020	CAP			C4
2518021	PLUG			C4
2756257	RETAINER			I12
3291290	NUT			I1
3455218	BOLT			G12
3480303	THERMOSTAT			H19
3490066	NUT			H16
3490094	BOLT			H24
3490095	WASHER			H24
3490103	SPACER			G23
3490132	FERRULE			H22, H24
3490133	NUT			H22, H24
3490179	HUB			G22
3490181	BUSHING			G22
3490186	STUD			H19
3490200	CONNECTOR			H22
3490221	WASHER			G22
3490223	WASHER	3725506	A	G22, H2, H19
3490238	WASHER			G22
3490323	SLEEVE			H24
3490324	SEAL			H24
3490325	WIRE			H24
3490351	WASHER			H22
3490352	BOLT			H22
3490713	PLUG			H2, H19
3490714	PLUG			G24
3551883	FILTER			H22
* 3575054	BOLT	3575055	B	D, H4
3575054	BOLT			H4
3575057	VALVE			H2
3575083	GASKET			H18
3679199	KIT			H10, H11
3724414	RETAINER			H11
3725302	THIMBLE			H6
3725304	LINER			H6
3725313	PLUG			H6
3725314	WASHER			H6
3725315	PLUG			H6
3725326	PLATE			H6
3725329	NUT			G6, H6
3725341	GASKET			H6
3725343	WASHER			H6
3725357	GASKET			H2
3725361	VALVE			H2
3725378	MANIFOLD			G20
3725380	STUD			G6, G20
3725388	GEAR			H10

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

Model 943

Loader Parts

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
3725392	SCREW			H10
3725393	WASHER			H10
3725394	KIT			H9
3725400	WASHER			H9
3725402	WASHER			H9
3725407	BUSHING			H11
3725424	CAP			G22
3725429	WASHER			G23
3725440	RETAINER			G24
3725441	SPRING			G24
3725442	SPRING			G24
3725449	SCREW			G24
3725450	LOCKNUT			G24
3725453	WASHER			G24
3725455	PUSHROD			G24
3725478	GEAR			G22
3725480	WASHER			G22
3725481	WASHER			G22
3725482	WASHER			G22
3725483	WASHER			G22
3725484	DOWEL			G22
3725486	GEAR			G22
3725516	WASHER			H16
3725656	CLAMP			H22
3725665	STUD			H24
3725673	PIPE			H24
3725674	PIPE			H24
3725675	PIPE			H24
3725677	DAMPER			H24
3725678	PLATE			H24
3725682	WASHER			G18, H24
3725700	WASHER			G23, H6, H16, H24
3725702	STUD			G12
3725703	WASHER			G12, H22
3726064	PLUG			H2, H6
3727285	WASHER			H22
3727374	NUT			H22
3727375	FERRULE			G18, G24, H22
3727381	NUT			G12
3727656	GASKET	6633126	A	H16
3727656	GASKET	6662042	A	H16
3734657	WASHER			H14
3737000	TRACK			A21
3737001	TRACK			A21
3737010	CUSHION			A21
3737081	CUSHION			A21
3737800	DOWEL			G22
3737844	SEAL			H6
3737942	WASHER			H8
3737945	BRACKET			H16
3737958	BRACKET			G24

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

Model 943

Loader Parts

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
3737963	CAP			H2
3737966	GEAR			G22
3738154	SEAL			G22
3739007	WASHER			H24
3739017	ADAPTER			H24
3739121	PLUG			H6
3739127	PIN			G22
3739136	TUBE			H22
3739137	TUBE			H22
3739148	WASHER			H2
3739149	COTTER			H2
3739167	ADAPTER			H24
3739216	KIT			H10, H11
3739248	REPAIR KIT			H20
3748597	BOLT			H24
3885315	ELEMENT			A1, H22
3984949	NUT			C18
4790721	WASHER			H6
5200262	BEARING			E14
5201528	POPPET			C17
5201530	SEAL			C17
5201532	SPRING			C18
5205733	UNION			H24
5208601	RACE			E14
5208954	BALL			C18
5208955	BALL			C18
5290199	SEAT			C18
5290308	COLLAR			E14
5290309	BUTTON			E14
5290318	GASKET			E14
5290323	SPRING			E14
5293737	SPRING			E14
6501755	ROD			D16
6501756	SLIDE			D16
6502203	CLAMP			C2, C8
6504426	GASKET			B10
6505076	SPRING			B22
6505237	GASKET			G4, G8, J14
6506477	WASHER			B22
6510070	GASKET			E14
6510254	CAP			C18
6510255	PLATE			C17
6510256	SEAT			C17
6510257	SPOOL END			C18
6510284	PLATE			H20
6510500	HOUSING			E14
6510585	WASHER			E16
6510586	WASHER			E13
6510590	RACE			E14
6510642	BUSHING			G22
6510643	VALVE			H2

Code for disposition of old part number
A — Use up
B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales
D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6511139	ATOMIZER			G4, G6
6511209	FILLER			G22
6511372	PLUG			C20
6511393	FILTER			B10, B14
6511627	SUPPORT PKG			F21
6511629	ARMATURE			F22
6511766	ELEMENT			A1, G4, G8, H6
6511767	HEAD			G4, G6, H6
6511768	WASHER			H6
6511855	SEAL			A12, G6, I12, I18, I20
6511957	BOLT	6611957	D	F13
6511983	GROMMET			D4, D12, I24
6512027	BUSHING			D16
6512136	SEAL			E13
6512274	CLIP			G16, I12, I16
6512808	LIGHT SWITCH			F2, F4
6512809	KEY			F2, F4
6512872	DRIVE			F22
6512909	NUT			G4, G6, J11
6512927	CAP			B16
6513096	SCREW			H6
6513098	BOLT			H6
6513099	HOUSING			G22
6513102	COVER			G23
6513120	SPACER			G12
6513152	SEAL			G8, I21
6513468	BULB			F2
6513469	HOLDER			F2, F4
6513679	DRAINCOCK			H6
6513709	CAP & PLUG			I6
6513963	GRIP			D16
6514642	CAP			F2, F4
6514643	GASKET			F2, F4
6514693	PLUG			H14
6514742	RIVET			F2
6514850	CLIP			I12
6514897	MOUNT			G12
6514963	PLUG			G20
6515131	BLADE			J6
6515167	PLUG			I6
6515472	SWITCH			F8
6515575	CLAMP			B12, G3
6515576	CLAMP			J13
6515598	PLUG			C6, C10
6515599	CAP			C6, C10
6515600	HANDLE			I12, I16, I20
6515603	GROMMET			F6, F10
6515678	PLUG			H6
6515679	SCREW			H11
6515682	PLUG			H22
6515687	INSET			H4

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6515689	PLATE			H2
6515695	KIT			H9
6515696	KIT			H9
6515697	KIT			H9
6515698	KIT			H10, H11
6515699	KIT			H10, H11
6515701	ROD			H11
6515707	PLUG			G20
6515771	RING GEAR			G10
6515817	WASHER			A12, A16
6516191	BAND	871610	A	I1
* 6517516	LIGHT	6557903	A	J6
6518510	PLUG			E6, E10
6518596	FITTING			B8
6518656	VALVE			E10
6518657	VALVE			E10
6519480	CLIP			G16, I12, I16
6519504	PLUG	3679284	A	H6
6519506	NUT			G8, G20
6519507	SEAL			G18, H2
6519737	BEARING			E14
6519740	COVER			E14
6529419	HEAD	6592771	A	C11
6531336	HOSE	6577244	A	D12
6531599	FAN			G4
6531627	TUBE			J14
6531649	HEAD			C15
6531651	MOUNT			G16
6531653	DECAL	6568912	A	J2
6531738	DECAL	6568529	A	J4
6531739	DECAL	6568530	A	J4
6531997	BOLT			E18
6532127	BOOT	NAP		A12
6532677	WASHER			B20
6532806	CLAMP			I6
6532807	TUBE			I6
6532808	TUBE			I6
6532809	TUBE			I6
6532810	BRACKET			I6
6532811	HOSE			I6
6532812	HOSE			I6
6533897	DECAL			J4
6534512	PLUMBING KIT			I6
6537287	PLATE			G8
6538000	HOSE	6568837	A	D2, D8
6538001	HOSE	6568839	A	D2, D8
6538002	HOSE	6571895	A	D2, D8
6538141	SEAL			C16
6538141	SEAL	6638141	D	C15
6538285	SNAP RING	1305943	A	B4, D6, D12
6538367	HEAD			C16

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6538381	PLATE			B16
6538847	ELBOW	6538003	A	D6, D14
6539341	BUSHING			C15, C16
6539341	BUSHING	6576755	A	C14
6539849	HOSE			D2
6539849	HOSE	5290012	B	D8
6550222	SPRING			A24
6552906	BRACKET			J16
6553411	BUSHING			B8, B12, G4, G6
6553412	ELBOW			B12, G4, G6
6553709	WASHER			A16
6553808	BOLT			I12, I16, I20
6554149	SAFETY CORD			A18
6554149	SAFETY CORD	6554223	A	I16, I20
6554222	EXTRUSION			I20
6555054	PLATE			I20
6555059	BRACKET			I20
6555331	WIRE ROPE			I16, I20
6555350	ADHESIVE			A18
6555351	SEAL			A18, I21
6556222	INSTRUCTIONS			J6
6556500	MANUAL			J4
6557224	DECAL			J4
6557291	BALL JOINT			G16
6557432	BOLT			B10
6557486	LAMP			F2, F4, F6, F10
6557493	GROMMET			F2, F4
6557565	DECAL			J2
6557640	SWITCH			I7
6557747	PUCK			B22
6557904	FLASHER			J6
6557929	WASHER			G10
6558076	KIT			J6
6558142	HOUSING			F2, F4
6558234	WASHER			B18
6558242	BRACKET			F2
6558309	WIRE ROPE	6558305	A	J4
6558310	SLEEVE			J4
6558465	WASHER			D8
6558680	WASHER			D16
6558826	MOUNT			F6
6559070	DECAL			J4
6559071	DECAL			J4
6559218	ANGLE			B22
6559237	DISC			B22
6559444	BLOCK			G4, G6
6559447	WASHER			D2, D8
6559479	NUT			A20, D16
6559515	EXIT TAG			A18, I16, I20
6560160	TUBE			B8, B12, H22
6560172	BOOT			F8, F12, J16

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6560334	BUSHING			B4
6560573	DECAL			J4
6560575	DIPSTICK			D2, D8
6560633	MOUNT			A12, A16
6561383	DECAL			J2
6561733	MOUNT			F10
6561811	PLUG			E17
* 6562018	SPRING	6578253	A	B6
6562224	BUSHING			A14
6562225	HINGE			B2
6562480	BLOCK			G10
6562602	MOUNT			A16
6562755	PIN			B22
6562756	WASHER			B22
6562757	BLOCK			B22
6563025	CABLE			F6, F10
6563148	BLOCK			A20
6563178	PIVOT			B22
6563313	RETAINER			A20
6563328	BLACK GOLD			A1, J24
6563330	BLACK GOLD			A1, J24
6563410	DECAL			I12, I18
6563423	DECAL			J11
6563431	PLATE			F4
6563462	CLAMP			F6
6563505	CONDUIT			F8, F12
6563557	WASHER			A20
6563681	HANDLE			B2
6563740	LIGHT			F6, F10
6563823	LEVER			B22
6564069	DOOR			I20
6564340	PIN			B2
6564343	BUSHING			G16
6564389	BUSHING			B22
6564452	GRIP			G16
6564656	PEDAL			C19
6564657	PIN			C19
6564785	LENS			F2
6564829	WINDOW			I18, I20
6564830	WINDOW			I18, I20
6564831	HINGE	6554831	D	I20
6564832	HINGE			I20
6564833	SAFETY TREAD			I12, I16, I20
6564907	SOCKET ASSY			F6, F10
6565013	BOOT			A12
6565289	CAP			B20
6565355	GUIDE			A20
6565373	INSULATION			A16
6565620	POPPET			E17
6565627	NUT			B2
6565628	NUT			B2

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6565629	SCREW			B2
6565738	RIM			J19
6565742	SPROCKET			B16, B23
6565825	CAP			B18
6565826	COVER			B18
6565828	COLLAR			B18
6565829	COLLAR			B18
6565830	CAP			B18
6565831	SNAP RING			B18
6565832	SHAFT			B18
6565834	GEAR			B18
6565838	SHIM			B18
6565839	SNAP RING			B18
6565840	HUB			B18
6565844	SNAP RING			B18
6565853	WEDGE			B6
6565854	SPACER			B6
6565855	LEVER			B6
6565856	LEVER			B6
6565858	PIVOT			B6
6565859	STUD			B6
6565862	BUSHING			A14, B4
6565864	PIN			B4
* 6565871	BOB-TACH			B6
6565909	BUSHING			B4
6565944	AXLE			B23
6565947	CAP			B23
6565951	STEP			B4
6565973	RIM			J19
6565975	SHIM			B23
6565990	DECAL			J4
6566844	INSTRUCTIONS			J16
6566957	INSTRUCTIONS			I21
6567007	MUFFLER			G4
6567008	PIPE			G4, G6
6567020	SPRING			E17
6567024	PULLEY			D2, D8, G10
6567119	LINK			B16
6567129	STOP			D16
6567130	LOCK			A20
6567137	MOUNT			D16, D18
6567138	CONNECTOR			C19
6567139	MOUNT			D16
6567145	STOP			D16
6567146	SHAFT			D16
6567147	MOUNT			C19
6567170	TANK			G4, G6
6567171	O-RING			B16
6567173	HUB			B23
6567174	COVER			B16, B22
6567175	COVER			B16, B22

Code for disposition of old part number
A — Use up
B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales
D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6567177	PEDAL			B22
6567178	MOUNT			B22
6567179	ROD			B22
6567181	INSULATION			B22
6567202	HOSE			G4, G6
6567203	HOSE			G4, G6
6567206	HOSE			D4
6567207	HOSE			D4
6567210	TANK			B8
6567211	TANK			B8
6567213	FLYWHEEL			G10
6567266	BELT			G10
6567271	BRACKET			B8, B12
6567273	HOSE			B8
6567274	ADAPTER			B8
6567283	STRIP			B8, B12
6567287	HOSE			G4, G6
6567326	TUBE			C2
6567343	BLOCK			D4, E17
6567345	BAND			D2, D8
6567346	TANK			D2
6567348	ANGLE			A12
6567359	TUBE			D4
6567366	HOSE			D4
6567403	MOUNT			D2, D8
6567405	MOUNT			G10
6567407	LEVER			G16
6567408	MOUNT			G16
6567416	GROMMET			D6
6567418	BRACKET			G3, G6
6567425	PIPE			G4
6567437	MAIN FRAME			A12
6567442	BUSHING			A14
6567459	BOOM STOP			A12
6567486	SEAL			A12
6567487	WASHER			A12
6567497	TUBE			C4, C10
6567498	TUBE			C4, C10
6567499	TUBE			C4
6567501	TUBE			C4
6567502	TUBE			C4
6567504	TUBE			C4
6567537	DIODE			F8, F12
6567544	PANEL			F2
6567550	ROD			G16
6567571	INSULATION			A16
6567572	INSULATION			A16
6567596	MOUNT			F6, F10, I7
6567651	SAFETY TREAD			J2
6567652	SAFETY TREAD			J2
6567653	SAFETY TREAD			J2

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6567667	STOP			J11
6567709	CLEVIS			C19
6567709	CLEVIS	6568316	A	D16
6567710	NUT			C19
6567736	SEAL			G4, G6
6567795	KIT			J4
6567805	ANGLE			G3
6567805	ANGLE	6568705	B, D	G6
6567876	TEE			D2
6567911	LEVER			G16
6567912	LEVER			G16
6567929	TANK			B12
6567931	CABLE			F6
6567932	CABLE			F6
6567933	CABLE			F6
6567934	CABLE			F8
6567956	MODULE			J16
6567959	WIRE			J16
6567962	WASHER			G16
6567963	SPACER			G16
6567965	HOSE			G4, G8
6567968	WIRE			J16
6567971	WIRE			J16
6567972	WIRE			J16
6567974	MOUNT			G4
6567979	WIRE			J16
6567990	KIT			I24, J16
6568047	NUT			I12, I16
6568051	HINGE			I12
6568055	BRACKET			I12, I16
6568057	FLANGE			A12
6568100	NUT			B4
6568166	BUSHING			B6
6568178	SUPPORT			G4, G6
6568259	TUBE			B8, B12
6568260	HOSE			B8, B12
6568262	STRIP			B8, B12
6568264	BRACKET			B8
6568316	CLEVIS	6567709	A	C19
6568318	CLAMP			A12
6568320	BRACKET			A16
6568324	TUBE			D2, D8
6568325	TUBE			D2, D8
6568328	TUBE			D4, D12
6568329	TUBE			D4, D12
6568336	TUBE			C2, C8
6568337	TUBE			C2
6568338	TUBE			C2
6568360	HOSE			D4, D14
6568415	MOUNT			G10
6568424	ADAPTER			G10

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

Model 943

Loader Parts

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6568425	ADAPTER			G10
6568435	MOUNT			D2
6568475	STOP			A16
6568476	CLAMP			C2, C4, C8, C10, G16
6568496	BUSHING			B6
6568498	WASHER			B6
6568526	SPACER			I12, I16
6568527	BRACKET			I12, I16
6568528	BRACKET			I12, I16
6568540	MOUNT			A16
6568547	LIFT EYE			J12
6568548	LIFT EYE			J12
6568644	GASKET			B2
6568645	FLANGE			B2
6568656	BRACKET			B8
6568704	SEAL			I12, I16
6568705	WINDOW			I14
6568707	BATTERY			A1
6568724	SHIELD			I12, I16
6568725	SPRING			I12, I16
6568726	HANDLE			I16
6568726	HANDLE	6569726	D	I12
6568727	ROD			I12, I16
6568728	SHIELD			I12, I16
6568729	KIT			J12
6568731	SNAP RING			B18
6568739	HARNESS			I12
6568742	BUSHING			A20
6568766	BRACKET			A12
6568770	DECAL			J12
6568790	INSULATION			A12
6568791	INSULATION			A12
6568792	INSULATION			A12
6568794	INSULATION			A12
6568797	SHIELD			G12
6568798	SPACER			G12
6568817	SPRING			D16
6568823	STOP			B6
6568824	SHIM			B6
6568826	BOLT			G10
6568828	ROD			G10
6568830	PIN			G10
6568834	BUSHING			D16
6568857	HARNESS			F6
6568858	HARNESS			F6
6568863	HARNESS			F2
6568933	CHAIN			B16
6568934	CHAIN			B16
6568938	TUBE			C4, C10
6568939	TUBE			C4, C10
6568940	TUBE			C2, C8

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6568941	TUBE			C2, C8
6568942	TUBE			C4, C10
6568943	TUBE			C4, C10
6568944	TUBE			C2, C8
6568945	TUBE			C2, C8
6568946	TUBE			C2
6568947	TUBE			C2, C8
6568948	TUBE			C2, C8
6568949	TUBE			C2, C8
6568971	DECAL			J4
6568973	SHIELD			I12, I16, I20
6568978	KIT			I21
6568980	KIT			J11
6568995	ADAPTER			C2, C4, C8, C10
6569014	HOSE			C2, C8
* 6569033	WINDOW			I16
6569054	WASHER			G12
6569062	MOUNT			G10
6569063	MOUNT			G12
6569064	COVER			B16
6569069	HOSE			D4
6569070	HOSE			D4
6569090	RETAINER			B16
6569091	PIN			G10
6569095	MOUNT			J5
6569112	KIT			J5
6569128	RIM			J19
6569138	ADAPTER			C2, C8
6569144	SPRING			E17
6569145	PLUG			E17
6569148	HUB			G4
6569160	TIRE			J19
6569203	CLAMP	6563462	A	F10
6569219	SCREEN			D8
6569219	SCREEN	6569212	D	D2
6569263	PLUG			A12
6569271	ADAPTER			D4
6569278	PLUG			D16
6569306	GUIDE			B6
6569309	TUBE			C2
6569310	TUBE			C2, C8
6569311	TUBE			C2
6569312	ORIFICE			C4, C10
6569328	SHIELD			A12
6569389	KIT			J2, J4
6569432	HARNESS			I7
6569433	HARNESS			I7, I8
6569436	HARNESS			F10
6569479	PIN			B4
6569480	PIN			B4
6569498	SPRING ASSY			G10

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6569520	BRACKET			A12
6569576	MOUNT			D18
6569600	WASHER			G12
6569623	BOLT			F6, F10
6569629	LEVER			B6
6569630	LEVER			B6
6569632	TUBE			J19
6569667	MOUNT			G12
6569670	MOUNT			D2, D8
6569674	MOUNT			C19, D16
6569675	ROD			G16
6569752	HOSE			B10, B14
6569754	WASHER			B20
6569802	MOUNT			D2, D8
6569802	MOUNT	6568435	A	G10
6569809	BELT			G10
6569837	GEARBOX	6565821	A	B16
6569873	ANGLE			G16
6569948	SEAL			A16
6569949	SEAL			A16
6569953	SPACER			D16
6569982	MUFFLER			G6
6570040	INSTRUCTIONS			J5
6570068	INSTRUCTIONS			J12
6570161	INSTRUCTIONS			I7
6570223	INSTRUCTIONS			J10
6570238	INSTRUCTIONS			J22
6570254	INSTRUCTIONS			J13
6570264	INSTRUCTIONS			I14
6570279	INSTRUCTIONS			I18
6570369	INSTRUCTIONS			J9
6570572	INSTRUCTIONS			I24
6570712	INSTRUCTIONS			J14
6571529	KNOB			A18
6571532	BRACKET			A18
6571533	MOUNT			A18
6571554	WASHER	6632208	A	F16
6571590	MOUNT			F6, F10
6571628	INSULATION			J13
6571669	STOP			D16
6571670	INSULATION			A12
6571671	INSULATION			A12
6571692	LEVER			I7
6571693	CLIP			I7
6571694	STRAP			I7
6571695	MAGNET			B16
6571700	KIT			J22
6571715	HINGE			I12, I16
6571722	BLOCK			D2
6571815	TANK			B8
6571816	TANK			B8

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6571855	KIT			I12
6571885	VALVE			D4, D12
6571907	HARNESS			F6
6571967	BRACKET			B10
6571968	STRAP	6571965	D	B10
6571975	STOP			B10
6571976	STOP			B10
6572009	PIVOT			B6
6572050	BOLT			B6
6572051	BUSHING			B6
6572053	PANEL			F4
6572056	LENS			F4
6572058	HARNESS			F4
6572065	BULB			F4
6572094	SALES			I16
6572136	PANEL			F4
6572161	CABLE			F6, F10
6575587	INSULATION			A12
6575588	INSULATION			A12
6575589	INSULATION			A12
6575594	INSULATION			A12
6575653	MOUNT			D16
6575920	PIVOT ASSY			B4
6575922	BUSHING			A14
6575966	PIVOT ASSY			B4
6576017	BLOCK	6567045	A	C2, C4, C8, C10
* 6576033	WASHER	6558465	A	B4, B16, D2, E10
6576048	DECAL	6557927	A	J2
6576059	TEE			D8, D12
6576167	LEVER			D16
6576167	LEVER	6567141	A	D16
6576188	CABLE			F10
6576189	CABLE			F10
6576235	KIT			J9
6576238	CLIP			I18
6576274	LENS	6568517	A	B2
6576284	COVER			A12
6576440	PULLEY	6571536	A	F16
6576440	PULLEY	6659373	A	F20
6576500	MAIN FRAME			A12
6576512	FLYWHEEL			G10
6576513	BOLT			A16
6576712	POPPET	6569029	A	E17
6576975	HOUSING			G8
6577002	BRACKET			D8
6577041	BRACKET			A16
6577051	BRACKET			B14
6577052	TANK			D8
6577063	TUBE ASSY			B12
6577064	HOSE			B12
6577108	TUBE			C8

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6577109	TUBE			C8
6577110	TUBE			D12
6577111	TUBE			C8
6577112	TUBE			C8
6577113	TUBE			C8
6577114	TUBE			C8
6577115	TUBE			C10
6577116	TUBE			C10
6577117	TUBE			C10
6577118	TUBE			C10
6577121	TUBE			C10
6577122	TUBE			C10
6577137	LOUVER			G8
6577140	LOUVER			G8
6577195	TUBE			B14
6577196	HARNESS			F10
6577233	BUSHING			G6
6577245	HOSE			D12
6577246	HOSE			D12
6577268	BLOCK			D12, E17
6577322	FAN			G6
6577392	TEE			D14, I24
6577456	KIT			F18
6577461	COVER			A12
6577495	KIT			I24
6577498	ANGLE			I24
6577499	BRACKET			I24
6577500	MOUNT			I24
6577512	COVER			I24
6577526	BRACKET			D18
6577529	BRACKET	6569976	A	D16
6577532	TUBE			D8
6577539	BRACKET			D18
6577545	GROMMET			D14
6577552	BRACKET	6563173	A	B22
6577578	TUBE			C10
6577579	TUBE			C10
6577580	HOSE			D14
6577605	BOLT	6577185	A	G8
6577754	DECAL	6568741	A	J2
6577785	CAP	6560209	A	D2, D8
6577821	HOSE	672221	A	B10, B12
6577822	HOSE	6562515	A	B8, B12, G3, G6
6578780	CROSSMEMBER	6572066	A	F4
6579389	DECAL			J4
6579406	DECAL			J4
6579448	KIT LATCH			B2
6579510	DECAL	6575854	A	I12, J2
6579511	DECAL	6565980	A	J4
6579528	DECAL	6565254	A	J2
6579990	BUSHING	6558429	A	C19

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6584584	SPRING			D16
6584872	WASHER			B4
6584978	CONDUIT			J16
6586455	TUBE			D10
6586568	HEAD			C12, C13
6586592	MOUNT			I8
6586780	KIT			I8
6586782	HARNES			I8
6586819	HOSE	6571721	A	D2, D8
6587014	DECAL	6531732	A	J4
6587035	PULLEY	6567112	C	G10
6587452	COVER	6567176	A	B16
6587458	KEY			B10, B14
6587526	KIT			J18
6587528	PLATE			A14
6587754	BRACKET			B14
6587765	BUSHING			G12
6587766	BOLT	9G-640	A	D16
6587781	ELBOW			D10
6587826	WASHER			G12
6587975	HOSE	1325172	A	D2, D8
6587977	HOSE	6531337	A	D12
6587979	HOSE	6568842	A	D4, D12
6587980	HOSE	6568844	A	D4, D12
6587981	HOSE	6567045	A	C2
6587981	HOSE	6569013	A	C8
6587982	HOSE	6569338	A	C2, C4, C8, C10
6587983	HOSE	6571789	A	D4
6587984	HOSE	6568927	A	D4, D12
6588893	ELBOW			D14
6588894	HOSE			D14
6588898	MOUNT			D10, G14
6588899	SPACER			G14
6588900	SHIM			G14
6588901	MOUNT	6589233	D	G10
6588905	PLATE			D10
6588912	HEAD	6531649	A	C14
6588946	TEE			D12
6588947	HOSE			D12
6588948	TUBE			D10
6588972	ROD			C16
6588973	CASE			C16
6588974	CYLINDER			C16
6588978	PISTON			C16
6588980	BRACKET	6588990	B, D	B14
6589139	BRACKET			G14
6589189	SPINDLE			G14
6589190	SPINDLE			G14
6589728	MOUNT	6569513	A	A12
6589735	LEVER			D18
6589886	SHIM			B18

Code for disposition of old part number
A — Use up
B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales
D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6589887	SHIM			B20
6589888	SHIM			B20
6589889	SHIM			B20
6591804	CLAMP			I6
6592304	STUD			B23
6592573	PISTON			C11, C12
6592772	ROD			C11, C12, C13
6592776	SPACER			C11, C12, C13
6592777	TUBE			C11, C12
6593052	ROD			C14
6593052	ROD	6586899	A	C15
6593384	CYLINDER			B4, C2, C8
6593388	DECAL			J2
6593476	PISTON			C14, C15
6595149	MOUNT	6537080	A	G6
6595352	TANK	6567928	A	B12
6595512	CYLINDER			C13
6595633	GEARBOX	6565822	A	B18
6595957	TUBE			C13
6595958	CASE			C11, C12, C13
6596221	GEAR			B18
6596222	GEAR			B18
6596496	SHIM	6589890	A	B20
6596889	PIN	6587801	A	G12
6597238	BUSHING	6553411	A	D8
6597294	SHAFT	6569753	A	B18
6597608	PIN	6596589	A	G12
6598031	BOLT			H14
6598058	SHIM KIT			E10
6598475	LATCH			I20
6598721	NUT			F2, F4
6598757	QUICK COUPLER			I6
6598758	QUICK COUPLER			I6
6598903	ELEMENT			A1, D12, E23
6598908	ELBOW			B8
6598908	ELBOW	6598909	D	B12
6599360	SEALANT			J24
6599361	PIN			B2
6599364	SWITCH			E23
6599365	KIT			E23, E24
6599449	SOLENOID			F21
6599462	VALVE			J9
6599643	BEARING	6631953	A	D16
6599645	PLUG			B14
6599646	NUT			H11
6599652	BOOT			F10
6599696	SOCKET			F2, F4
6599719	GREASE			J24
6599741	WASHER			D16
6599744	BALL JOINT			D18
6599767	RECITIFIER			F14

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6599768	BOLT			F14
6599771	ROTOR	908015	A	F14
* 6599779	ADJUSTER	6650227	A	A24
6599780	TRACK			A21
6599781	KNOB			F2, F4
6599931	ALARM	6579858	A	I7, I8
65G-608	BOLT			F4
65G-810	SCREW			F22
6610510	STA-STRAP			B10, I8
6610510	STA-STRAP	6591255	A	B14, J9
6610585	WASHER			E15
6615575	CLAMP			G6
6620642	MOTOR			I14
6624289	STA-STRAP			I6
* 6628799	SPACER			I10
6630065	VALVE			C2, C20
6630093	COUPLER			D4, D12
6630098	ALTERNATOR	NAP	D	I22
6630115	SPRING			C20
6630119	PLUG			C20
6630120	PLUG			C20
6630121	SPRING			C20
6630130	SEAL KIT			C20
6630138	SEAL			B2
6630142	SEAL			B23
6630151	SLEEVE			B23
6630156	CAP			A1
6630164	PULLEY			I22
6630168	COUPLER			D6, D14
6630171	ENGINE			G4, G6, G18
6630180	STARTER			F6, F10, F21
6630188	POLISH			J24
6630189	POLISH			J24
6630190	POLISH			J24
6630191	POLISH			J24
6630207	RIVET	6512797	A	A12, A20
6630207	RIVET	6598092	A	B14, G8
6630212	MOTOR			D4, E18, G4
6630233	AIR CLEANER			G4, G6, I1
6630241	BUSHING			G10
6630248	SENDER			B8, B12
6630333	VALVE			C20
6630340	HOUSING			I22
6630341	STATOR			I23
6630342	HOUSING			I23
6630343	RETAINER			I23
6630344	BRUSH ASSY			I23
6630345	GASKET			I23
6630346	COVER			I23
6630348	CAPICATOR			I23
6630350	DIODE			I23

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6630357	BODY			E16
6630358	GEAR			E16
6630366	INDICATOR			G4, G6
6630367	CAP			D6, D14
6630403	BRUSHES			F22
6630405	DOWEL PIN			F22
6630406	SPRING			F22
6630407	COIL			F21
6630408	FRAME			F21
6630411	PLATE			F22
6630413	HOUSING			F22
6630423	GASKET KIT			G18
6630465	CUSHION			A21
6630468	CUSHION			A21
6630469	TRACK			A21
6630481	TUBE			H22
6630585	CLIP			F6, F10, I7
6630586	CLIP			F6, F10
6630588	SOLENOID			F6, F10, G4, G8
6630643	DOWEL PIN			E18
6630794	ADAPTER			B12
6630797	GAS SPRING			A12, I12, I16
6630821	SWITCH			J16
6630832	PIPE			H24
6630842	HOUSING			E18
6630844	GEAR			E18
6630845	GEAR			E18
6630846	KEY			E18
6630847	PLATE			E18
6630848	SEAL KIT			E18
6630918	TRACK			I21
6630919	TRACK			I21
6630924	BRACKET			I21
6630925	WINDOW			A16
6630926	HINGE			A16
6630939	ELEMENT			A1, I1
6630940	ELEMENT			A1, I1
6630941	COVER			I1
6630943	BLADE			I12
6630945	WASHER			G16
6630972	GASKET			B8, B12
6630974	ADAPTER			B8
6630977	ELEMENT			A1, D4
6630977	ELEMENT	6661248	D	D12, E24
6631008	ARM			I12
6631009	SWITCH			I12, I16
6631010	SWITCH	6646596	A	F12
6631012	CABLE			D16
6631013	CABLE			C19
6631015	ROTATING			D20
6631016	THRUST PLATE			D20

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6631017	HOUSING			D20
6631018	CAP			D20
6631019	PLATE			D20
6631020	GASKET			D20
6631022	BEARING			D20, E2, E8
6631025	PLATE			E15, E16
6631026	PLATE			E15, E16
6631027	BODY			E15
6631028	GEAR			E15
6631029	GEAR			E15
6631030	PUMP			E15
6631031	SHAFT			D20
6631036	BALL JOINT			D16
6631047	SWITCH			E17, F6, F10
* 6631067	SEAL			I10
6631067	SEAL			B4, B6, C13, C14, C15, C16
6631417	PUMP			E13
6631418	PIN			A16
6631419	VALVE			C2, C4, C8, C10, C19, D4, D12, D16
6631425	SHAFT			E4
6631428	SLEEVE			E2, E8
6631430	SPRING			E4, E10
6631435	GASKET			E10
6631438	COUPLER			E10
6631444	GUIDE			E4, E10
6631445	GUIDE			E4, E10
6631446	STOP			E4, E10
6631449	SPRING			E4, E12
6631450	RING			E10
6631453	BRACKET			E4, E12
6631458	NUT			E4, E12
6631463	PLUG			E10
6631465	PLUG			E10
6631467	RING			E4, E10
6631468	O-RING			E4, E10
6631469	RING			E4, E10
6631470	SCREW			E4, E10
6631471	WASHER			E4, E12
6631476	OIL COOLER			D4, D12
6631478	ROTATING			E2, E8
6631483	CONTROL			E14
6631484	COMPENSATOR			E14
6631485	ROTATING			E14
6631486	YOKE			E14
6631487	SHAFT			E14
6631488	PLATE	6631448	D	E14
6631490	PUMP			E13
6631494	CLAMP			B8, B10
6631498	INSERT			H2
6631500	HEAD	6634200	A	H2
6631501	SHIM			G24

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

Model 943

Loader Parts

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6631504	OIL PUMP			H14
6631505	PLUNGER			H13
6631506	SPRING			H13
6631507	CAP			H13
6631508	PIN			H13
6631509	PUMP			H24
6631510	INJECTOR			H24
6631511	NOZZLE			H24
6631512	SEAL			G18, H24
6631513	COVER			H2
6631514	BODY			H19
6631515	WATER PUMP			H18
6631516	KIT			H18
6631517	PULLEY			H18
6631518	HOUSING			H19
6631519	PULLEY			F14
6631520	BELT			G12
6631521	STRAP			G12
6631522	PLATE			H2
6631524	BOLT			C18
6631525	BOLT			C18
6631526	SECTION			C17
6631528	SECTION			C17
6631529	SECTION			C17
6631530	SECTION			C17
6631532	SECTION			C17
6631533	CAP			C18
6631534	SPACER			C18
6631535	SPRING			C18
6631536	END			C18
6631537	SPOOL END			C18
6631538	SEAT			C18
6631539	SLEEVE			C18
6631540	SPRING			C18
6631541	SPOOL END			C18
6631542	SEAT			C18
6631543	SPRING			C18
6631544	ROLL PIN			C18
6631545	CAP			C18
6631546	SPOOL END			C18
6631547	SLEEVE			C18
6631548	LOOP			I21
6631549	HOOK			I21
6631553	CAMSHAFT			G22
6631555	PIN			E14
6631556	FOLLOWER			E14
6631557	CAP			E14
6631560	CAP			E14
6631561	NUT			C22, C24, E14
6631563	PLUG			E14
6631567	SEAL KIT			E14

Code for disposition of old part number
A — Use up
B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales
D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6631568	KIT			E14
6631598	SEAL KIT			E15, E16
6631624	CLAMP			F6, F10
6631625	DECAL			A18
6631626	CLAMP			F6, F10
6631638	BATTERY			F6
6631640	LINK			B16
6631642	STUD			E6
6631643	PLATE			E2
6631649	GUAGE			F2, F4
6631665	KNOB			A16
6631674	PIPE			H14
6631706	FILTER ASSY			E23
6631925	LINK			B16
6631926	LINK			B16
6631927	GEAR			I14
6631935	HANDLE			I14, I18
6631961	VALVE			C17
6631962	RELIEF VALVE			C18
6631969	FILTER			E24
6632000	SCREW			E16
6632004	SCREW			E15
6632045	SEAL			A18
6632047	SNAP RING			D6, D14
6632048	SEAL KIT			D6, D14
6632053	SWITCH			E23, E24
6632095	SECTION			C17
6632167	LINK			G4, G8
6632207	NUT			F16
6632210	SPACER			F16
6632217	STRIP			B2
6632221	STUD			I12
6632222	BOLT			F16
6632228	RETAINER			F20
6632242	CONDENSOR			F16
6632253	GASKET			F16
6632264	VALVE			E24
6632265	PLUG			I21
6632280	U-PACKING	6632283	A	C4
6632281	VALVE ASSY			C4
6632282	VALVE ASSY			C4
6632284	SEAL			C4
6632304	PURIFIER			J13
6632307	MUFFLER			J13
6632323	WASHER			F20
6632383	KIT			F18
6632429	RETAINER			G2
6632430	ROLLER			G2
6632432	PLUNGER			G2
6632433	GASKET			G2
6632434	COVER			G2

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6632435	BALL			G2
6632436	SPRING			G2
6632441	SPRING			G2
6632448	SPACER			E14
6632454	PLUG			I16
6632462	VALVE			E4, E10
6632464	PIN			E2, E8
6632469	ADHESIVE			A12, A18
6632501	SEALANT			B16
6632538	OIL PAN			H16
6632559	BUSHING			D16
6632560	KEY			I14, I18
6632601	CAP			B16, G12
6632949	WEIGHT			H13
6632950	WEIGHT			H14
6632954	PROBE			J22
6632973	SWITCH			F2, F4
6633583	SEALANT			J24
6633675	GASKET			J13
6634201	WASHER			H2
6634202	SPRING			H4
6634203	SPRING			H2
6634204	WASHER	3725439	A	G24
6634207	STUD			G12
6634207	STUD	6515738	A	H6
6634208	CRANKSHAFT			H10
6634209	SPACER			H10
6634210	BOLT			H9
6634222	FRAME	6631503	A	H13
6634223	STUD	375510	A	H16
6634224	INJECTOR			H24
6634225	NOZZLE			H24
6634311	ROTATING			D20
6634313	ADAPTER			E10
6634382	SWASHPLATE			E2, E8
6634393	LUBRICANT			J24
6634404	BOLT			F21
6634425	GASKET			E4, E10
6634427	SLEEVE			E6, E10
6634429	PISTON			E4, E10
6634478	ORIFICE			E6, E10
6634481	HANDLE			E4, E12
6634488	SEAL KIT			E4, E10
6634533	PIN			E2, E8
6634552	O-RING			E10
6634553	PIN	666863	B, D	D20
6634592	PIN			E2, E8
6634603	BOLT			E4, E10
6634604	BOLT			E12
6634613	BEARING			E2, E8
6635733	GEAR			E16

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
663834	SNAP RING			B20
663834	SNAP RING	663844	D	B18
6640607	POPPET			E2, E12
6640609	VALVE			E4
6640610	PLATE			E8
6640612	GASKET			E2, E8
6640618	SPOOL			E4, E12
6640619	ORIFICE			E6, E10
6640798	SHAFT	6613101	A	G24
6641051	KNOB			J8
6641052	CONTROL			J8
6641053	COIL			J8
6641054	SUPPORT			J8
6641055	GROMMET			J8
6641056	GROMMET			J8
6641057	COVER			J8
6641058	FAN BLADE			J8
6641059	HARNESS			J8
6641060	DECAL			J8
6641061	SWITCH			J8
6641062	SCREW			J8
6641063	GRIP			J8
6641064	SPRING			J8
6641065	NUT			J8
6641066	SCREW			J8
6641067	DAMPER			J8
6641068	HANDLE			J8
6641069	WEATHER STRIP			J8
6641070	WEATHER STRIP			J8
6641071	WEATHER STRIP			J8
6641072	WASHER			J8
6641073	NUT			J8
6641074	PAD			J8
6641075	MOTOR			J8
6641076	HOUSING			J8
6641274	LATCH			I14, I18
6641320	SHORT BLOCK			G18
6641351	BALANCER	6632896	A	H13
6641358	COUPLER			C4, C10
6641359	COUPLER			C4, C10
6645071	COVER	6631442	A	E4, E12
6645072	COVER	6631443	A	E4, E10
6645090	SEAL	6631023	D	D20
6645090	SEAL	6640613	A	E8
6645231	CAP			C4, C10
6645232	PLUG			C4, C10
6645537	HEATER			J8, J9
6646086	PLUG			E12
6646578	VALVE			D10
6646635	COUPLER			D14
6646781	SWITCH			I8

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6646782	PUMP			E13
6646784	BEARING	5292915	A	B18
6647635	KNOB			I14, I18
6647636	KEY			I14, I18
6647667	SHOCK			D18
6647721	PUMP			E16
6647753	SEAL KIT			E22
6647754	SEAL KIT			E20, E22
6647776	PLUNGER			C22
6647777	PIN			C22, C24
6647778	CAP			C22, C24
6647779	PLUG			C21
6647780	PLUG			C21, C23
6647781	PLUG			C22
6647783	LOAD CHECK			C21, C23
6647784	PLUG			C21, C23
6647785	SPRING			C21, C23
6647786	SEAL KIT			C22
6647808	KIT			C18
6647875	ELBOW	6003173	A	D6, D14
6647879	TIRE			J19
6648256	NUT	6631457	A	E4, E10
6648293	SCREW			C24
6648293	SCREW	6631562	A	C22, E14
6648294	SPRING			C24
6648294	SPRING	6647782	A	C22
6648346	PUMP			H24
6648561	SEAL KIT			C6, C10
6648774	BEARING	743778	A	B18
6648776	RACE	743777	A	B18
6648778	BEARING	742273	A	B18
6648779	RACE	731994	A	B18
6648780	BEARING	6512923	A	B23
6648782	RACE	6512922	A	B23
6648785	RACE	730503	A	B18
6648968	COUPLER			C6, C10
6648970	COUPLER			C6, C10
6649386	THRUST PLATE			D20
6649387	HOUSING			D20
6649421	BLOCK			H6
6649422	LINER			H6
6649423	GASKET	3737951	A	G18, H6
6649425	BOLT			H4
6649426	BOLT			H4
6649427	BOLT			H4
6649429	GUIDE	6634220	A	H4
6649430	SHAFT	3739649	A	G24
6649431	GASKET			G18, G22
6649432	BOLT	18C-514	B	G22
6649432	BOLT	3734229	A	H17
6649433	CAMSHAFT	6649443	D	G22

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6649434	GEAR			G22
6649435	BOLT			G22
6649437	NUT	909696	A	H14
6649438	WASHER			G22
6649439	GEAR	909562	A	H14
6649440	BOLT	29CM-1060	A	H14
6649441	BOLT	29CM-1035	A	H14
6649444	BOLT			18C-572, H16
6649448	GASKET	3725428	B	G23
6649449	PIPE	994921	B	G23
6649450	STUD	3725328	A	H6
6649452	PULLEY			H10
6649455	BOLT	3726840	A	H20
6649459	SPACER	6664959	B	I23
6650219	KNOB KIT			A24
6650220	SHROUD			A24
6650221	LATCH KIT			A24
6650223	CABLE			A24
6650224	SUPPORT			A24
6650225	BACK CUSHION			A24
6650226	SEAT CUSHION			A24
6650228	TRACK			A24
6650229	SPRING			A24
6650230	SEAT PAN			A24
6650231	CLIP			A24
6650239	SCREEN	6598911	A	B8, B12
6650241	PUSH NUT			A24
6650242	TIP			A24
6650243	BOOT			A24
6650244	NUT			A24
6650245	WASHER			A24
6650246	WASHER			A24
6650247	WASHER			A24
6650248	SPACER			A24
6650249	SPACER			A24
6650250	WASHER			A24
6650251	CLIP			A24
6650388	SEALANT			B18, J24
6650388	SEALANT	1802303	A	B16, B22
6650407	ADHESIVE			J24
6650656	SPRING			E2, E12
6650669	POPPET			E2, E12
6651167	VALVE	6646483	A	C8
6651223	ADAPTER			I6
6651476	TIRE			J19
6651664	STARTER	6651210	A	F24
6652373	VALVE	3739636	A	I1
6652818	ADHESIVE			J24
6652935	EDGING			A21
6653517	REDUCER			J24
6653518	PRIMER			J24

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6653728	NUT			E6, E12
6653731	VALVE			E2, E12
6653733	BOLT	17C-410	B	E4, E12
6653734	NUT	6631456	A	E4, E12
6653735	WASHER	8E-4	B	E4, E12
6653736	BOLT			E4, E10
6653738	O-RING			E10
6654216	ADHESIVE			B14
6654374	KEY			B10, B14
6655042	O-RING			E12
6655317	MOTOR	6646893	A	E20
6655435	MOTOR	6630132	A	B16, D20
6655454	SHAFT			D20
6655796	SEAL KIT			C6, C10
6656074	HOUSING			E10
6656075	HOUSING			E4
6656076	COVER			E8
6656265	SOLENOID	6630257	A	E17, F6, F10
6656306	COVER			E4
6656379	SEAL KIT			E20
6657082	SWITCH	6568930	A	E17, F6, F10
6657083	ELBOW	6599488	A	B8
6657267	SWITCH	6568962	A	F6
6657267	SWITCH	6646780	A	F10
6657299	OIL			A1, J24
6657301	OIL			A1, J24
6657303	OIL			A1, J24
6657315	SLEEVE			E6, E10
6657320	ORIFICE			E6, E10
6657732	PUMP			E2, E8
6658142	WINDOW	6630923	A	I21
6658143	WINDOW	6630922	A	I21
6658266	GREASE			J24
6658352	MOULDING			A16
6658352	MOULDING	6554221	A	I16
6658564	HOLDER ASSY			F24
6658565	BRUSH			F24
6658566	BRUSH			F24
6658567	BUSHING			F24
6658568	SPRING			F24
6658569	BEARING			F24
6658570	BEARING			F24
6658571	SUPPORT			F24
6658572	LEVER			F24
6658573	STOP			F24
6658574	ARMATURE			F24
6658575	FRAME			F24
6658576	DRIVE SHAFT			F24
6658577	SUPPORT			F24
6658580	FRAME ASSY			F24
6658581	O-RING			F24

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6658582	SOLENOID	6652562	A	F24
6658691	RIVET	6632113	A	A12
6658818	SENDER			F6, F10
6658903	PLUNGER	6630417	A	F21
6659256	RING	6653740	A	E6, E12
6659319	SOLENOID	6632186	A	F6, F10
6659371	NUT			F20
6659372	WASHER			F20
6659374	SPACER			F20
6659375	FAN			F20
6659376	BRACKET			F20
6659378	BOLT			F20
6659379	BEARING			F20
6659380	ROTOR			F20
6659381	STATOR			F20
6659382	BRACKET			F20
6659384	RECTIFIER			F20
6659385	SCREW			F20
6659386	HOLDER			F20
6659387	NUT			F20
6659388	CONDENSER			F20
6659390	HOLDER			F20
6659391	NUT			F20
6659392	BOLT			F20
6659393	REGULATOR			F20
6659394	BRUSH			F20
6659395	SPRING			F20
6659396	SCREW			F20
6659397	TERMINAL			F20
6659398	COVER			F20
6659399	SCREW			F20
6659400	CONNECTOR			F20
6659543	PLUG			J15
6659818	O-RING			H24
6659949	LATCH			I21
6659972	FLASH TUBE	NSS	D	J17
6660004	RADIATOR	6630958	A	G3, G6
6660079	GUIDE			D20, E6, E12
6660080	RETAINER			D20, E6, E12
6660318	PIPE	6576942	A	G6
6660366	SNAP RING	NSS		E20, E22
6660456	PUMP			E2, E8
6660650	PLATE			G22
6660651	GASKET			G18, G22
6660727	FILTER			D10
6660728	ELEMENT			A1, D10
6660778	ADAPTER			E12
6660779	O-RING PLATE			E12
6660780	BOLT			E12
6660932	LATCH	6647789	A	I12, I16
* 6660988	RETAINER			J6

Code for disposition of old part number
A — Use up
B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales
D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6660988	NUT			I14, I18
6661036	SEAL KIT	6569347	A	C18
6661037	SEAL KIT	6579425	A	E6, E12
6661040	SERVO KIT	6720759	A	E6, E12
6661114	CAP	6632468	A	B8, B12
6661150	HARNESS			I8
6661213	CLIP			B10, B14
6661248	ELEMENT			A1, E23
6661248	ELEMENT	6598903	B	D4
6661299	BEARING	6630242	A	G10
6661610	KIT			J15
6661611	ALTERNATOR			F20
6661655	ENGINE			G18
6661685	DRIVE	6658583	A	F24
6661686	SUPPORT	6658578	A	F24
6661687	HOUSING DRIVE	6658586	A	F24
6661689	TRACK	6630916	A	I21
6661690	TRACK	6630917	A	I21
6661696	CAP			B8, B12
6662031	BLOCK			H6
6662032	KIT	3725418	A	H11
6662033	LINER			H6
6662034	CRANKSHAFT			H10
6662035	WASHER	3725399	A	H9
6662037	VALVE			H2
6662038	VALVE			H2
6662040	GASKET			G18, H6
6662041	GASKET			G18
6662041	GASKET	3739740	A	G20
6662043	GASKET KIT			G18, H2, H8
6662044	GASKET KIT			G18, H8
6662044	GASKET KIT	6630423	A	H8
6662049	KIT	3726184	A	H11
6662692	SHAFT			H14
6662789	SEAL			G12
6662834	SPRING			I14, I18
6664260	PIPE			G24
6664261	BOLT			G24
6664351	SEAL			A18
6664440	SWITCH			E17
6664440	SWITCH	6657724	A	F6, F10
6664886	HOURLMETER	6631657	A	F2, F4, J16
6665021	LENS			J18
6665022	FLASH TUBE			J18
6665023	GASKET			J18
6665024	BRANCH GUARD			J18
6665025	LENS			J18
* 6665086	SEAL	1615087	B	C15
6665086	SEAL			C16
* 6665122	PLATE			E8
6665383	CAP	6630156	A	G8

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6665398	MOTOR	6646900	A	D20
6665409	KEY			I18
6665427	BATTERY	6641343	A	F10
6665430	BACK-UP RING			I6
6665606	SWITCH			F2, F4
6665656	CLIP			A21
6665715	PISTON			C13
6666220	BOLT	6656077	A	E6, E12
* 6666221	SHAFT	6631426	A	E8
6666342	VALVE			C23
* 6666544	SEAL	1657088	B	C11, C12, C13
* 6666596	VALVE			E4
6666606	CAP	6630156	A	G4
6666622	CLUTCH			G2
6666624	SNAP RING			G2
6666628	NUT			G2
6666629	WASHER			G2
6666630	WASHER			G2
6666631	O-RING			G2
6666632	O-RING			G2
6666633	BOLT			G2
6666634	SCREW			G2
6666635	SCREW			G2
6666637	NUT			G2
6666638	GASKET			H20
6666639	PUMP			H20
6667176	PLUG			C23
6667185	SEAL KIT			C24
* 6667320	STARTER			G2
* 6667327	SEAL	6538140	B	C12, C13
* 6667492	HOUSING			H6
6667501	BLOCK	6634206	A	H6
6667502	SCREW	3725342	A	H6
* 6667506	TUBE			H16
* 6667512	DIPSTICK			H16
6667832	GASKET	3725500	A	G22
* 6667875	SEAT BELT			A20
6668014	GASKET			G18
6668014	GASKET	907983	A	H19
6668015	GASKET KIT	908230	A	G18, H2, H8
6668020	GASKET			G18
6668020	GASKET	3490326	A	H24
6668021	GASKET	3490369	A	G22
6668022	GASKET			G18
6668022	GASKET	3679404	A	H8
6668023	GASKET	3679408	A	H17
6668025	GASKET	3725457	A	G20
6668026	GASKET	3725458	A	G20
6668027	GASKET	3725459	A	G20
6668030	GASKET			G18
6668034	GASKET			G18

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6668034	GASKET	3739690	A	G22
6668035	GASKET	6510282	A	H20
* 6668117	GASKET			H24
6668210	PLUG	3725310	B	H6
6668230	WASHER	3725401	A	H9
* 6668241	VALVE	3725360	A	H2
6668241	GUIDE	6649428	A	H4
6668249	LEVER	3725444	A	G24
6668251	LEVER	3725445	A	G24
* 6668264	PLATE	3490184	A	G22
* 6668551	GASKET	6668030	A	H19
6668717	SCREW			A24
6668733	REGULATOR	6630349	B	I23
* 6668815	SWITCH			J6
6668829	DIPSTICK			H16
6668830	TUBE			H16
6668879	DECAL			I7, I8
6668881	CORD			I9
6668953	BRACKET			A22
6669082	PUMP REMAN			E2, E8
6669089	TRACK			A22
6669135	SEAT			A22
6669345	YOKE			G2
6669346	ARMATURE			G2
6669347	BEARING			G2
6669348	BEARING			G2
6669349	BEARING			G2
6669350	KIT			G2
6669352	BEARING			G2
6669353	BEARING			G2
6669354	SHAFT			G2
6669357	KIT			G2
6669358	KIT			G2
6669359	BOLT			G2
6669360	BUSHING			G2
6669361	HOLDER			G2
6669362	SPRING			G2
6669364	PINION			G2
6669365	BOOT			G2
6669366	BOLT			G2
6669367	BOLT			G2
6669368	O-RING			G2
6669369	PINION			G2
6669370	BRUSHES			G2
6669371	BRUSHES			G2
6669372	COVER			G2
6669434	HOUSING			G2
6669435	SWITCH ASSY			G2
6669436	FRAME			G2
* 6669663	GUAGE	6658817	A	F2, F4
* 6669664	VOLTMETER	6658819	A	F2

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
* 6669664	VOLTMETER	6658821	A	F4
* 6669665	FUEL GUAGE	6658820	A	F2, F4
6669982	VALVE	6631419	A	C17
6670160	CUSHION			A22
6670163	SHAFT			I14
6670164	LINK			I14
6670165	CLIP			I14
* 6670274	ROTATING	6634311	A	E2, E8
* 6670281	TAPPET	0994904	A	G24
* 6670881	PLUG	3725306	A	H6
* 6671958	TIRE & RIM			J20
* 6671959	TIRE & RIM			J20
* 6671960	TIRE & RIM			J20
* 6671961	TIRE & RIM			J20
* 6672046	TIRE & RIM			J21
* 6672047	TIRE & RIM			J21
* 6672048	KIT			J21
* 6672049	KIT			J21
* 6672537	PIPE	3725676	A	H24
* 6673049	PIN	6670273	A	E2, E8
* 6674013	TRACK			A22
* 6674019	SEAT	6647432	A	A21, A24
* 6674202	NUT			F2, F4
* 6674204	MOTOR OIL			A1, J24
* 6674205	MOTOR OIL			A1, J24
* 6674206	MOTOR OIL			A1, J24
* 6674361	COVER	6662836	A	G22
* 6674744	HOSE			A14
* 6677327	SEAL	6538140	B	C11
6700170	WASHER	6563152	A	A20, G16
* 6700171	GAS SPRING	6706590	A	A16
6700388	DECAL	6561379	B	J4
6700782	GREASE CAP			G12
6701159	SHIM			G12
6701378	SHIM	6565827	A	B18
6701986	WINDOW	6563391	A	A16
6702255	DECAL			J2
6702301	DECAL			J2
6702302	DECAL	6575694	A	J2
6702430	SPRING	6563149	A	A20
6702593	STRIP			I8
6702642	BOLT			F4
6702731	WINDOW	6567750	A	I21
6702797	CAP	6558658	A	G3, G6
6702857	HOSE			D12
6702971	BOLT	6568398	A	A12, A16
6703159	TRACK			A18
6703159	TRACK	6630921	A	I21
6703160	TRACK			A18
6703160	TRACK	6630920	A	I21
6703705	PLATE	6563431	A	F2

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
6704248	PIVOT	6576454	A	B6
6704349	BOLT	37C-616	B	C19
6704425	ROD	6576470	A	I12, I16
6704426	RETAINER	6578398	A	I14, I18
6704428	SHIELD	6576471	A	I12, I16
6704430	DOOR	6704431	A	I14
6704453	SPRING	6578252	C	A20, B6
6704887	HARNESS			I23
6704891	WINDOW	6703021	A	A18
6705735	WINDOW			A16
6706553	INSULATION			A16
6708294	DECAL	6569021	A	J2
6708850	RETAINER			I14
6708929	DECAL			J4
6708990	KIT			I14
6709028	PLATE	6708701	A	F2, F4
6709527	KEY	6666202	A	F2, F4
6711327	DECAL	6563382	A	J4
* 6711708	MOUNT			J6
* 6711907	GUIDE			A20
* 6712288	HARNESS			J6
* 6713061	KIT			A20
* 6714062	KIT			A16
* 6714213	HARNESS			J6
* 6714901	ELBOW	1300294	A	C8, D4, D12
6720038	INSTRUCTIONS			I9
6720075	INSTRUCTIONS			I6
6720745	HEATER	6647892	A	I9
6720856	INSTRUCTIONS			J17, J18
6722155	INSTRUCTIONS			I8
* 6722344	BLACK GOLD			A1
6722344	BLACK GOLD			J24
6722781	PAINT			J24
6722782	PAINT			J24
6722783	PAINT			J24
6722784	PAINT			J24
6722785	PAINT			J24
6722786	PAINT			J24
6722787	PAINT			J24
6722788	PAINT			J24
6722789	PAINT			J24
6724094	ANTI-FREEZE			J24
6724279	INSTRUCTIONS			I14
6724282	SWITCH KIT			F2, F4
6724354	ANTI-FREEZE	6658230	A	J24
6724557	OIL			A1, J24
6724558	OIL			A1, J24
6724559	OIL			A1, J24
6787983	HOSE	6571789	A	D12
6800659	ADAPTER	6577261	A	D8
* 6803313	SEAL KIT	6586686	A	C12, C13

Code for disposition of old part number
A — Use up
B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales
D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
* 6803867	WASHER	6558956	A	B16
* 6804061	BUSHING			I10
* 6804062	BUSHING			I10
* 6804064	PIN			I10
* 6804075	KIT			I10
* 6804342	WASHER	6571723	C	G12
* 68044592	NUT	6803253	B	C14
* 6804592	NUT	6803253	B	C15, C16
* 6804603	SEAL KIT	6589798	A	C16
* 6804603	SEAL KIT	6803269	A	C11
* 6804604	SEAL KIT	6803272	A	C14, C15
* 6805079	HOSE	6564639	A	G10
* 6900530	INSTRUCTIONS			I10
* 6900531	INSTRUCTIONS			A16
7000010	SPACER			A22

JENSALES®

purchase full manual at

JENSALES.COM

or Call 800-443-0625

Code for disposition of old part number
A — Use up
B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales
D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
1CM-610	BOLT			H14
1CM-650	BOLT			F24
1CM-830	BOLT			J21
1CM-865	BOLT			H14
1EM-60	WASHER			F24
2F-8127	PIN			A16
4E-4	WASHER			G23, I23
4E-5	WASHER			A21, G22, G23, H2, H16, H17, H24
4E-6	WASHER			G12, G20, G22, H2, H18, H19, H22
4E-7	WASHER			H6
4E-10	WASHER			H18
4F-5062	PIN			C19, D16
5H-8	CLAMP			D2
5K-116	NIPPLE			5K-124, G4, G6
6E-6	WASHER			F4
6H-31	CLAMP			H16
6J-405	KEY			I23
6J-505	KEY			H18
6J-807	KEY			D2, D8, E8, G22, H10
6J-1210	KEY			B18
7C-312	BOLT			I23
7C-322	BOLT			I23
7C-520	BOLT			I20
7C-560	BOLT			D2
7C-612	BOLT			G4, G6
7C-644	BOLT			D14
7C-652	BOLT			J11
7D-5	NUT			F22
7D-8	NUT			D16
7DM-6	NUT			F24
7G-416	BOLT	7G-412	B	I14, I18
7J-10208	KEY			B23
8C-1020	BOLT			G12
8D-4	NUT			D16
8D-5	NUT			C19
9G-616	BOLT			A12, G8
9J-34	SNAP RING			D16
10D-5	NUT			H16
10H-25	GREASE ZERK			B4, G14
10H-35	GREASE ZERK			B6
10K-5	TEE			C4, C10
10K-7	TEE			C8
11F-12	PLUG	40K-12	A	B16
11H-25	GREASE ZERK			D16
12D-6	NUT			F2, F4, J16
12D-8	NUT			F14
12D-10	NUT			A16, I20, I23, J5
12E-6	WASHER			F2, F4
12G-420	BOLT			E14
12G-856	BOLT			H4
12K-5	FITTING			J14

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
13F-2	PLUG			H6
13GM-404	SCREW			F24
13GM-408	SCREW			F24
13K-6	TEE			D2, D8, I6
14J-2512	PIN			A20
14J-2516	PIN			B22
14J-5040	PIN			B6
14J-5044	PIN			B6
15K-5	ADAPTER			D2, D8
15K-6	ADAPTER			G12
15K-7	ADAPTER			C2
15K-8	ADAPTER			C4, C10, D4, D12
15K-10	ADAPTER			C2, C4, C8, C10, D4, D12
15K-11	ADAPTER			D4, D14
16C-716	BOLT			G10
16D-6	WING NUT			J11
16F-4	PLUG			H8
16F-8	PLUG			H2, H16, H17, H19
17C-408	BOLT			G22, J16
17C-410	BOLT			F6, F10
17C-412	BOLT			B10
17C-508	BOLT			B18, D16, G4, G8
17C-510	BOLT			A24
17C-516	BOLT			I7
17C-520	BOLT			A16, G16
17C-524	BOLT			A16
17C-528	BOLT			D8, G6
17C-532	BOLT			C2
17C-540	BOLT			C8
17C-572	BOLT			F2
17C-608	BOLT			G10
17C-610	BOLT			D4, D12
17C-612	BOLT			A20, B18, D16
17C-614	BOLT			J16
17C-616	BOLT			A12, B8, B10, B12, B22, D8 D16, E15, E16, F6, F10, G3 G6, I8, I18, I20
17C-618	BOLT			G16
17C-620	BOLT			B10, D2, E14
17C-624	BOLT			C19
17C-628	BOLT			B6
17C-632	BOLT			G16
17C-640	BOLT			G10
17C-644	BOLT			D16, E17
17C-664	BOLT			B22
17C-712	BOLT			I12
17C-714	BOLT			I16
17C-716	BOLT			A20
17C-720	BOLT			G4, G6
17C-812	BOLT			B22
17C-820	BOLT			B18, B22

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
17C-832	BOLT			D2, D8
17C-836	BOLT			D20
17C-864	BOLT			G10
17C-868	BOLT			G12
17C-888	BOLT			G12
17C-1024	BOLT			B23
17C-1052	BOLT			G12
17C-1056	BOLT			A16
17C-1220	BOLT			B18
17C-1228	BOLT			B16
17C-1236	BOLT			B14
17C-1256	BOLT			B4
17E-8	WASHER			I22
17E-10	WASHER			I23
17K-6	ELBOW			D2, D6, D8
17K-7	ADAPTER			C8
17K-8	ELBOW			D4, D12
17K-10	ELBOW			D4, D12
18C-410	BOLT			G23
18C-508	BOLT			F8, F12, H16
18C-510	BOLT			G22
18C-512	BOLT			G23, H2, H16
18C-514	BOLT			H16, H19
18C-516	BOLT			H6
18C-520	BOLT			F8, F10
18C-522	BOLT			H24
18C-536	BOLT			H19
18C-540	BOLT			G22
18C-552	BOLT			H16
18C-556	BOLT	18C-552	B	G12
18C-580	BOLT			G12
18C-608	BOLT			B14
18C-610	BOLT			H6
18C-612	BOLT			G4, G6, J14
18C-614	BOLT			H2
18C-616	BOLT			G10, G22, H22
18C-620	BOLT			G20
18C-622	BOLT			G20, H19
18C-628	BOLT			G12
18C-636	BOLT			H19
18C-640	BOLT			G22, H14, H18
18C-644	BOLT			H18
18C-648	BOLT			H14
18C-652	BOLT			H14
18C-656	BOLT			G20, H18
18C-716	BOLT			G10
18C-732	BOLT			G24
18C-818	BOLT			G22
18C-824	BOLT			G10
18K-4	ELBOW			B14
18K-5	ELBOW			D8

Code for disposition of old part number
A — Use up
B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales
D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
18K-8	ELBOW			D4, D12
19F-4	ADAPTER			F6, F10
19K-7	ELBOW			D14
19K-11	TEE			D4, D12
21K-4	TEE			B8, B12
21K-5	TEE			D2, D8
21K-6	TEE			D10, D12
21K-7	TEE			C2
22K-4	NUT			B10
23E-5	WASHER			F22
24K-3	PLUG			E4, E10
24K-5	PLUG			I24
24K-6	PLUG			D20
24K-7	PLUG			C2, C4, C8, C10, E12
25E-4	WASHER			F21
25E-10	WASHER			I20
25E-13	WASHER			D16
25E-14	WASHER			D10
25E-15	WASHER			I20, J21
25E-15	WASHER	25E-14	B	A18
25E-16	WASHER			I12, I16
25E-17	WASHER			D16, G16, J16
25E-18	WASHER			G16, I12, I16, I20
25E-19	WASHER			H18, I16
25E-19	WASHER	4E-10	D	H17
25E-20	WASHER			A18
25E-21	WASHER			G10
25G-410	BOLT			J5
25G-510	SCREW			I12, I16
25G-512	BOLT			A22
25G-514	BOLT			F2, F4
25G-520	BOLT			A22
25K-20012	O-RING			E10
25K-20012	O-RING	25K-20020	B	E4
25K-20014	O-RING			C18
25K-20016	O-RING			E17
25K-20020	O-RING			E4, E10
25K-20026	O-RING			E12
25K-20308	O-RING	6510656	A	E15, E16
25K-20400	O-RING			E2
25K-30018	O-RING			E14
25K-30028	O-RING			E14
25K-30100	O-RING			B22
25K-30114	O-RING			E14
25K-30400	O-RING			B16
25K-40024	O-RING			C17
25K-40100	O-RING			C18, F2, F4, F6, F10
25K-40200	O-RING			D2
25K-40316	O-RING			C17
27E-5	WASHER	3727372	A	G12
27E-6	WASHER			D16, G8, G10

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
27E-7	WASHER			25E-19, G12
27E-8	WASHER			I10
29CM-825	BOLT			G12
29CM-830	BOLT			H14
29CM-1245	BOLT			H14
30H-27	CLAMP			C4, C10
30H-29	CLAMP			B10
30H-31	CLAMP			B8, B12
30H-42	CLAMP	5H-8	B	D8
30H-45	CLAMP			F2, F4
30H-50	CLAMP			F8, F12
31C-420	BOLT			J6
31C-510	BOLT			A24
31C-612	BOLT			G4
31C-1228	BOLT	17C-1228	B	A12
31C-1232	BOLT	17C-1232	B	A12
33G-404	SCREW			B2
33G-608	SCREW			G4
35C-410	BOLT			A18
35C-410	BOLT	25G-410	B	I21
35C-412	BOLT			D10, I12, I16
35C-416	BOLT			I12, I16
35C-508	BOLT			G4, G6, I24
35C-512	BOLT			A21, G12
35C-516	BOLT			I12, I16, I20, J5
35C-608	BOLT			A20
35C-610	BOLT			B6
35C-612	BOLT			C4, C10
35C-616	BOLT			A14, C19, D4, D12, G8, I24
35C-820	BOLT			D10
35C-824	BOLT			G10
35C-832	BOLT			I10
35C-840	BOLT			G14
36K-5	CAP			C4, C10, D2, D8
36K-6	CAP			G10
37C-616	BOLT	6514537	A	B10, D16
37C-624	BOLT			G8
37C-828	BOLT	6516292	A	C2, C8
37K-302	COUPLING			G4, G6
38C-624	BOLT	6564599	B	B2
40DM-8	NUT			J21
40K-2	PLUG			G20
41E-1616	ADAPTER	52E-1616	A	D2
41E-1616	ADAPTER	52E-1616	D	D8
41G-806	SCREW			I22
41K-4	PLUG			H8
42E-1616	ELBOW	55E-16	A	D2, D4, D12
42E-1616	ELBOW	55E-16	B	D8
42H-10	CLAMP			J9
42H-12	CLAMP			G23
42H-32	CLAMP			D2, D4, D8, D12

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
42H-32	CLAMP	42H-24	A	B8, B12
42H-32	CLAMP	42H-24	B	G4, G6
42H-64	CLAMP			A12
43G-408	SCREW			F21
45G-1008	BOLT			F14, I14, I18, I20
45K-5	ADAPTER			C4, C10
45K-6	ADAPTER			I6
46D-5	NUT			I14, I16
47K-5	PLUG			C11, C12, C13, C14, C16
47K-5	PLUG	47K-7	D	C15
48K-16	O-RING			I6
50D-10	NUT			I14, I16
54K-30218	O-RING	25K-30218	B	C11, C12, C13, C15, C16
54K-40224	O-RING	58K-232	B	C11, C12, C13, C15, C16
54K-40300	O-RING	58K-232	B	C15, C16
54K-40300	O-RING	58K-234	B	C12, C13
56E-16	TEE			C2
56F-16	TEE			C8
57D-5	NUT			I18
57D-6	NUT			A12, B8, B12, C19, D4, D8 D12, D16, I24
57F-3	FERRULE			H22
58F-3	NUT			H22
58G-1008	SCREW			A12
58K-10	O-RING			E14
58K-12	O-RING			E4, E12
58K-19	O-RING			E10
58K-21	O-RING			C2, C8, D2, D4, D8, D12
58K-109	O-RING			A18
58K-111	O-RING			C20
58K-114	O-RING			C20
58K-115	O-RING			C20
59D-4	NUT			A16
59D-5	NUT			F6, F10
59G-616	BOLT			I8
61D-4	NUT			B10, G10, J16
61D-5	NUT			A12, A24, F2, F4, I7, I8, I14
61D-6	NUT			A12, B10, F6, F10, G3, G6, G16, J16
61D-7	NUT			G4
61D-8	NUT			B22
62D-4	NUT			I23
62D-5	NUT			H24
62D-6	NUT			D18, G12, H19
62D-10	NUT			H18
73G-428	SCREW			C18
73G-612	BOLT			G16
73G-620	BOLT			C19
73K-15	BACK-UP RING			C18
75F-1	COUPLING			G6
75G-1016	SCREW			32G-1016, I12, I16
75G-1020	BOLT			I20

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
75K-16	O-RING			D6, D14
75K-16	O-RING	79K-16	B	D2, D8
76K-113	O-RING			C18
79K-10	O-RING			C2, C4, C8, C10, D4, D12, E10, E17
79K-12	O-RING			C4, C10, C18, D4, D12, E4, E10
79K-12	O-RING	79K-5	B	D, C18
79K-14	O-RING			C2, C4, C8, C10, C18
79K-16	O-RING			C2, C8, C10, D4, D12
79K-16	O-RING	79K-8	B	D6
79K-4	O-RING			E4, E10
79K-5	O-RING			B8, B10
79K-6	O-RING			C11, C12, C13, C14, C15, C16, D2
				D4, D8, D14, D16, F6, F10
79K-8	O-RING			D2, D8, D12, D20, G10
79K-20	O-RING			D4, D12
80K-14	BACKUP RING			E17
80K-232	BACKUP RING	73K-232	B	C11, C12, C13, C15, C16
81D-8	KEY			E2
83D-4	NUT			A18, I7, I12, I16, I21, J5
83D-5	NUT			F2, I12, I16, I20, J5
83D-6	NUT			B10, G8
83D-7	NUT	61D-7	A	G6
83D-8	NUT			D2, D8, G10
83D-10	NUT			A16, G14
83D-12	NUT			A12, B8, B12
83F-5	ELBOW	83F-8	B	D4
84D-7	NUT			G12
84G-1608	SCREW			I23
84G-1906	SCREW			I23
84G-1910	SCREW			I23
84G-2516	SCREW	61G-416	B	A16
84G-3112	BOLT			A16, I12, I16
84G-3712	BOLT			A12, B4, B16, B22, D10, F6, F10
				G4, G6, I6, I24, J9
84G-3716	BOLT			A12, D2, D8
84G-3720	BOLT			B16, G16
85D-4	NUT			F6, F10, G16
85D-5	NUT			A16, A21, B2, C2, C8, C19
				D2, D8, G8, G16
85D-6	NUT			A12, A20, B6, B22, C2, C4, C8
				C10, C19, D14, D16, E17, G12
				G16, I18, I20
85D-7	NUT			A20
85D-8	NUT			A12, A16, B22, C2, C8
85D-10	NUT			G12
85G-608	BOLT			F2, J16
85G-1008	BOLT			B12, J5
85G-1014	BOLT			A16
86D-12	NUT			D2, D8, E8
86D-4	NUT			D16
86D-8	NUT			B6, C18

Code for disposition of old part number
A — Use up
B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales
D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
86D-14	NUT			C11
86F-5	NUT			C4, C10
86F-6	NUT			D14, I6
86G-1008	SCREW			B8
86G-1014	SCREW			H22
86G-1016	SCREW			H24
87F-5	ADAPTER			C10
88F-5	ELBOW			C4
89G-520	BOLT			B2
90KV-5	PLUG			C13, C16
91G-416	SCREW			A16
92D-14	NUT			C12, C13
92F-4	NUT			H22
93G-406	SCREW			C17
93G-524	SCREW			E10
93G-616	SCREW			E2, E8
93G-832	SCREW			B16, E10
93G-840	SCREW			D2, D8
95K-6	PLUG			C13, C16

Code for disposition of old part number
A — Use up
B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales
D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
* NAP	BRACKET	6632224	A	F16
* NAP	CLAMP	6656124	A	G4, G8
* NAP	COVER	6649424	A	H6
* NAP	DIPSTICK	6633915	A	H16
* NAP	FAN	6632209	A	F16
* NAP	HEAD	6662036	A	H2
* NAP	HOSE	6631014	A	A12
* NAP	MOUNT	6568680	A	D4, D12
* NAP	PLATE	6634474	A	E8
* NAP	REAR DOOR	6567494	A	B2
* NAP	RING	6630331	A	B2
* NAP	ROD	6571551	A	B6
* NAP	SCREW	6630415	A	F22
* NAP	SEAT	6563140	A	A21
* NAP	SEAT BELT	6564744	A	A20
* NAP	TIRE	6567000	A	J19
* NAP	TIRE	6568572	A	J19
* NAP	TRACK	6669088	A	A22
* NAP	TUBE	6510524	A	H16
* NAP	TUBE	6515731	A	H16
* NAP	VALVE	3725362	A	H2
* NAP	VALVE	6634471	A	E4
* NAP	VALVE	6646641	A	E2, E12
* NAP	VALVE	6653745	A	E2, E12
NAP	ALTERNATOR	6632211	A	F16
NAP	BLOCK	6634199	A	H6
NAP	BODY	906101	A	H17
NAP	BRACKET	6568264	A	B12
NAP	BRACKET	6568656	A	B12
NAP	BRACKET	6587038	A	G10
NAP	BRACKET	6587804	A	G12
NAP	CAP	6631559	A	E14
NAP	CAP	6654373	A	B8, B12
NAP	CASE	6586880	A	C11, C12
NAP	CASE	6586919	A	C15
NAP	CASE	6592794	A	C14
NAP	CHAINCASE	6567027	A	B16
NAP	CLIP	6630928	A	A16
NAP	COUPLER	2518027	A	C4
NAP	COVER	6631451	A	E4, E12
NAP	CYLINDER	6586871	A	C12
NAP	CYLINDER	6586977	A	C15
NAP	CYLINDER	6593384	A	C14
NAP	CYLINDER	6593477	A	C11
NAP	DECAL	6575855	A	J2
NAP	DIPSTICK	6632539	A	H16
NAP	DOOR	6571754	A	I16
NAP	DOOR	6571755	A	I14
NAP	DOOR	6704434	A	I16

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

Model 943

Loader Parts

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
NAP	ELBOW	6656125	A	G4, G8
NAP	ENGINE	6641260	A	G18
NAP	FRAME	6538635	A	B6
NAP	FRAME	6565865	A	B6
NAP	GAS SPRING	6706590	A	A16
NAP	GEAR	6565843	A	B18
NAP	GEAR	6567961	A	B18
NAP	GEAR	6569587	A	B18
NAP	GEARBOX ASSY	6565821	A	B18
NAP	GEARBOX ASSY	6569837	A	B18
NAP	HOSE	6568362	A	B8, B12
NAP	KIT	6531643	A	J14
NAP	KIT	6569443	A	I7
NAP	KIT	6571597	A	J10
NAP	KIT	6571626	A	J13
NAP	KIT	6632381	A	F16
NAP	KIT	6632382	A	F16
NAP	LATCH	6630929	A	A16
NAP	LIFT ARMS	6575921	A	B4
NAP	MOULDING	6703019	A	A18
NAP	PIPE	909649	A	G24
NAP	PLATE	3725502	A	G22
NAP	PUMP	6630862	A	H20
NAP	PUMP	6632972	A	E2
NAP	PUMP	6633581	A	E2
NAP	PUMP	6656255	A	E2
NAP	PUMP	6659317	A	E2, E8
NAP	PURIFIER	6649868	A	J14
NAP	SAFETY CORD	6703020	A	A18
NAP	SCREEN	6569935	A	J10
NAP	SCREEN	6569936	A	J10
NAP	SEAT	6632388	A	A21
NAP	SEAT BAR	6589572	A	A20
NAP	SENDER	6599492	A	F6, F10
NAP	SHAFT	6565837	A	B18
NAP	SHAFT	909565	A	H14
NAP	SLEEVE	6640617	A	E6, E10
NAP	SPOOL	6634428	A	E4, E10
NAP	SPRING	6632299	A	E2, E12
NAP	STATOR	6632230	A	F16
NAP	STROBE LIGHT	6659815	A	J17
NAP	SWITCH	6519592	A	F2, F4
NAP	VALVE	6631531	A	C18
NAP	VALVE	6651167	A	C21
* NSS	ROTOR	6632229	A	F16
NSS	BRACKET	6632231	A	F16
NSS	BRUSH HOLDER	6632248	A	F16

Code for disposition of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales

D — Part Number Error

NUMERICAL INDEX (Cont'd)

Part No.	Description	Was	Code	Page
NSS	COLLAR	6659974	A	J17
NSS	GASKET	6659973	A	J17
NSS	KIT	6632384	A	F16
NSS	KIT	6632385	A	F18
NSS	LENS	6659971	A	J17
NSS	LENS	6660247	A	J17
NSS	PLATE	6536392	A	A12

CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

JENSALES®

purchase full manual at

JENSALES.COM
or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

Code for disposition of old part number
A — Use up
B — Use on other application (See PNI)

C — File PDR Report with Melroe Parts Sales
D — Part Number Error