



CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

J.I. Case

Parts Manual

30-60X

Motor

Parts Manual

purchase full manual at

JENSALES.COM

or Call **800-443-0625**

JENSALES

CLICK ANYWHERE FOR MORE DETAILS

THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
J.I. CASE OR IT'S SUCCESSORS. **J.I. CASE** AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

CA-P-30-60X MTR

CLICK ANYWHERE FOR MORE DETAILS

REPAIR PARTS

PRICE LIST

MANUAL PREVIEW

30-60 Tractor

JENSALES®



purchase full manual at

JENSALES.COM

Effective March 1, 1922

or Call 800-443-0625

J. I. Case Threshing Machine Co.,

(INCORPORATED)

RACINE, WISCONSIN

CLICK ANYWHERE FOR MORE DETAILS

CLICK ANYWHERE FOR MORE DETAILS

JENSALES®

purchase full manual at

JENSALES.COM

or call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS



CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

JENSALES®

purchase full manual at

JENSALES.COM

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

JENSALES®

purchase full manual at

JENSALES.COM

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

JENSALES®

purchase full manual at

JENSALES.COM

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

JENSALES®

purchase full manual at

JENSALES.COM

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

30-60 H. OIL TRACTOR REPAIRS

When Ordering Repairs YOU MUST Give Tractor Number

Telegraph Cipher	Number of part	Price	NAME OF PART	Page
Perdure.....	101 A	40.00	Pedestal for front axle.....	2
Peregrine.....	102 A	2.00	Canopy post bracket.....	2
	103 A		Steering knuckle, L. H. —08048A.....	6
Peremptory.....	103½ A	.60	Wood shoe for friction clutch.....	5
Perennial.....	104 A	10.00	Reach rod sleeve.....	5
Perezone.....	105 A	11.00	Bracket for reach rod sleeve.....	5
Perfect.....	106 A	.40	Plate for brake foot lever.....	5
	107 A		Steering knuckle, R. H. —08047A.....	5
Perfective.....	108 A	4.50	Steering worm.....	5
Perfectly.....	109 A	3.50	Bevel gear for steering.....	5
Perfervid.....	110 A	2.00	Bevel pinion for steering.....	5
Perfidy.....	111 A	16.00	Bracket for steering bevel gear.....	4
Perflation.....	112 A	25.00	Piston with oiler and set screw.....	2
	A 112 A	25.00	½" Oversize piston.....	2
Perfluent.....	112½ A	.15	Shoe for brake band.....	3
Perfoliate.....	113 A	1.50	Piston ring.....	2
	A 113 A	1.50	½" Oversize piston ring.....	2
Perforate.....	114 A	225.00	Balance wheel.....	5
Perforce.....	115 A	90.00	Belt pulley with bushings, see 2523A.....	3
Perform.....	116 A	11.00	Bushing for belt pulley.....	4
Performer.....	117 A	5.00	Cap for end of crank shaft.....	3
	118 A		Spider for belt friction clutch (see 08113A).....	3
	119 A		Spider for traction friction clutch (see 08119A).....	3
	120 A		Furnish A120A, 130A, 19½" of 1¼ pipe.....	2
Perfumery.....	A 120 A	110.00	Cylinder.....	2
	A 123 A		Rocker for exhaust cam, R. H., (see 08124A1).....	2
	A 124 A		Rocker for exhaust cam, L. H., (see 08125A1).....	2
Perianth.....	A 127 A	3.00	Bushing for cam rocker.....	3
	A 128 A		Exhaust valve rod end (see 08137A).....	3
Periblem.....	A 129 A	35.00	Cylinder head.....	2
Peribolos.....	130 A	.75	Pipe flange for cylinder head.....	2
	131 A		Inlet valve cage (see 08091A).....	3
Pericarp.....	132 A	2.00	Inlet valve guide.....	3
Pericenter.....	133 A	3.00	Exhaust valve guide.....	3
Periclinal.....	135 A	6.00	Bushing for traction clutch spider.....	4
Pericline.....	136 A	6.50	Bushing for wrist pin.....	2
Pericope.....	137 A	7.00	Bearing block for crank pin.....	2
Pericycle.....	138 A	7.00	Bearing cap for crank pin.....	2
Peridental.....	139 A	15.00	Lining for crank pin bearing with babbitt (2 pieces).....	2
Periderm.....	140 A	5.00	Cap for center crank bearing.....	5
Peridium.....	141 A	8.00	Cap for crank bearing, R. H. and L. H.....	5
Peridrome.....	142 A	15.00	Lining for center crank bearing with babbitt.....	2
Perigean.....	143 A	20.00	Lining for crank bearing with babbitt, R. H. and L. H.....	2
Perigone.....	144 A	3.00	Upper side plate for crank case, R. H.....	3
Peril.....	145 A	2.00	Lower side plate for crank case, R. H.....	3
Perilous.....	146 A	2.50	Side plate for crank case L. H.....	3
Perimeter.....	147 A	1.25	Crank shaft oil collar.....	3
Perimetry.....	148 A	12.00	Counter balance for crank shaft, prior to engine No. 627.....	6
Perimorph.....	A 148 A	12.00	Counter balance for crank shaft.....	6
Period.....	149 A	9.00	Intermediate cam gear.....	3
Periodic.....	150 A	11.00	Cam shaft gear.....	3
Peripatus.....	151 A	6.00	Bushing for intermediate gear fulcrum pin.....	3
Periplasm.....	A152 A	11.00	Center cam shaft bearing.....	4
Peripteral.....	153 A	3.50	Cap for center cam shaft bearing.....	3
Perique.....	154 A	.75	Guide for reverse lever quadrant catch.....	3
Perisperm.....	A155 A	.60	Shifting lever for cam roller.....	4
	156 A		Crank shaft oil ring with pad, see 08002A.....	3
	157 A		Crank shaft oil ring without pad, see 08002A.....	3
Peritroch.....	158 A	.50	Elbow for fuel pump.....	4
Perjure.....	159 A	.60	Lever for igniter quadrant.....	3
Perkin.....	161 A	1.50	Fork for igniter trip shaft.....	3
Perky.....	A162 A	2.00	Rocker arm for igniter trip shaft.....	3
Perlite.....	163 A	.75	Head for igniter pull rod.....	4
Permanence.....	164 A	2.00	Head for exhaust muffler (engine with single exhaust).....	2
Permanent.....	165 A	2.00	Guide for igniter rod.....	2
Permeable.....	166 A	.60	Igniter rod cushion plug.....	2
	167 A		Igniter frame, see 08019A1.....	3
Permeation.....	168 A	.50	Washer L. H. end of cam shaft.....	3
Permeative.....	168 A½	.50	Washer for oil pump eccentric.....	3
Permission.....	169 A	15.00	Governor gear.....	3
Permutable.....	171 A	5.00	Exhaust hole cover.....	3
Permutator.....	172 A	.10	Bevel channel washer, ½" hole.....	3
Permute.....	173 A	.10	Bevel channel washer, 16" hole.....	3
Pernicious.....	174 A	.65	Governor valve lever.....	4
Pernor.....	175 A	.40	Governor valve arm.....	3
Peroneal.....	176 A	1.50	Eccentric strap for oil pump.....	3

Give the NUMBER of your Tractor, and much Time and Expense will be saved.