



CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

J.I. Case
Operator's Manual

DI

purchase full manual at

Operator's Manual

JENSALES.COM

or Call 800-443-0625



CLICK ANYWHERE FOR MORE DETAILS

THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
J.I. CASE OR IT'S SUCCESSORS. J.I. CASE AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

CA-O-DI

Make: Ji Case	Model: D	Years Made: 1953-1953
HP-PTO: 35	HP-Engine:	HP-Drawbar: 31
HP-Range: 35	Engine-Make: CASE	Engine-Fuel: GAS
Engine-Cyl(s)-CID: 4/259.5	Transmission-STD: SG	Optional:
Fwd/Rev Standard: 4/1	Fwd/Rev Optional:	Mfwd-Std/Opt:
Tires-Std Front: 6.00-16	Tires-Std Rear: 12-26	Wheelbase-Inch:
Pto Type:	Pto Speed:	CAT I-3pt Hitch: False
CAT II-3pt Hitch: False	CAT III-3pt Hitch: False	Hitch Lift:
Hydraulics-Type:	Hyd-Cap:	Hyd-Flow:
Hyd Std Outlets:	Cooling Capacity:	Fuel Tank Capacity:
Cab-Std/A/C; Rops:	Weight: 4600	New Price: 2494

Make: Ji Case	Model: DC	Years Made: 1949-1955
HP-PTO: 37.28	HP-Engine:	HP-Drawbar: 33.0
HP-Range: 37	Engine-Make: CASE	Engine-Fuel: GAS
Engine-Cyl(s)-CID: 4/	Transmission-STD: SG	Optional:
Fwd/Rev Standard: 3/1	Fwd/Rev Optional:	Mfwd-Std/Opt:
Tires-Std Front: 6.00-16	Tires-Std Rear: 11-38	Wheelbase-Inch:
Pto Type:	Pto Speed:	CAT I-3pt Hitch: False
CAT II-3pt Hitch: False	CAT III-3pt Hitch: False	Hitch Lift:
Hydraulics-Type:	Hyd-Cap:	Hyd-Flow:
Hyd Std Outlets:	Cooling Capacity:	Fuel Tank Capacity:
Cab-Std/A/C; Rops:	Weight: 5300	New Price: 2633

Make: J.I. Case	Model: DO	Years Made: D Series
Factory: n/a	Chassis: n/a	Wheelbase: n/a
Front tire: n/a	Rear tire: n/a	Weight: n/a
Length: n/a	Width: n/a	Height: n/a
Elec. Grounding: n/a	Elec. Charging Amps: n/a	Elec. Volts: n/a
Hitch Rear Type: n/a	Hitch Rear Lift: n/a	Fuel Capacity: n/a
Hydraulics Type: n/a	Hydraulics Capacity: n/a	Hydraulics Pressure: n/a
Hydraulics Valves: n/a	Hydraulics Total Flow: n/a	Hydraulics Valve Flow: n/a
Steering: n/a	Brakes: n/a	New Price: n/a
Hyd Std Outlets:	Cooling Capacity:	Fuel Tank Capacity:
Cab-Std/A/C; Rops:	Weight: 2800	New Price: 1710

PLATE FASTENED TO INSTRUMENT PANEL for the D		
Year	Beginning Serial Number	
1938	4200001	
1939	4300001	
1940	4400001	
1941	4500001	
1942	4600001	
1943	4700001	
1944	4800001	
1945	4900001	
1946	5000001	
1947	5100001	
1948	5200001	
1949	5300001	
1950	5400001	
1951	5500001	
1952	5600001	
1953	5700001	

D: STANDARD-TREAD
DC: ROW CROP
DI: INDUSTRIAL
DO: ORCHARD

Paint Codes		
Location		MFG Color Name
RIMS		ALUMINUM
BODY		FLAMBEAU RED

JENSALES.COM

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

Operator's Instruction Book

INSTRUCTIONS FOR THE
OPERATION AND CARE
OF YOUR

CASE

MODEL "D" TRACTOR



Established
1842

JENSALLES.COM

or Call 800-443-0625

J. I. CASE CO.

RACINE - WISCONSIN - U. S. A.

Form 5298 1M

Second Edition

CLICK ANYWHERE FOR MORE DETAILS

CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

Model "DI" Tractor[®]

purchase full manual at

JENSALES.COM

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

SPECIFICATIONS

1

SAFETY

2

STARTING

3

OPERATING

4

LUBRICATION

5

SPARK PLUGS

6

FUELS

7

AIR CLEANER

8

INDEX

TO

OPERATING

INSTRUCTIONS

MANUAL PREVIEW

JENSALES®

purchase full manual at

JENSALES.COM

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

SPECIAL MESSAGE TO PURCHASERS OF NEW CASE MODEL "DI" SERIES TRACTORS

Your new Model "DI" Series tractor is as fine a machine as you can buy today. You have purchased it to reduce your production costs, and during the design and manufacture of this tractor, every effort has been made toward this end. With the tractor in your hands, our major responsibility necessarily must cease; how well the tractor serves your needs now depends on you.

If you will observe the few simple precautions described in this manual, your new CASE tractor will serve you well for many years to come. On the other hand, the best of care in design, selection of materials, and manufacture are of no avail in any machine if the purchaser neglects proper care and servicing.

Therefore, it is to your interest to understand your tractor and to learn its needs. Only in this way will you obtain the maximum service.

Read this instruction book—it has been made easy to read and to understand. Keep it handy for future reference when questions arise. A great majority of troubles developing in the field could be avoided by following the instructions given in the operator's instruction book.

When it becomes necessary to replace certain parts on your tractor after long service, be sure to use genuine CASE parts to insure proper fit and continued good service.

These parts can be secured from your nearest CASE dealer, who also has trained mechanics that can take care of any servicing your tractor may require.

When ordering replacement parts, be sure to give Model and serial number of your tractor in addition to the name (and part number if available) of the parts required.

JENSALES.COM
or Call 800-443-0625