



CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

J.I. Case

Parts Manual

W5A

Loader

S/N 8164260 & Up

JENSALES.COM

or Call **800-443-0625**

JENSALES

Parts Manual

CLICK ANYWHERE FOR MORE DETAILS

THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
J.I. CASE OR IT'S SUCCESSORS. J.I. CASE AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

CA-P-W5A

MODEL W5A LOADER

S/N 8164260 AND AFTER

Parts Catalog C1039

500 (Reprint) 8-76 PRINTED IN U.S.A.

Note: This catalog replaces the previous issues - 1039, A1039, B1039 - which are obsolete and should be discarded.

CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

JENSALES®

purchase full manual at

JENSALES.COM

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

ALPHABETICAL INDEX

ENGINE SECTION

CLICK ANYWHERE FOR MORE DETAILS

	DIESEL	GAS
AIR INTAKE & EXHAUST SECTION:		
AIR CLEANER	7,9	47
EXHAUST PIPE	7,9	47
HEATER, MANIFOLD	7,9	-
MANIFOLDS	7,9	47
MUFFLER	7,9	47
COOLING SECTION:		
RADIATOR	5	45
THERMOSTAT	5	45
WATER PUMP, BELT & FAN	5	45
ENGINE SECTION:		
CAMSHAFT & BUSHINGS	25	51
CONNECTING RODS & BRGS.	37	59
CRANKSHAFT & BRGS.	33	55
CYLINDER BLOCK	27-31	53
CYLINDER HEAD & COVER	21	49
CYLINDER SLEEVES	37	59
FLYWHEEL & HOUSING	33,109	55,109
GASKET KITS	39	65
GOVERNOR	-	61
HEATER, MANIFOLD	7,9	-
MOUNTS	109,143-147	109,143-147
OIL FILTER	35	57
OIL PAN	35	57
OIL PUMP	35	57
PISTONS AND RINGS	37	59
ROCKER ARMS & SHAFT	23,25	51
TIMING GEAR COVER	19	61
VALVE MECHANISM	23,25	51
WATER PUMP	5	45
FUEL SECTION:		
CARBURETOR	-	69,71
FUEL FILTER	17	-
FUEL INJECTION LINES	11,13	-
FUEL INJECTION PUMP	15	-
FUEL INJECTORS	11,13	-
FUEL STRAINER	-	41
FUEL TANK & LINES	41	41
THROTTLE & CONTROLS	17	63
LUBRICATION SECTION:		
OIL FILTER	35	57
OIL PAN	35	57
OIL PUMP	35	57

MANUAL PREVIEW

JENSALES[®]

purchase full manual at

JENSALES.COM

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

ALPHABETICAL INDEX

BASIC TRACTOR SECTION

AXLE SECTION:

DIFFERENTIAL	131,133
FRONT AXLE	123
HOUSING, FRONT AXLE	123
REAR AXLE	141
SPINDLES	141
TIE RODS	141

BRAKE SECTION:

BRAKE ASSY.	131,133
BRAKE CONTROLS	129
BRAKE PEDALS	129

CHASSIS SECTION:

BUCKETS, LOADER	177
CHASSIS	143-147
COUNTERWEIGHT	143-147
ENGINE MOUNTING	143-147
LIFT ARM	177
RAD. FRAME & GRILLE	143-149
SEAT, OPERATOR'S	151

ELECTRICAL SECTION:

ALTERNATOR	99-101
BATTERY & CABLES	77-85
DISTRIBUTOR	103-105
ELEC. EQUIP. & WIRING	77-85
ENG. TROUBLE IND. LAMP	87,89
FRONT & REAR LAMPS	87
GENERATOR	95,97
INSTRUMENT PANEL	73,75
LIGHTING EQUIPMENT	87
STARTER MOTOR	91,93
STOP & TAIL LAMP	87
WIRING - CHASSIS	77-85
WIRING - INSTRUMENTS	75

FORK LIFT SECTION:

FORK LIFT	179
-----------------	-----

HYDRAULIC SECTION:

CYLINDER, LIFT	175
CYLINDER, TILT	173
HOSES & LINES	157-161
HYD. CONTROLS	157
OIL FILTER	159,161
OIL RESERVOIR	159
PUMP, HYD.	155
VALVE, CONTROL	163-171

SHEET METAL SECTION:

DECALS	179
HOOD	149
PANEL, INSTRUMENT	73,75
PLATFORMS	151
RAD. FRAME & GRILLE	143-149
SIDE PANELS	149
TRAY, BATTERY	151

STEERING SECTION:

ARMS, STEERING	141
CYLINDER, STR.	137,139
HOSES & TUBES	137
PUMP, POWER STR.	137
STR. WHEEL & GEAR	135
TIE ROD	141

TRANSMISSION SECTION:

CLUTCH, FRWD. & REV.	119
CONVERTER COOLER HOSES	121
CONVERTER & TRANS.	111-127
COUNTERSHAFT, TRANS.	127
DIPSTICK, TRANS.	113,115
FILTER SCREEN, TRANS.	113,115
GASKETS, TRANS.	121
GEAR SHIFT	123
HOUSING, CONV.	111
MAIN SHAFT, TRANS.	127
MANUAL TRANS.	127
POWER SHUTTLE TRANS.	113,115
PUMP, CONVERTER	111
SHAFT, DRIVE	121
TORQUE CONV. ASSY.	111
TRANS. CASE & COVERS	125
TRANS. MOUNTS	113,115
VALVE CONTROLS, CONV.	107
VALVE, CONV. CONTROL	117

WHEEL SECTION:

FRONT WHEELS	153
REAR WHEELS	153

or call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

CLICK ANYWHERE FOR MORE DETAILS



(188) DIESEL ENGINE
ENGINE COOLING SYSTEM

REF.	PART NO.	DESCRIPTION	REQ'D
1 A	15678	RADIATOR - engine coolant	1
2 A	22943	SHROUD - radiator fan	1
3 A	21389	CAP - pressure, radiator (7 lbs.)	1
4	214- 260	CLAMP - hose, 1-3/16" to 2-3/4"	1
5 A	15642	HOSE - radiator, upper	1
6	214- 256	CLAMP - hose, 1-3/16" to 1-3/4"	1
7 A	16419	HOSE - outlet, radiator	1
8	214- 258	CLAMP - hose, 1-5/16 x 2-1/4"	2
9 A	27862	VALVE - drain, radiator	1
10 A	15639	SUPPORT - mtg., radiator L.H. & R.H.	2
11	14- 510	BOLT - 5/16 x 5/8" N.F. hex.	6
12	92- 5	WASHER - lock, 5/16"	6
13	14- 620	BOLT - 3/8 x 1-1/4" N.F. hex.	4
14	92- 6	WASHER - lock, 3/8"	4
15 G	2144	HOUSING - outlet and thermostat	1
16 G	46907	GASKET - hsg., outlet & thermostat	1
17	13- 616	BOLT - 3/8 x 1" N.C. hex.	2
18	92- 6	WASHER - lock, 3/8"	2
19 G	45788	THERMOSTAT - used w/bolt-on housing	1
20 G	37088	THERMOSTAT - used w/out bolt-on housing	1
21 G	49625	SLEEVE - for use w/G37088 thermostat	1
22 A	15480	FAN - radiator, pusher type	1
23 A	15478	FAN - radiator, suction type	1
24	13- 512	BOLT - 5/16 x 3/4" N.C. hex.	4
25	92- 5	WASHER - lock, 5/16"	10
26 G	46238	BELT - fan	1
27 G	11339	PULLEY - fan and water pump	1
28 G	11939	PUMP ASSY. - water	1
29 A	30067	RING - retainer	1
30 G	46875	GASKET - mtg., water pump	1
31	13- 644	BOLT - 3/8 x 2-3/4" N.C. hex.	1
32	13- 612	BOLT - 3/8 x 3/4" N.C. hex.	2
33	193- 46	WASHER - Shakeproof, 3/8" int.	3
34 A	29433	STUD - mtg., water pump, 3/8" N.C. x 1-1/8"	1
35	25- 106	NUT - 3/8" N.C. hex.	1

JENSALES.COM

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS