



CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

J.I. Case

Parts Manual

W7C

Wheel Loader

Parts Manual

JENSALES.COM
or Call 800-443-0625

JENSALES

CLICK ANYWHERE FOR MORE DETAILS

THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
J.I. CASE OR IT'S SUCCESSORS. **J.I. CASE** AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

CA-P-W7C

W7C LOADER


Parts Catalog A1114

NOTE: Discard parts catalog 1114

CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

JENSALES®



purchase full manual at

JENSALES.COM






or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

Printed in U.S.A.

**MODEL W7C LOADER
SERIAL NUMBER LOCATION**

CLICK ANYWHERE FOR MORE DETAILS



JENSALES.COM

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

MODEL W7C LOADER

ALPHABETICAL INDEX

- ENGINE SECTION -

CLICK ANYWHERE FOR MORE DETAILS

A

Air Cleaners - engine, diesel	83
Air Cleaners - engine, gasoline	85
Alternator - electrical	77

B

Balancer - engine, diesel	21
Balancer - engine, gasoline	43
Belt - drive, fan and alternator	55,59
Block - cylinder, diesel	15
Block - cylinder, gasoline	37

C

Camshaft - engine, diesel	13
Camshaft - engine, gasoline	35
Carburetor - engine, gasoline	51
Coil - electrical, gasoline engine	81
Crankshaft - engine, diesel	17
Crankshaft - engine, gasoline	39

D

Distributor - electrical, gasoline engine	79,81
Dipstick - engine oil, diesel	15
Dipstick - engine oil, gasoline	37

E

Electrical System - diesel	55,57,63
Electrical System - gasoline	59-63,81

F

Fan - engine cooling	7
Filter - engine oil, diesel	23
Filter - engine oil, gasoline	45
Filter - fuel, diesel	29
Flywheel - engine, diesel	17
Flywheel - engine, gasoline	39
Fuel Tanks - engine	137

G

Gasket Kits - engine, diesel	25
Gasket Kits - engine, gasoline	47
Gauges - instrument panel	65
Governor - engine, gasoline	49

H

Head - cylinder, diesel	11
Head - cylinder, gasoline	33

I

Ignition System - engine, gasoline	81
Index - basic tractor	3
Index - loader	4,5
Index - numerical	236-257
Injection System - fuel, diesel	27
Injection - fuel, diesel	27

K

Kits - piston and sleeve, diesel engine	19
Kits - piston and sleeve, gasoline engine	41

L

Linkage - throttle control, diesel	89
Linkage - throttle control, gasoline	91

M

Manifold - exhaust	9
Manifold - intake	9
Manifold - water	7
Muffler - exhaust	87

P

Pan - engine oil, diesel	23
Pan - engine oil, gasoline	45
Panel - instrument	65
Pistons - engine, diesel	19
Pistons - engine, gasoline	41
Pump - fuel injection, diesel	31
Pump - engine oil, diesel	21
Pump - engine oil, gasoline	43
Pump - water	7

R

Radiator - engine cooling	125
Rings - piston, diesel	19
Rings - piston, gasoline	41
Rocker Arm - engine, diesel	13
Rocker Arm - engine, gasoline	35
Rod - connecting, diesel	19
Rod - connecting, gasoline	41
Rod - push, diesel	13
Rod - push, gasoline	35
Rotor - distributor, gasoline engine	79

S

Sleeve - engine, diesel	19
Sleeve - engine, gasoline	41
Spark Plug - ignition, gasoline engine	81
Starter - engine, diesel	71
Starter - engine, gasoline	75

T

Thermostat - coolant temperature	7
Timing Gear Cover - engine, diesel	15
Timing Gear Cover - engine, gasoline	37

V

Valve Cover - engine, diesel	11
Valve Cover - engine, gasoline	33
Valve Guides - engine, diesel	13
Valve Guides - engine, gasoline	35
Valves - engine, diesel	13
Valves - engine, gasoline	35
Ventilation - crankcase	53

MODEL W7C LOADER ALPHABETICAL INDEX

3

A

Accumulator - hydraulic	223
Alternator - electrical	77
Axle - rigid, front	167, 173-177
Axle - steering, rear	169-177

B

Batteries - electrical	63
Battery Cables - electrical	63
Brake - parking, transmission	153
Brake Controls - foot	103
Brake Controls - parking	123
Brake System - Hydrovac, diesel	109
Brake System - Hydrovac, gasoline	113

C

Cab - operator	227
Chassis - tractor	131
Cleaner - air, Hydrovac	121
Clutch - high gear, transmission	153
Clutches - forward, reverse and low gear, transmission	151
Clutch Control - brake	103
Converter - torque	159
Cooling System - converter and transmission	145
Counterweights - rear	131
Cylinder - Hydrovac	117
Cylinder - master, brake	115
Cylinder - wheel, brake	115

D

Decals - tractor	237
Differential - tractor	173
Drive Shafts - transmission and axle	179
Drum - brake	177

E

Electrical System - cab	229
Electrical System - tractor, diesel	55
Electrical System - tractor, gasoline	59

F

Fenders - tractor	135
Filter - air, Hydrovac	121
Filter - converter oil	147
Filter - hydraulic oil	139
Floor Plates - tractor	129

G

Gauges - instrument panel	65
Grill - radiator guard	125

H

Heater - cab	231
Horn - tractor	69
Hood - engine	127
Hydraulics - power steering	97

I

Index - engine	2
Index - loader	4,5
Index - numerical	236-257
Instrument Panel - tractor	65

Printed in U.S.A.

L

Lever - fuel shut-off, diesel	89
Lights - dash	69
Lights - front and rear	69
Lights - stop	69
Lights - turn signal	233,235
Linkage - steering	95

M

Mounts - engine	133
Muffler - exhaust	87

P

Panel - instrument	65
Panels - engine side	127
Pedal - throttle control	89,91
Pedals - brake, Hydrovac	103
Plates - floor	129
Platform - operator compartment	129
Pump - charging, torque converter	163
Pump - power steering	101
Pump - vacuum, Hydrovac	121

R

Radiator - engine cooling	125
Reservoir - power steering	101

S

Seat - operator	129
Shaft - input, transmission	151
Shaft - output, transmission	155
Shift Controls - transmission	141
Shift-Out - rear axle	155
Shutter - radiator	125
Side Panels - engine	127
Starter - electrical, diesel	71
Starter - electrical, gasoline	75
Steering Cylinder - hydraulic	99
Steering Gear - tractor	93
Steering Hydraulics - tractor	97
Steering Wheel - tractor	95

T

Tank - fuel	137
Tank - hydraulic oil	139
Tank - reserve, Hydrovac	111,113
Transmission Controls - tractor	141

U

Universal Joints - drive shaft	179
--------------------------------	-----

V

Valve - accumulator	225
Valve - check, Hydrovac	121
Valve - clutch control	123
Valve - control, transmission	157
Valve - power steering cylinder	99
Valve - regulating, torque converter	165

W

Wheels - drive	177
----------------	-----

CLICK ANYWHERE FOR MORE DETAILS

CONTROL VALVE AND LEVERS - 203-205

CHASSIS MOUNTING FRAME - 131

RETURN TO DIG PARTS - 191

TILT CYLINDER - 219

TILT CYLINDER HYDRAULICS - 199

DECALS - 237

BUCKETS - 185,187

LOADER LIFT FRAME - 181

LIFT CYLINDER HYDRAULICS - 197

LIFT CYLINDER - 217

JENSALES.COM

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

MODEL W7C LOADER

5

ALPHABETICAL INDEX

LOADER SECTION

B
Bucket Control Levers - loader 203,203B
Bucket Teeth - loader 185,187
Bucket - loader, Drott 4-In-1 187
Buckets - loader 185

I
Index - basic tractor 3
Index - engine 2
Index - numerical 236-257

C
Controls - loader, Drott clam 203B
Controls - loader, lift and tilt 203,203B
Controls - loader, return-to-dig 191
Cylinder - loader, Drott clam 221
Cylinder - loader, lift 217
Cylinder - loader, tilt 219

D
Decals - loader 237

F
Fork Lift - loader 193
Frame - loader, lift 181
Frame - loader mounting, chassis 131

H
Hydraulics - loader, lift cylinder 197
Hydraulics - loader, pump suction and
pressure line 195
Hydraulics - loader, tilt cylinder 199

L
Levers - loader, control 203,203B
Lift Cylinder - loader 217

P
Pump - equipment, hydraulic 215

R
Return To Dig - loader 191

V
Valve - check, loader 213
Valve - main relief, loader 213
Valve - relief, Drott 189
Valve Spools - loader control 207-211
Valves - loader control 205

JENSALES.COM
or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

CLICK ANYWHERE FOR MORE DETAILS