



CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

Ford

Parts Manual

**Fordson Dexta &
Fordson Super Dexta**

Parts Manual

JENSALES.COM

or Call **800-443-0625**



CLICK ANYWHERE FOR MORE DETAILS

THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
FORD OR IT'S SUCCESSORS. **FORD** AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

FO-P-DEXTA

Serial Number Information for Fordson Dexta

Serial Number:	Year Made:	Plate Location:
957E 1	1957	Lip of bell flange between engine and clutch, left side of tractor
957E 144	1958	Lip of bell flange between engine and clutch, left side of tractor
957E 22558	1959	Lip of bell flange between engine and clutch, left side of tractor
957E 44432	1960	Lip of bell flange between engine and clutch, left side of tractor
957E 71921	1961	Lip of bell flange between engine and clutch, left side of tractor
09B 702592	1962	Lip of bell flange between engine and clutch, left side of tractor
09C 932031	1963	Lip of bell flange between engine and clutch, left side of tractor
09D 907332	1964	Lip of bell flange between engine and clutch, left side of tractor
09D 928248	Final	Lip of bell flange between engine and clutch, left side of tractor

Serial Number Information for Fordson Super Dexta

Serial Number:	Year Made:	Plate Location:
09A 312001M	1961	Lip of flange connecting engine and clutch, left side of tractor
09B 070000A	1962	Lip of flange connecting engine and clutch, left side of tractor
09C 731454A	1963	Lip of flange connecting engine and clutch, left side of tractor
09D 9000000A	1964	Lip of flange connecting engine and clutch, left side of tractor

The gasoline version of the Dexta was produced in much smaller numbers than the diesel version. The Dexta was sold in the United States as the Diesel 2000. A narrow model (52-inch width) as well as an industrial model, and a Dexta Special (Germany) were made.

CLICK ANYWHERE FOR MORE DETAILS

PARTS LIST

with illustrations for the

FORDSON DEXTA AND SUPER DEXTA

1957/64

purchase full manual at

JENS



ES.COM

or Call 800-443-0625

Ford policy is one of continuous improvement, the right to change prices, specifications
and equipment at any time without notice is reserved.

CLICK ANYWHERE FOR MORE DETAILS

FORD TRACTOR DIVISION

FORD MOTOR COMPANY

CLICK ANYWHERE FOR MORE DETAILS

CONTENTS OF PARTS LIST

1. Printed Index
2. Pictorial Index
3. Illustrations and text of detail parts.

INSTRUCTIONS FOR ORDERING

Refer to:—

1. Pictorial/Printed Index and select page number of illustration and/or text of assembly or system required.
2. Illustration (if shown) and select basic part number of item required.
3. Parts List for correct part number including prefix and suffix.

Note:— Items on pages 14 to 137 are listed in basic part number sequence when shown in the outset position unless otherwise stated.
Non-basic numbers, e.g., E30-CA-9 are shown in part number sequence in index pages 10 to 13.

EXPLANATORY NOTES

YEAR RANGES:

- (i) Where a part has been used from the commencement of production or some later date the month and year of introduction is shown to the left of an oblique stroke thus:—
11/57/ indicates part introduced in November 1957.
- (ii) Where a part is introduced, used for a period, then discontinued the year range is shown thus:—
11/60/62/4 indicates part introduced in November 1960 and discontinued as from April 1962.

SOMMAIRE DU CATALOGUE DE PIÈCES

1. Index imprimé
2. Index illustré
3. Illustrations et texte des pièces détaillées

INSTRUCTIONS POUR PASSER LES COMMANDES

Se référer à:—

1. l'index illustré/imprimé et noter le numéro de la page of l'illustration et/ou du texte de l'ensemble ou du système requis.
2. à l'illustration (si représentée) et noter le numéro de pièce de base de la pièce requise.
3. au catalogue de pièces pour le numéro de pièce correct, préfixe et suffixe y compris.

Remarque: Les articles des pages 14 à 137 sont énumérés dans l'ordre de pièce de base lorsqu'ils figurent à la position extérieure, à moins d'indication contraire.

Les numéros qui ne sont pas des numéros de base, par ex. E30-CA-9 sont indiqués dans l'ordre des numéros de pièces aux index des pages 10 à 13.

REMARQUES EXPLICATIVES

ANNÉES:

- (i) Lorsqu'une pièce a été employée depuis le commencement de la production ou à une date ultérieure, le mois et l'année d'introduction sont indiqués à la gauche d'une barre oblique, ainsi:—
11/57/ indique que la pièce a été introduite en Novembre 1957.

- (ii) Lorsqu'une pièce est introduite, utilisée pendant un certain temps, puis n'est plus employée, l'année est indiquée de la manière suivante:—
11/60/62/4, ce qui indique que la pièce a été introduite en Novembre 1960 et n'est plus utilisée depuis Avril 1962.

CLICK ANYWHERE FOR MORE DETAILS

CLICK ANYWHERE FOR MORE DETAILS

INDEX TO PARTS LIST


	page		page
ACCESSORIES	133	INSTRUMENT BOX	117
AIR CLEANER	107	KITS AND MISCELLANEA	132
AUTOMATIC HITCH	52	MANIFOLDS	94
AXLE—FRONT	43	MUDGUARDS (FENDERS)	125
AXLE—REAR	47	MISCELLANEOUS	134
BATTERY CLAMP	56	MISCELLANEOUS NON-BASIC NUMBERS	10
BONNET (HOOD)	127	POWER TAKE-OFF	75
BRAKES	36	PULLEY	78
BRAKES—DUAL REAR WHEEL	40	SEAT	14
CLUTCH	80	SILENCER (MUFFLER)	56
COOLING SYSTEM	85	STANDARD PARTS	138
DRAWBAR	53,57	STEERING GEAR	46
ELECTRICAL SYSTEM	109	TACHOMETER	128
ENGINE	58	THROTTLE CONTROLS	107
ENGINE OIL FILTER	68,131	TOOLS AND STARTING HANDLE	128
FUEL INJECTION EQUIPMENT	99	TRANSMISSION—FRONT	71
FUEL SYSTEM	86	TRANSMISSION—REAR	47
GEARBOX	71	WHEELS	34
HYDRAULIC POWER LIFT	14		

INDEX DE CATALOGUE DE PIÈCES

	page		page
ACCESSOIRES	133	MÉCANISME DE DIRECTION	46
ATTACHE DE BATTERIE	56	MOTEUR	58
BARRE D'ATTELAGE	53,57	OUTILS ET MANIVELLE DE DÉMARRAGE	107
BOITE D'INSTRUMENTS	117	PIÈCES STANDARD	138
BOITE DE VITESSES	71	PONT ARRIÈRE	47
CAPOT	127	POULIE	78
COMMANDES D'ACCÉLÉRATEUR	107	PRISE DE FORCE	75
DISPOSITIF D'ATTELAGE AUTOMATIQUE	52	RELEVAGE HYDRAULIQUE	14
DIVERS	134	ROUES	34
DIVERS—NUMÉROS QUI NE SONT PAS LES		SIÈGE	14
NUMÉROS DE BASE	10	SILENCIEUX	56
EMBRAYAGE	80	SYSTÈME D'ALIMENTATION	88
EPURATEUR D'AIR	107	SYSTÈME DE FROIDISSEMENT	85
EQUIPEMENT D'INJECTION	99	SYSTÈME ÉLECTRIQUE	109
ESSIEU AVANT	43	TACHYMÈTRE	128
FILTER À HUILE DE MOTEUR	68,131	TRANSMISSION—ARRIÈRE	47
FREINS	36	TRANSMISSION—AVANT	71
FRIENS—ROUES ARRIÈRE JUMELÉES	40	TROUSSES ET DIVERS	132
GARDE-BOUE	125	TUBULURES	94

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS



Illus. No.	Part No.	Name of Part	% Scale	Year Range	Remarks	Qty. Req.
------------	----------	--------------	---------	------------	---------	-----------

HYDRAULIC POWER LIFT-continued

H.P.L. LINK STABILISER

AC	E38-WP-9	Kit (H.P.L. stabiliser)		11/57/		1
AC	E133-WP-9	Bar (H.P.L. link stabiliser) assy.	2	11/57/		2
AC	E52-WP-9	Bracket (H.P.L. link stabiliser)-R.H.		11/57/		1
AC	115735-ES	Bolt (bracket to rear axle housing)		11/57/		2
AC	E53-WP-9	Bracket (H.P.L. link stabiliser)-L.H.		11/57/		1
AC	115735-ES	Bolt (bracket to rear axle housing)		11/57/		2
AC	C5NN-A889-A	Pivot pin (H. P. L. linkage stabiliser)	2	11/57/	Replaces E54-WP-9	2
AC	33850-S2	Nut (pivot pin to bracket)		11/57/		2
AC	34811-S7/8	Lockwasher		11/57/		2
AC	E27N-995217	Linch pin (H.P.L. linkage stabiliser)	100	11/57/		2
AC	E27N-995279	Ring (H.P.L. linkage stabiliser linch pin)	100	11/57/		2
AC	E97-QF-9	Chain (H.P.L. linkage stabiliser linch pin to bracket)		11/57/		2
AC	72019-S8	Split pin (H.P.L. chain anchor)		11/57/		2

STANDARD PARTS—continued

Part No.	Name of Part	Part No.	Name of Part
117812-ESA	clip	119758-ES	$\frac{7}{8}$ "—18 plug
117818-ES	$\frac{17}{32}$ " x $\frac{1}{2}$ " wire cable clip	119785-ES	$\frac{5}{8}$ " expansion plug
118105-ES	No. 2 B.A. flat washer	119786-ES	1.07" dia. expansion plug
118135-ES	.205" I.D. x .75" O.D. x .195" flat washer	119811-ES	$\frac{3}{16}$ " dia. ball
118140-ES	$\frac{1}{4}$ " insulated washer	119928-ES	$\frac{5}{32}$ " x $\frac{17}{32}$ " flat head rivet—copper
118141-ES	$\frac{17}{64}$ " I.D. washer—double tab	119930-ES	.15" x .718" special tubular rivet
118150-ES	.257" I.D. x $\frac{3}{8}$ " O.D. flat washer—special	119933-ES	$\frac{1}{8}$ " clip pin
118154-ES	$\frac{1}{4}$ " I.D. x $\frac{3}{8}$ " O.D. fibre washer—special	119946-ES	$\frac{1}{8}$ " x $1\frac{1}{4}$ " groove pin
118165-ES7/8	$\frac{17}{64}$ " lockwasher	119976-ES7/8	$\frac{5}{32}$ " x $\frac{5}{8}$ " pin
118176-ES8	$\frac{3}{16}$ " washer ribbed	119975-ES7/8	$\frac{3}{8}$ " x $\frac{3}{4}$ " pin
118189-ES	$\frac{3}{8}$ " I.D. x $\frac{23}{32}$ " O.D. x $\frac{1}{64}$ " flat washer	119984-ES	$\frac{3}{16}$ " ferrule
118190-ES	$\frac{3}{8}$ " I.D. x $\frac{3}{4}$ " O.D. x $\frac{1}{64}$ " lockwasher	119987-ES	$\frac{1}{4}$ " ferrule
118194-ES	$\frac{15}{64}$ " I.D. x $\frac{1}{16}$ " O.D. x $\frac{1}{32}$ " flat washer	119990-ES	Ferrule
118199-ES7	.260" I.D. x .460" O.D. x .021" countersunk washer	119993-ES	Ferrule
118203-ES2	No. 2 B.A. shakeproof washer—internal teeth	304702-S	$\frac{5}{16}$ "—24 x $1\frac{1}{2}$ " hex. head bolt
118228-ES	$\frac{1}{2}$ " flat washer special	305026-S	$\frac{3}{32}$ " x $\frac{1}{2}$ " spring pin
118257-ES	$\frac{3}{8}$ " I.D. x $1\frac{1}{8}$ " O.D. x $\frac{1}{2}$ " flat washer	305039-S7/8	$\frac{1}{4}$ " x $\frac{3}{8}$ " spring tension pin
118290-ES7/8	$\frac{25}{64}$ " I.D. x $\frac{5}{8}$ " O.D. washer—waved	305041-S7/8	$\frac{1}{8}$ " x $\frac{5}{8}$ " spring pin
118318-ES	$\frac{23}{64}$ " I.D. x 1.62" O.D. x .1675" flat washer	305084-ES	$\frac{1}{8}$ " x $1\frac{1}{8}$ " spring tension pin
118319-ES	$1\frac{1}{8}$ " I.D. x $1\frac{1}{2}$ " O.D. x $\frac{1}{16}$ " flat washer	305086-S	$\frac{3}{16}$ " x $1\frac{1}{2}$ " spring tension pin
118321-ES100	1.035" I.D. x 1.906" O.D. x .064" thick flat washer	350433-S	$\frac{5}{16}$ "—18 x $\frac{23}{32}$ " special shoulder hex. head bolt
118322-ES	$\frac{25}{64}$ " I.D. x 1" O.D. x $\frac{1}{32}$ " flat washer	350439-S	$\frac{5}{16}$ "—24 x $\frac{5}{16}$ "
118346-ES	$\frac{15}{64}$ " I.D. x $1\frac{1}{16}$ " O.D. x $\frac{3}{64}$ " flat washer	350476-S2	$\frac{5}{16}$ "—24 x $\frac{1}{4}$ " carriage bolt
118352-ES	$\frac{15}{64}$ " I.D. washer tab—special	350890-S	$\frac{1}{4}$ "—28 special wing nut
118354-ES	$\frac{23}{64}$ " I.D. x $\frac{5}{8}$ " O.D. x $\frac{1}{16}$ " flat washer	350947-S8	$\frac{3}{16}$ "—24 hex. head nut
118355-ES	$\frac{11}{32}$ " I.D. x $\frac{17}{64}$ " O.D. x $\frac{1}{16}$ " flat washer	351047-S	$\frac{7}{16}$ "—20 special hex. lock nut
118356-ES	$\frac{11}{32}$ " I.D. x $\frac{23}{32}$ " O.D. x $\frac{3}{64}$ " flat washer	351052-S7	$\frac{1}{2}$ "—20 thin—hex. nut
118357-ES	$\frac{11}{32}$ " I.D. x $\frac{1}{2}$ " O.D. x $\frac{1}{32}$ " flat washer	351090-ES8	$\frac{7}{16}$ "—20 hex. nut—nyloc
118358-ES	$\frac{3}{16}$ " I.D. x $\frac{11}{16}$ " O.D. x $\frac{1}{16}$ " flat washer	351129-S	$\frac{3}{4}$ "—16 slotted hex. nut
118364-ES	$\frac{25}{64}$ " I.D. x $\frac{11}{16}$ " O.D. x $\frac{1}{16}$ " flat washer	351153-ES	$\frac{7}{8}$ "—14 special hex. nut
118366-ES	$\frac{11}{32}$ " I.D. x $\frac{1}{2}$ " O.D. x $\frac{1}{16}$ " flat washer—leather—special	351385-S	$\frac{3}{16}$ " I.D. x $\frac{3}{4}$ " O.D. x $\frac{1}{32}$ " flat washer
118511-ES2	.38 O.D. pipe clip	351428-S8	$\frac{7}{16}$ " I.D. x $\frac{23}{32}$ " O.D. x $\frac{1}{16}$ " flat washer
118521-ES2	$\frac{1}{2}$ " and $\frac{1}{4}$ " dual pipe clip	351436-ES	$\frac{7}{16}$ " special spring lockwasher
118537-ES	Clip	351452-S7	$\frac{1}{2}$ " I.D. x $\frac{23}{32}$ " O.D. x $\frac{1}{16}$ " light lockwasher
118545-ES	.45" dia. hole, 2.12" long conduit clip	351502-S	$\frac{5}{8}$ " x 1" special flat washer
118550-ES	.41" dia. hole, 1 $\frac{1}{2}$ " long wiring clip	351505-ES	$\frac{5}{8}$ " I.D. x $1\frac{1}{4}$ " O.D. x $\frac{1}{2}$ " flat washer
118656-ES7/8	No. 2 B.A. x $\frac{5}{16}$ " headless set screw	351963-S	$\frac{3}{16}$ " x .94" oval countersunk head rivet
118667-ES7	No. 2 B.A. x $\frac{11}{16}$ " special cheese head screw	352594-ES	$\frac{3}{8}$ " x $1\frac{1}{16}$ " clevis pin
118767-ES	$\frac{1}{4}$ " B.S.F. x $\frac{11}{32}$ " special headless set screw	352625-S7/8	$\frac{3}{4}$ " x $3\frac{3}{4}$ " clevis pin
118850-ES	$\frac{1}{2}$ "—18 x 3" special square head bolt	352648-ES	$\frac{1}{4}$ " x .58" straight pin—end drilled
118861-ES	$\frac{1}{8}$ "—16 x $1\frac{1}{32}$ " recessed head screw	353026-ES7	$\frac{3}{16}$ " lubricator
118876-ES	$\frac{5}{8}$ " B.S.F. x $3\frac{7}{8}$ " hex. head bolt	353043-ES7/8-8	$\frac{1}{4}$ "—28 lubricator—check valve type—short
118899-ES	$\frac{5}{8}$ "—18 x 3 $\frac{1}{2}$ " hex. head bolt	353051-ES	$\frac{3}{4}$ " extended square head plug
118930-ES8	$\frac{5}{8}$ "—18 x 5.23" special carriage bolt	353043/S7-A2	$\frac{1}{4}$ "—20 lubricator
118992-ES	$\frac{1}{2}$ "—13 x $1\frac{1}{16}$ " special hex. head bolt	353055-S	$\frac{1}{4}$ "—18 extended head plug
119203-ES	No. 8—32 hex. nut	353075-S	$\frac{3}{8}$ " steel ball
119258-ES	$\frac{7}{16}$ " x $\frac{1}{16}$ " brass washer	353080-S	$\frac{3}{16}$ " steel ball
119265-ES7	$\frac{1}{4}$ " I.D. x $\frac{23}{32}$ " O.D. x $\frac{1}{4}$ " flat washer	353753-S	$\frac{1}{8}$ " x $\frac{1}{4}$ " rolled pin
119270-ES	$\frac{5}{8}$ " O.D. x $\frac{25}{16}$ " I.D. x $\frac{1}{16}$ " tick, flat washer	354069-S	$\frac{7}{16}$ " steel ball
119290-ES	$\frac{3}{8}$ " washer—flat	354288-S	$\frac{7}{16}$ "—14 x $3\frac{1}{4}$ " hex. head bolt
119425-ES	$\frac{5}{32}$ " x $\frac{3}{32}$ " flat countersunk head semi-tubular rivet	354502-ES	.223"/.229" retainer
119473-ES	$\frac{5}{32}$ " x 1" oval head semi-tubular rivet	354518-ES	$\frac{5}{16}$ "—24 x .72 special thread hex. head screw
119572-ES	$\frac{3}{16}$ "—24 slow speed nut	354519-ES18	$\frac{1}{4}$ " x 1" straight pin
119699-ES	$\frac{1}{4}$ " insulated washer	354550-ES	$\frac{5}{16}$ "—18 x .72" hex. head bolt
		354606-S	$\frac{7}{16}$ "—14 x $2\frac{1}{4}$ " hex. head bolt
		354607-S	$\frac{7}{16}$ "—14 x $2\frac{1}{4}$ " hex. head bolt
		357344-S	$\frac{5}{16}$ "—24 carriage head bolt

STANDARD PARTS - continued

Part No.	Name of Part	
357724-ES8	$\frac{1}{4}$ " - 14, $\frac{1}{4}$ " - 20 x 1.86" stud	995928-ES7/8 No. 10 - 23 x $\frac{1}{4}$ " round head screw
374863-S	$\frac{1}{4}$ " flat washer	995953-ES7/8 No. 2 B. A. x $\frac{1}{4}$ " cheese head screw
374864-S	$\frac{1}{4}$ " flat washer	995957-ES8 No. 4 B. A. x $\frac{1}{4}$ " cheese head screw
374865-S	$\frac{1}{4}$ " flat washer	996291-ES7/8 $\frac{1}{4}$ " B. S. F. hex. nut
374866-S	$\frac{1}{4}$ " retaining ring	996202-ES-B No. 2 B. A. x $\frac{1}{4}$ " hex. nut
374897-S	$\frac{1}{4}$ " flat washer	996412-ES $\frac{1}{4}$ " B. S. F. flat washer
995901-ES7	No. 2 B. A. x $\frac{1}{4}$ " hex. head screw	996414-ES $\frac{1}{2}$ " B. S. F. flat washer
		996417-ES2 $\frac{1}{4}$ " lockwasher

JENSALES®

purchase full manual at

JENSALES.COM
or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS