

John Deere


CLICK ANYWHERE FOR MORE DETAILS

MODEL:

4040 Tractor

MANUAL PREVIEW

**PARTS
MANUAL**



JENSALES.COM
or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
JOHN DEERE OR IT'S SUCCESSORS. **JOHN DEERE** AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

JD-P-PC1610

CLICK ANYWHERE FOR MORE DETAILS

**4040
Tractor**

MANUAL PREVIEW

**PARTS
CATALOG**

purchase full manual at

JENSALES.COM
or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

Waterloo Tractor Works

PC-1610

LITHO IN U.S.A. (R) NEW



Specifications and design subject to change without notice.

BOLT AND CAP SCREW STRENGTH IDENTIFICATION

Bolts and cap screws required to have high-strength qualities equivalent to SAE Grade 8 are identified throughout this catalog by the description HS SAE 8. Unless identified by this description all standard bolts and cap screws are SAE Grade 5.

COMPLETE GOODS LISTINGS

Complete goods are listed in bold face type. Order separately. Do not include on replacement part order.

AN EXPLANATION OF CHANGE INDICATOR LINE

New and revised information is identified by vertical lines marked in the left-hand margin of revised pages. These lines indicate changes affecting the ordering of parts.

SI (International System) UNITS OF MEASURE

Metric equivalents have been included, where applicable, throughout this parts catalog.

JENSALES.COM
or Call 800-443-0625

SERIAL NUMBER COLUMN

Serial number information given on any page is applicable only to parts listed and illustrated on that page.

When the parentheses include only the dash (-)
the part is used on all tractors.

When a serial number appears before the dash (000000-)
the part was introduced beginning with that serial
number and is still being used.

When a serial number appears after the dash (-000000)
the part was used up to and including that serial num-
ber but was not used after that serial number.

When serial numbers appear both before and after the dash (000000-000000)
the part was used beginning with the first serial num-
ber but was not used after the second serial number.

When a serial number contains xxxxxx before the dash (xxxxxx-)
the part was approved for production but the beginning
serial number was not established when this catalog went
to press.

When a serial number contains xxxxxx after the dash (-xxxxxx)
the part is discontinued but the last serial number was
not established when this catalog went to press.

When a model number begins with 14HA, 12BV, 11DL,
4PP, 1DC, 23SC, 24SC, 1RC, 3RC, 11RS or 14SV (14HA1-)
it refers to the model number of accumulator, brake
valve, differential lock valve, hydraulic pumps, power
weight transfer control valve, remote cylinder selective
control valve—single-dual-triple, remote cylinders,
remote cylinders with mechanical stops, rockshaft
control valve or steering valve.

JENSALES.COM

or Call 800-443-0625

SECTIONAL INDEX

General	10-1 to 10-
Engine	20-1 to 20-
Fuel and Air	30-1 to 30-
Electrical	40-1 to 40-
Power Train	50-1 to 50-
Steering and Brakes	60-1 to 60-
Hydraulics	70-1 to 70-
Wheels, Front Axles, Sheet Metal	80-1 to 80-
Operator's Station	90-1 to 90-

MANUAL PREVIEW

JENSALES®

purchase full manual at

JENSALES.COM
or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

10-7

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
1D10	CABLES, BATTERY	40-8	2J18	CONTROL SUPPORT	90-60
1A22	CAM FOLLOWERS	20-3	2H17	CONTROL SUPPORT BRACKET	90-16
1B1	CAMSHAFT	20-4	2J19	CONTROL SUPPORT INSULATION	90-61
1B1	CAMSHAFT GEAR	20-4	1G20	CONTROL VALVE (QRT)	50-18
2H16	CANOPY	90-15	1K7	CONTROL VALVE BRACKET (PFWD)	50-90
1C4	CAP, AIR STACK	30-2	1K10	CONTROL VALVE OVERHAUL KIT (PFWD)	50-93
1B8	CAP, CRANKCASE	20-11	1K8	CONTROL VALVE PARTS (PFWD)	50-91
1C8	CAP, FUEL FILLER	30-6	1J5	CONTROL VALVES, TRANSMISSION	50-67
1K6	CARRIER, FIRST PLANET PINION (PFWD)	50-89	1C21	CONTROL, FOOT SPEED	30-19
1G19	CARRIER, PLANET PINION	50-16	2D15	CONTROL, LOAD	70-35
1I12	CARRIER, PLANET PINION	50-53	2D16	CONTROL, LOAD	70-36
1J21	CARRIER, PLANET PINION	50-83	2D12	CONTROL, LOAD SELECTOR	70-32
1H1	CARRIER, PLANET PINION (QRT)	50-20	1H4	CONTROL, TRANSMISSION SHIFTER	50-24
1I5	CASE, TRANSMISSION	50-46	1H8	CONTROL, TRANSMISSION SHIFTER	50-28
1G13	CASE, TRANSMISSION (QRT) (SRT)	50-9	1E21	CONTROL, TURN SIGNAL	40-41
2G6	CAST DISK WHEELS	80-14	2F9	CONVERSION KIT, REMOTE CYLINDER	70-70
2E3	CENTER LINK, HITCH	70-44	1B12	COOLER, ENGINE OIL	20-15
2G23	CHART, GROUND SPEED	80-32	2D1	COOLER, HYDRAULIC OIL	70-20
1D12	CIRCUIT BREAKER	40-10	2H8	CORE, EVAPORATOR	90-6
1D13	CIRCUIT BREAKER	40-11	1G15	COUNTERSHAFT, TRANSMISSION	50-11
1D14	CIRCUIT BREAKER	40-12	2F11	COUPLER, AUXILIARY OUTLET	70-72
1D15	CIRCUIT BREAKER	40-13	2E18	COUPLER, BREAKAWAY	70-58
1D15	CIRCUIT BREAKERS AND ACCESSORY RELAY	40-13	2E20	COUPLER, BREAKAWAY (ISO)	70-60
1C5	CLEANING GUN, DRY AIR CLEANER ELEMENT	30-3	2E19	COUPLER, FLEXIBLE OIL LINE	70-59
1G7	CLUTCH DISK	50-3	2E5	COUPLER, IMPLEMENT QUIK	70-46
1I1	CLUTCH DRIVE SHAFT	50-42	2E6	COUPLER, IMPLEMENT QUIK	70-47
1I3	CLUTCH DRUM	50-44	2C4	COUPLER, MAIN PUMP DRIVE	70-1
1G20	CLUTCH DRUM (QRT)	50-18	2C5	COUPLER, MAIN PUMP DRIVE	70-2
1G5	CLUTCH HOUSING	50-1	2E11	COUPLER, POWER WEIGHT TRANSFER HITCH	70-52
1H20	CLUTCH HOUSING	50-40	2F13	COUPLINGS, REUSABLE	70-74
1I4	CLUTCH HUB (POWER SHIFT)	50-45	2G14	COVER, BATTERY BOX	80-23
1J10	CLUTCH OIL ACCUMULATOR PISTON	50-72	2B14	COVER, BRAKE VALVE HOUSING	60-18
1I2	CLUTCH OIL MANIFOLD	50-43	2D14	COVER, CONTROL VALVE HOUSING	70-34
1G10	CLUTCH OIL PRESSURE VALVE HOUSING	50-6	2E18	COVER, DUST, BREAKAWAY COUPLER	70-58
1G8	CLUTCH OPERATING PISTON HSG. (QRT) (SRT)	50-4	2E19	COVER, DUST, BREAKAWAY COUPLER	70-59
1H21	CLUTCH OPERATING ROD	50-41	1B11	COVER, ENGINE OIL FILTER	20-14
1H21	CLUTCH PEDAL	50-41	1C7	COVER, EXHAUST MUFFLER	30-5
1G6	CLUTCH PEDAL (QRT) (SRT)	50-2	1H14	COVER, OIL FILTER (QRT) (SRT)	50-34
1H21	CLUTCH PEDAL BOOT	50-41	1J8	COVER, PORTED RETURN	50-70
1G20	CLUTCH PISTON (QRT)	50-18	2J6	COVER, PRESSURIZER	90-48
1G7	CLUTCH PTO	50-3	2D10	COVER, R.S. CONTROL VALVE HOUSING	70-30
1G7	CLUTCH SHAFT	50-3	1A21	COVER, ROCKER ARM	20-2
1H1	CLUTCH SHAFT (QRT)	50-20	2D6	COVER, ROCKSHAFT BOTTOM	70-26
1G8	CLUTCH SHAFT (QRT) (SRT)	50-4	2D14	COVER, ROCKSHAFT CONTROL VALVE HOUSING	70-34
1G11	CLUTCH VALVE HOUSING (QRT) (SRT)	50-7	2D8	COVER, ROCKSHAFT PISTON	70-28
1G11	CLUTCH VALVE, PTO (QRT) (SRT)	50-7	2D20	COVER, ROCKSHAFT PISTON	70-40
2H5	CLUTCH, COMPRESSOR	90-3	2E14	COVER, ROCKSHAFT PISTON (PWTH)	70-54B
1H4	CLUTCH, CONTROL, TRANSMISSION	50-24	1B8	COVER, TIMING GEAR	20-11
1J4	CLUTCH, OIL ACCUMULATOR PISTON	50-66	1G14	COVER, TRANSMISSION CASE	50-10
1I4	CLUTCH, PTO PISTON (POWER SHIFT)	50-45	1I6	COVER, TRANSMISSION CASE	50-47
1H21	CLUTCH, VALVE HOUSING	50-41	1I6	COVER, TRANSMISSION CASE	50-47
2H5	COIL, COMPRESSOR	90-3	1G14	COVER, TRANSMISSION CASE (QRT) (SRT)	50-10
1C24	COLD WEATHER STARTING AID	30-23	2J18	COWLS	90-60
1C25	COLD WEATHER STARTING AID (ELECTRIC)	30-24	1B6	CRANKSHAFT	20-9
1G17	COLLAR, SYNCHRONIZER DRIVE	50-14	1H7	CREEPER CONTROL RODS	50-27
2H4	COMPRESSOR	90-2	2H20	CUSHION, ARM REST	90-19
2H5	COMPRESSOR	90-3	2I4	CUSHION, BACKREST	90-24
2H6	CONDENSER LINES	90-4	2H20	CUSHION, SEAT	90-19
1B5	CONNECTING ROD BEARINGS	20-8	2I4	CUSHION, SEAT	90-24
1B5	CONNECTING RODS	20-8	1B3	CYLINDER BLOCK	20-6
1E8	CONSOLE LAMP	40-28	1K4	CYLINDER BLOCK, MOTOR (PFWD)	50-87
2K2	CONSOLE SUPPORT	90-67	1A20	CYLINDER HEAD	20-1
2J21	CONSOLE, CONTROL	90-64	1B5	CYLINDER LINER	20-8
1I19	CONTROL CABLES, TRANSMISSION	50-60	2E1	CYLINDER, LIFT ASSIST	70-42
2J21	CONTROL CONSOLE	90-64	2D17	CYLINDER, LIFT ASSIST, LINES	70-37
2E17	CONTROL LEVER SUPPORT, HYDRAULIC	70-57	2F5	CYLINDER, REMOTE	70-66
2D12	CONTROL LINKAGE, ROCKSHAFT	70-32	2F6	CYLINDER, REMOTE	70-67

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
2F7	CYLINDER, REMOTE	70-68	1F20	ELECTRIC REMOTE CONTROL KIT	40-64
2F8	CYLINDER, REMOTE, OVERHAUL KIT	70-69	1F21	ELECTRICAL OUTLET SOCKET	40-65
2H3	CYLINDER, SEAT POSITION	90-34	1F22	ELECTRICAL OUTLET SOCKET KIT	40-66
D					
1B6	DAMPER, CRANKSHAFT	20-9	1F19	ELECTRICAL REMOTE CONTROL	40-63
2G22	DECAL SET	80-31	1F3	ELEMENT, COOLANT HEATER	40-47
1B15	DEFLECTOR, FAN BLAST	20-18	1C3	ELEMENT, DRY AIR CLEANER	30-1
2H1	DELUXE SEAT SUPPORT	90-21	1B11	ELEMENT, OIL FILTER, ENGINE	20-14
2H2	DELUXE SEAT SUSPENSION	90-22	1J7	ELEMENT, OIL FILTER, TRANSMISSION	50-69
2G6	DEMOUNTABLE RIMS	80-14	2K8	EMBLEM, SLOW MOVING VEHICLE	90-73
1J17	DIFFERENTIAL	50-79	2K10	ENCLOSURE, WEATHER	90-75
1J18	DIFFERENTIAL	50-80	2F21	END, TIE ROD	80-6
1J19	DIFFERENTIAL	50-81	1F3	ENGINE COOLANT HEATER	40-47
1J20	DIFFERENTIAL	50-82	1B9	ENGINE OIL	20-12
1G16	DIFFERENTIAL DRIVE SHAFT	50-12	1B12	ENGINE OIL COOLER	20-15
1H13	DIFFERENTIAL DRIVE SHAFT	50-54	1B11	ENGINE OIL FILTER	20-14
1J17	DIFFERENTIAL DRIVE SHAFT	50-79	1B10	ENGINE OIL PUMP	20-13
1J18	DIFFERENTIAL DRIVE SHAFT	50-80	1D3	ETHER STARTING AID	40-1
1J19	DIFFERENTIAL DRIVE SHAFT	50-81	2H8	EVAPORATOR	90-6
1J20	DIFFERENTIAL DRIVE SHAFT	50-82	1C6	EXHAUST MANIFOLD	30-4
1J14	DIFFERENTIAL LOCK OIL PIPES	50-76	1A22	EXHAUST VALVE	20-3
1J16	DIFFERENTIAL LOCK PEDAL	50-78	1A22	EXHAUST VALVE ROTORS	20-3
1J16	DIFFERENTIAL LOCK RELEASE LINK	50-78	1A20	EXHAUST VALVE SEAT INSERT	20-1
1J13	DIFFERENTIAL LOCK VALVE	50-75	1C7	EXTENSION, MUFFLER	30-5
1B3	DIPSTICK, ENGINE	20-6	2G15	EXTENSION, PLATFORM	80-24
2D6	DIPSTICK, TRANSMISSION	70-26	2G3	EXTENSION, SPINDLE FRONT WHEEL	80-11
2D10	DIRECTIONAL CONTROL VALVE	70-30	2G2	EXTENSION, SPINDLE, FRONT WHEEL	80-10
1K8	DIRECTIONAL CONTROL VALVE (PFWD)	50-91	F		
2D14	DIRECTIONAL VALVE	70-34	2B9	FACING, BRAKE	60-12
2B9	DISK, BRAKE	60-12	1B16	FAN	20-19
1G7	DISK, CLUTCH	50-3	1E1	FAN AND ALTERNATOR DRIVE BELT	40-21
1G7	DISK, PTO CLUTCH	50-3	1B16	FAN BELT	20-19
1H1	DISK, TORSIONAL DAMPER	50-42	1B15	FAN BLAST DEFLECTOR	20-18
1G17	DISK, TRANSMISSION SYNCHRONIZER	50-14	1B16	FAN PULLEY	20-19
1E20	DOE LIGHT	40-40	1E2	FAN, ALTERNATOR	40-22
2J4	DOOR HANDLE, SOUND-GARD BODY	90-46	2K1	FENDERS	90-66
2H10	DOOR, FRESH AIR FILTER SERVICE	90-9	1B11	FILTER, ENGINE OIL	20-14
2J2	DOORS, SOUND-GARD BODY	90-45A	1C10	FILTER, FUEL	30-8
2E4	DRAFT LINKS, HITCH	70-45	1J7	FILTER, TRANSMISSION HYDRAULIC OIL	50-69
2D5	DRAIN PIPES, REAR HYDRAULIC (PFWD)	70-24	1H14	FILTER, TRANSMISSION OIL (QRT) (SRT)	50-34
2E10	DRAWBAR CLEVIS PIN KIT	70-51	1D21	FLASHER, LAMP	40-20
2E9	DRAWBAR, FRONT SUPPORT	70-50	2E19	FLEXIBLE OIL LINE COUPLER	70-59
2E7	DRAWBAR, REGULAR	70-48	2F13	FLEXIBLE OIL LINE, BULK	70-74
2E8	DRAWBAR, WIDE SWING	70-49	2J14	FLOOR MAT	90-56
1H18	DRIVE GEAR, PTO	50-38	2D10	FLOW CONTROL VALVE	70-30
2C5	DRIVE HYDRAULIC PUMP	70-2	1C24	FLUID, STARTING	30-23
1H18	DRIVE SHAFT, PTO	50-38	1C25	FLUID, STARTING (ELECTRIC)	30-24
2G5	DRIVE WHEELS	80-13	1B6	FLYWHEEL	20-9
2F18	DRIVE, FRONT WHEEL	80-3	1A22	FOLLOWER, CAM	20-3
2C4	DRIVE, HYDRAULIC PUMP	70-1	1C21	FOOT SPEED CONTROL	30-19
1B2	DRIVE, SPEED-HOUR METER	20-5	2G11	FRAME	80-19
1H3	DRUM, CLUTCH	50-44	2G11	FRAME PLATES	80-19
1G20	DRUM, CLUTCH (QRT)	50-18	2G11	FRAME, SIDE	80-19
1H4	DRUM, CLUTCH, REAR (POWER SHIFT)	50-45	2F19	FRONT AXLE KNEE	80-4
1G17	DRUM, SYNCHRONIZER	50-14	2F22	FRONT AXLE TIE RODS, ADJUSTABLE (PFWD)	80-7
1F2	DUAL HORN	40-46	2F18	FRONT AXLE, ADJUSTABLE TREAD	80-3
2G8	DUAL REAR WHEELS	80-16	2E9	FRONT DRAWBAR SUPPORT	70-50
2E18	DUST COVER, BREAKAWAY COUPLER	70-58	2D2	FRONT HYDRAULIC PIPES AND LINES (PFWD)	70-21
2E19	DUST COVER, BREAKAWAY COUPLER	70-59	1D8	FRONT LAMP	40-6
E					
1F2	ELECTRIC HORN	40-46	1E10	FRONT LAMP	40-30
TRACTOR - 4040 PC-1610 (14-JUL-78) LITHO IN U.S.A.					
			1E12	FRONT LAMP	40-32
			1E8	FRONT LAMPS	40-28
			2G12	FRONT WEIGHTS	80-20
			2G13	FRONT WEIGHTS	80-21
			2G1	FRONT WHEELS	80-9

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
2G4	FRONT WHEELS	80-12	1A20	HEAD, CYLINDER	20-1
1C10	FUEL FILTER	30-8	1F18	HEADPHONES, RADIO	40-62
1F1	FUEL GAUGE	40-43	2H13	HEATER AND HOSES	90-12
1C8	FUEL GAUGE SENDER	30-6	1F3	HEATER, ENGINE, COOLANT	40-47
1C12	FUEL INJECTION NOZZLE	30-10	1I4	HIGH RANGE DRIVE SHAFT	50-45
1C20	FUEL INJECTION NOZZLE	30-18	2E3	HITCH CENTER LINK	70-44
1C12	FUEL INJECTION PUMP	30-10	2E4	HITCH DRAFT LINKS	70-45
1C14	FUEL INJECTION PUMP	30-12	2E2	HITCH LIFT LINKS	70-43
1C16	FUEL INJECTION PUMP	30-14	2G18	HOOD	80-27
1C18	FUEL INJECTION PUMP	30-16	2G18	HOOD ORNAMENT	80-27
1C19	FUEL INJECTION PUMP	30-17	2G18	HOOD SUPPORTS	80-27
1C16	FUEL INJECTION PUMP AUTOMATIC ADVANCE	30-14	1F2	HORN SWITCH	40-46
1C16	FUEL INJECTION PUMP DRIVE SHAFT	30-14	1F2	HORN, ELECTRIC	40-46
1C18	FUEL INJECTION PUMP GOVERNOR	30-16	1C5	HOSE, AIR INTAKE	30-3
1C18	FUEL INJECTION PUMP HEAD AND ROTOR	30-16	2H13	HOSE, HEATER	90-12
1C16	FUEL INJECTION PUMP HOUSING	30-14	2F5	HOSE, REMOTE CYLINDER	70-66
1C14	FUEL INJECTION PUMP LINKAGE	30-12	2F10	HOSE, REMOTE CYLINDER	70-71
1C23	FUEL INJECTION PUMP SHUT-OFF	30-21	2F13	HOSE, REMOTE CYLINDER	70-74
1C19	FUEL INJECTION PUMP TRANSFER PUMP	30-17	2G15	HOUSING, BATTERY	80-24
1C11	FUEL PIPES	30-9	1G20	HOUSING, BRAKE PISTON (QRT)	50-18
1C11	FUEL PUMP	30-9	1G5	HOUSING, CLUTCH	50-1
1C23	FUEL SHUT-OFF	30-21	1H20	HOUSING, CLUTCH	50-40
1C8	FUEL TANK	30-6	1J2	HOUSING, CLUTCH REGULATING VALVE	50-64
G			1G11	HOUSING, CLUTCH VALVE (QRT) (SRT)	50-7
1B18	GASKET SET	20-21	1B8	HOUSING, CRANKSHAFT OIL SEAL	20-11
1A20	GASKET, CYLINDER HEAD	20-1	1J17	HOUSING, DIFFERENTIAL	50-79
1A21	GASKET, ROCKER ARM COVER	20-2	1J18	HOUSING, DIFFERENTIAL	50-80
1F1	GAUGE, INSTRUMENT PANEL	40-43	1J19	HOUSING, DIFFERENTIAL	50-81
1H4	GEAR SHIFT LEVER	50-24	1J20	HOUSING, DIFFERENTIAL	50-82
1G16	GEAR, BEVEL, DIFFERENTIAL	50-12	1J13	HOUSING, DIFFERENTIAL LOCK VALVE	50-75
1I13	GEAR, BEVEL, DIFFERENTIAL	50-54	1C16	HOUSING, FUEL INJECTION PUMP	30-14
1J17	GEAR, BEVEL, DIFFERENTIAL	50-79	1K3	HOUSING, MOTOR (PFWD)	50-86
1J18	GEAR, BEVEL, DIFFERENTIAL	50-80	2F20	HOUSING, MOTOR (PFWD)	80-5
1J19	GEAR, BEVEL, DIFFERENTIAL	50-81	1B10	HOUSING, OIL COOLER BYPASS	20-13
1J20	GEAR, BEVEL, DIFFERENTIAL	50-82	1B10	HOUSING, OIL PUMP, ENGINE	20-13
1B1	GEAR, CAMSHAFT	20-4	1K3	HOUSING, PLANET BRAKE PISTON (PFWD)	50-86
1G15	GEAR, COUNTERSHAFT	50-11	1K5	HOUSING, PLANETARY (PFWD)	50-88
1B6	GEAR, CRANKSHAFT	20-9	1G10	HOUSING, PRESSURE REGULATING VALVE	50-6
1J11	GEAR, PTO DRIVE	50-73	2D6	HOUSING, ROCKSHAFT	70-26
1J12	GEAR, PTO DRIVE	50-74	2D10	HOUSING, ROCKSHAFT CONTROL VALVE	70-30
1J9	GEAR, PTO IDLER SHAFT	50-71	2E18	HOUSING, SELECTIVE CONTROL VALVE	70-58
1B2	GEAR, SPEED-HOUR METER DRIVE	20-5	2F1	HOUSING, SELECTIVE CONTROL VALVE	70-62
1B6	GEAR, STARTER	20-9	2F3	HOUSING, SELECTIVE CONTROL VALVE	70-64
1B10	GEARS, ENGINE OIL PUMP	20-13	1B2	HOUSING, SPEED-HOUR METER DRIVE	20-5
1G16	GEARS, TRANSMISSION	50-12	2B7	HOUSING, STEERING MOTOR	60-10
2J11	GLASS, SOUND-GARD BODY	90-53	1I21	HOUSING, TRANSMISSION CLUTCH VALVE	50-62
1C18	GOVERNOR, FUEL INJECTION	30-16	1J4	HOUSING, TRANSMISSION CONTROL VALVE	50-66
2G17	GRILLE	80-26	1G8	HSG. CLUTCH OPERATING PISTON (QRT) (SRT)	50-4
2G23	GROUND SPEED CHART	80-32	1I4	HUB, CLUTCH (POWER SHIFT)	50-45
1H15	GUARD, PTO MASTER SHIELD	50-35	1K3	HUB, FRONT WHEEL (PFWD)	50-86
1J10	GUARD, PTO MASTER SHIELD	50-72	2C14	HYDRAULIC AND TRANSMISSION OIL	70-12
1H15	GUARD, REAR PTO	50-35	2E17	HYDRAULIC CONTROL LEVER SUPPORT	70-57
1J10	GUARD, REAR PTO	50-72	2D5	HYDRAULIC DRAIN PIPES, REAR (PFWD)	70-24
1C5	GUN, AIR CLEANER ELEMENT CLEANING	30-3	1K1	HYDRAULIC LINE SHIELD (PFWD)	50-84
H			2D3	HYDRAULIC LINES, FRONT (PFWD)	70-22
2G19	HANDLE, TRACTOR MOUNTING	80-28	2C10	HYDRAULIC MANIFOLD	70-8
2J21	HANDREST	90-64	2C12	HYDRAULIC OIL ATTENUATOR	70-10
1D8	HARNESS, LIGHTING	40-6	2C13	HYDRAULIC OIL ATTENUATOR	70-11
2H3	HARNESS, WIRING	90-1	2D1	HYDRAULIC OIL COOLER	70-20
1D17	HARNESS, WIRING (PST) (PFWD)	40-15	2C18	HYDRAULIC OIL COOLER PIPE	70-16
1D16	HARNESS, WIRING (QRT) (SRT) (PFWD)	40-14	2C20	HYDRAULIC OIL COOLER PIPE	70-18
I			2C10	HYDRAULIC OIL PRESSURE PIPE	70-8
2G19	HANDLE, TRACTOR MOUNTING	80-28	2C17	HYDRAULIC OIL RETURN PIPE	70-15
2J21	HANDREST	90-64	2C16	HYDRAULIC OIL RETURN PIPES	70-14
1D8	HARNESS, LIGHTING	40-6	2D2	HYDRAULIC PIPES AND LINES, FRONT (PFWD)	70-21
2H3	HARNESS, WIRING	90-1	2C4	HYDRAULIC PUMP DRIVE	70-1
1D17	HARNESS, WIRING (PST) (PFWD)	40-15	2C5	HYDRAULIC PUMP DRIVE	70-2
1D16	HARNESS, WIRING (QRT) (SRT) (PFWD)	40-14			

ALPHABETICAL INDEX - CONTINUED

[illegible]