

John Deere

CLICK ANYWHERE FOR MORE DETAILS

MODEL:

8820 Combine

Volume 1 of 2

**PARTS
MANUAL**



JENSALES.COM

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
JOHN DEERE OR IT'S SUCCESSORS. **JOHN DEERE** AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

JD-P-PC1668



John Deere 8820 Combine with 844 Corn Head

(Specifications and design subject to change without notice.)

NOTE:

For 200 Series Platform Parts Information, refer to John Deere 200 Series Platform Parts Catalog - PC-1558.

For 40 Series Corn Head Parts Information, refer to John Deere 40 Series Corn Head Parts Catalog - PC-1223.

For 50 Series Row-Crop Head Parts Information, refer to John Deere 50 Series Row-Crop Head Parts Catalog - PC-1189.

EXPLANATION OF CHANGE INDICATOR LINES

New and revised information is identified by vertical lines marked on the left-hand margin of revised pages. These lines indicate changes affecting the ordering of parts.

EXPLANATION OF DIRECTION OF TRAVEL ARROW

An arrow is added to the illustration indicating forward travel of the machine.

EXPLANATION OF BOX ENCLOSED ILLUSTRATIONS

A key number, shown in the parts list, is assigned to the box enclosing all parts sold as a service assembly.

EXPLANATION OF KITS

Kit information will be found immediately following the story in which it is used. The illustration is repeated with only the kit parts called out and with all other parts shown in phantom for relationship.

SI (INTERNATIONAL SYSTEM) UNITS OF MEASURE

Metric equivalents have been included, where applicable, throughout this parts catalog.

BOLT AND CAP SCREW STRENGTH IDENTIFICATION

Bolts and cap screws required to have high-strength qualities equivalent to SAE Grade 8 are identified throughout this catalog by the description HS SAE 8. Unless identified by this description, all standard bolts and cap screws are SAE Grade 5 or lower.

SECTIONAL INDEX

	SECTION
General.....	10
Engine.....	20
Fuel and Air.....	30
Electrical.....	40
Power Train.....	50
Steering and Brakes.....	60
Hydraulics.....	70
Separator Shell.....	80
Operator's Station.....	90
Headers—Refer to Individual Header Parts Catalogs.....	100
Feeder House.....	110
Separator.....	120
Grain Tank and Unloading Auger.....	130
Major Drives.....	140
SideHill System.....	150
Automatic Header Height Control.....	160
Decals.....	170
Numerical Index.....	180

purchase full manual at

JENSALES.COM
or Call 800-443-0625

ALPHABETICAL INDEX

GRID	PAGE	GRID	PAGE
A			
1F21 ACCESSORIES, INSTRUMENT PANEL.....	40-31	2D15 BEARINGS, CRAWLER.....	50-63
2I11 ACCUMULATOR,PRESSURE CTL.VALVE & MTG.BKT.....	70-57	2D15 BEARINGS, CRAWLER.....	50-63
1D17 AIR CLEANER.....	30-15	2D17 BEARINGS, CRAWLER DRIVE.....	50-65
3C14 AIR CONDITIONER EVAPORATOR.....	90-42	2B21 BEARINGS, FINAL DRIVE.....	50-23
3C13 AIR CONDITIONER LINES.....	90-41	2B23 BEARINGS, FINAL DRIVE.....	50-25
3C14 AIR CONDITIONER LINES.....	90-42	2C1 BEARINGS, FINAL DRIVE (CRAWLER TRACKS).....	50-26
3C7 AIR CONDITIONING COMPRESSOR.....	90-34	2C2 BEARINGS, FINAL DRIVE (CRAWLER TRACKS).....	50-27
3I10 AIR DUCTS, CLEANING FAN.....	120-91	3J11 BEARINGS, TAILINGS ELEVATOR CONVEYOR.....	120-114
3C4 AIR FILTER, CAB.....	90-31	2B15 BEARINGS,TRANSMISSION COUNTERSHAFT,GEARS.....	50-17
1D16 AIR INTAKE TUBES (PRECLNR.TO AIR CLNR.).....	30-14	2B15 BEARINGS,TRANSMISSION INPUT SHAFT,GEARS.....	50-17
1D18 AIR INTAKE TUBES-AIR CLEANER TO MANIFOLD.....	30-16	2B17 BEARINGS,TRANSMISSION PINION SHAFT,GEARS.....	50-19
3C2 AIR LOUVER.....	90-29	3F22 BEATER.....	120-31
1H4 ALTERNATOR.....	40-61	3J18 BEATER AND CYLINDER TACHOMETER.....	120-121
1H5 ALTERNATOR ADJUSTING STRAP.....	40-62	3F22 BEATER AND TACHOMETER DRIVE.....	120-31
1H5 ALTERNATOR BRACKET.....	40-62	3G2 BEATER BEARING LUBE BANK SYS-LH-HYDRO.....	120-33
3F7 ARM, CONCAVE ADJUSTING SHAFT.....	120-15	3G1 BEATER BEARING LUBE BANK SYSTEM-RH.....	120-32
1B13 ARM, ROCKER.....	20-17	3F22 BEATER BELT.....	120-31
1H8 ARMATURE, STARTER.....	40-65	3J18 BEATER BELT.....	120-121
3B14 ARMREST (PERSONAL POSTURE SEAT).....	90-17	3E22 BEATER GRATE, OPEN-BAR CONCAVE.....	120-7
3B17 ASH TRAY.....	90-20	3G3 BEATER IDLER AND MOUNTINGS.....	120-35
1D19 ASPIRATOR.....	30-17	1D15 BELL CRANK, THROTTLE LINKAGE.....	30-13
4C6 AUGER AND HOUSING, HORIZONTAL UNLOADING.....	130-35	3J17 BELT & SHEAVES TORQ-SENSING CTRSHAFT.....	120-120
4B23 AUGER AND HOUSING, VERTICAL, GRAIN TANK.....	130-29	3J17 BELT AND SHEAVES.....	120-120
1E20 AUGER LIGHT, UNLOADING.....	40-5	4C22 BELT GUIDES, SEPARATOR DRIVE.....	140-16
2H9 AUGER SWING HYD.OIL LINES AND HOSES.....	70-31	4C22 BELT GUIDES, UNLOADING AUGER DRIVE.....	140-16
4B11 AUGER, CROSS, FRONT, GRAIN TANK.....	130-15	2C6 BELT TENSIONING MECHANISM,HYDROSTATIC DR.....	50-31
4B12 AUGER, CROSS, REAR, GRAIN TANK.....	130-16	2I7 BELT TENSIONING SYSTEM, HYDRAULIC.....	70-53
4C2 AUGER, HORIZONTAL UNLOADING SWIVEL.....	130-31	3C7 BELT, AIR CONDITIONING COMPRESSOR.....	90-34
3J2 AUGER, LOADING.....	120-105	3F22 BELT, BEATER.....	120-31
3J6 AUGER, LOWER TAILINGS.....	120-109	3J18 BELT, BEATER.....	120-121
3I14 AUGER, LOWER, CLEAN GRAIN.....	120-95	3C11 BELT, COMPRESSOR.....	90-39
4C3 AUGER, UNLOADING, LUBE BANK SYSTEM.....	130-32	3F11 BELT, CYLINDER DRIVE INTERMEDIATE SHAFT.....	120-19
1E19 AUGER, UNLOADING, WIRING HARNESS.....	40-3	3J18 BELT, CYLINDER TACHOMETER.....	120-121
3J13 AUGER, UPPER TAILINGS AUGER.....	120-116	2I12 BELT, DRIVE, HYDRAULIC REEL LIFT.....	70-58
4B21 AUGER, VERTICAL, LOWER GEAR CASE.....	130-27	2I13 BELT, DRIVE, HYDRAULIC REEL LIFT.....	70-59
4B19 AUGER,CROSS,DRIVE TIGHTENERS,GRAIN TANK.....	130-25	4D2 BELT, DRIVE, SECONDARY COUNTERSHAFT.....	140-19
4C4 AUGER,HORIZONTAL UNLDG. DRIVE GEAR CASE.....	130-33	1C12 BELT, FLAT ROTARY SCREEN.....	20-41
4B4 AUGER,HORIZONTAL UNLOADING SWIVEL SHROUD... ..	130-7	3J4 BELT, GEAR CASE, LOADING AUGER.....	120-107
3H10 AUGERS, HOUSING, SHOE GRAIN SUPPLY.....	120-67	2H18 BELT, HYDROSTATIC REEL PUMP.....	70-41
3H14 AUGERS, SHOE GRAIN SUPPLY, DRIVE SHAFT.....	120-71	3J6 BELT, LOWER TAILINGS AUGER.....	120-109
3H12 AUGERS, SUPPLY, SHOE GRAIN.....	120-69	2C4 BELT, PROPULSION DRIVE CTRSHAFT. SHEAVE.....	50-29
4D4 AUTO.HEADER HEIGHT CONTROL CHECK BLOCK.....	160-1	1C20 BELT, RADIATOR FAN.....	20-49
4D13 AUTOMATIC HDR.HGT.CTL.WIRING HARNESS.....	160-11	3H3 BELT, REAR, STRAW CHOPPER.....	120-59
4D9 AUTOMATIC HDR.HGT.CTL.DROP RATE VALVE.....	160-7	1D1 BELT, ROTARY SCREEN.....	20-54
4D9 AUTOMATIC HDR.HGT.CTL.FULL FLOW PLUG.....	160-7	3H2 BELT, STRAW CHOPPER DRIVE.....	120-57
4D9 AUTOMATIC HDR.HGT.CTL.HYDRAULIC OIL LINE.....	160-7	3G13 BELT, STRAW SPREADER DRIVE.....	120-45
4D13 AUTOMATIC HEADER HEIGHT CONTROL LINKAGE.....	160-11	3F22 BELT, TACHOMETER DRIVE.....	120-31
4D14 AUTOMATIC HEADER HEIGHT CONTROL SWITCH.....	160-12	4B9 BELT, UNLOADING AUGER COUNTERSHAFT.....	130-13
4D4 AUTOMATIC HEADER HEIGHT CONTROL VALVE.....	160-1	3I20 BELT,DR.CTRSHAFT,CLEAN GRAIN ELEVATOR.....	120-101
2B21 AXLE SHAFT FINAL DRIVE.....	50-23	3D23 BELT,FDR,HSE.LOWER SHAFT-VARIABLE DRIVE.....	110-27
2B11 AXLE, DRIVE WHEEL.....	50-12	3H14 BELT,SHOE GRAIN SUPPLY AUGERS DR. SHAFT.....	120-71
2C1 AXLE, FINAL DRIVE (CRAWLER TRACKS).....	50-26	3K3 BELTS, CLEAN GRAIN ELEVATOR.....	120-128
2F18 AXLE, REAR.....	60-27	3J22 BELTS, DRIVE, CLEANING FAN.....	120-125
2F21 AXLE,REAR,SPINDLE HSGS-HVY-DTY REAR AXLE.....	60-30	1C23 BELTS, DRIVE, ENGINE R.H. SIDE.....	20-53
		3E10 BELTS, DRIVE, FEEDER HOUSE (LONG).....	110-38
B		3K3 BELTS, LOADING AUGER.....	120-128
3G6 BAR, CYLINDER SHEAR.....	120-38	4C15 BELTS, PRIMARY COUNTERSHAFT SHEAVES.....	140-9
1F10 BATTERY CABLES.....	40-19	1C14 BELTS, ROTARY SCREEN.....	20-43
1F10 BATTERY MOUNTINGS.....	40-19	4D1 BELTS,DRIVE,ENGINE TO PRIMARY CTRSHAFT.....	140-18
2C3 BEARING CAP, FINAL DRIVE (CRAWLER TRACKS).....	50-28	3E5 BELTS,DRIVE,FEEDER HOUSE (VARIABLE DR.).....	110-32
1B10 BEARING, MAIN.....	20-14	3J21 BELTS,DRIVE,SHOE GRAIN SUPPLY AUGERS.....	120-124
1B10 BEARING, MAIN THRUST.....	20-14	2E12 BELTS,HYDROSTATIC GROUND DRIVE.....	50-86
2D13 BEARINGS, CRAWLER.....	50-61	3C2 BEZEL, AIR LOUVER.....	90-29
		3H7 BLADE, STRAW SPREADER.....	120-63
		1G8 BLADE, WINDSHIELD WIPER.....	40-43
		3G22 BLADES AND ROTOR, STRAW CHOPPER.....	120-55
		1B2 BLOCK, CYLINDER.....	20-6

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
2D23	BLOCK, MOTOR CYLINDER (PRWD).....	50-72	3D11	CHAIN, FEEDER CONVEYOR.....	110-14
4D4	BLOCK,CHECK,AUTO.HEADER HEIGHT CONTROL.....	160-1	3E12	CHAIN, FEEDER HOUSE (LONG).....	110-40
1G4	BLOWER SWITCH.....	40-37	3G14	CHAIN, STRAW WALKER.....	120-47
3C6	BLOWER, PRESSURIZER.....	90-33	3J11	CHAIN, TAILINGS ELEVATOR CONVEYOR.....	120-114
2E14	BOOT, PARKING BRAKE CONTROL.....	60-1	3J13	CHAIN, UPPER TAILINGS AUGER.....	120-116
1F19	BOX, CONTROL, LOW SHAFT SPEED MONITORING.....	40-29	3J22	CHAINS, DRIVE, STRAW WALKER.....	120-125
2J3	BOX, TOOL.....	80-13	3E6	CHAINS, FEEDER HOUSE (VARIABLE DRIVE.....	110-33
2I22	BRACES, SEPARATOR CROSS.....	80-8	3B4	CHANNEL SUPPORTS.....	90-7
3F13	BRACES, SUPPORT, CYLINDER DRIVE.....	120-21	4B13	CHANNELS,GRAIN TANK INNER UNLDG.AUGER.....	130-17
1H5	BRACKET, ALTERNATOR.....	40-62	2C15	CHARGE PUMP MOUNTING, HYDROSTATIC DRIVE.....	50-40
3D12	BRACKET, FEEDER CONVEYOR.....	110-15	2C13	CHARGE PUMP, HYDROSTATIC DRIVE.....	50-38
1F6	BRACKET, HARNESS, REAR CAB.....	40-15	4D4	CHECK BLOCK, AUTO.HEADER HEIGHT CONTROL.....	160-1
2I11	BRACKET,MTG.ACCUMULATOR & PRES.CTL.VALVE..	70-57	1E13	CHECK VALVE, FUEL.....	30-34
3I2	BRACKETS, CHAFFER FRAME.....	120-81	3G16	CHOPPER HOUSING, STRAW.....	120-49
2E14	BRAKE CONTROLS, PARKING.....	60-1	3G21	CHOPPER, STRAW, KNIFE AND SUPPORT.....	120-54
2E16	BRAKE LINES.....	60-3	3G18	CHOPPER, STRAW, PLATE AND FINS.....	120-51
2E18	BRAKE MASTER CYLINDER.....	60-5	1F21	CIGAR LIGHTER.....	40-31
2E15	BRAKE PEDALS AND LINKAGE.....	60-2	1F12	CIRCUIT BREAKER AND RELAY PANEL.....	40-21
3B6	BRAKE PLATE.....	90-9	1F6	CLAMPS, HARNESS, REAR CAB.....	40-15
2E1	BRAKE PLATES (PRWD).....	50-73	3K3	CLEAN GRAIN ELEVATOR DRIVE.....	120-128
2E22	BRAKE SHOES AND DRUM.....	60-9	3I20	CLEAN GRAIN ELEVATOR DRIVE COUNTERSHAFT.....	120-101
2E19	BRAKE SLAVE CYLINDER.....	60-6	3I22	CLEAN GRAIN ELEVATOR DRIVE IDLER.....	120-103
1F12	BREAKER, CIRCUIT.....	40-21	3I22	CLEAN GRAIN ELEVATOR DRIVE TIGHTENER.....	120-103
2C16	BRG.-SEAL-HYDRO.DR.PUMP FRONT COVER ASSY.	50-41	3I18	CLEAN GRAIN ELEVATOR HOUSING.....	120-99
2C19	BRGS.TRUNNIONS,HYDRO.DR.PUMP SWASHPLATE.....	50-44	3K3	CLEAN GRAIN ELEVATOR SHEAVES AND BELTS.....	120-128
1F21	BUZZER, WARNING.....	40-31	3I14	CLEAN GRAIN LOWER AUGER AND HOUSING.....	120-95
C			3I16	CLEAN GRAIN LOWER AUGER HOUSING.....	120-97
3B18	CAB.....	90-21	3I7	CLEANING FAN.....	120-87
3C4	CAB AIR FILTER.....	90-31	3I10	CLEANING FAN AIR DUCTS.....	120-91
3B21	CAB COVERS.....	90-25	3J22	CLEANING FAN DRIVE BELTS.....	120-125
3B21	CAB DOORS.....	90-25	3J22	CLEANING FAN DRIVE SHEAVES.....	120-125
3B21	CAB HANDLE.....	90-25	3I9	CLEANING FAN HOUSING.....	120-89
3B22	CAB ROOF AND SUPPORTS.....	90-26	3I9	CLEANING FAN PROTECTOR SHIELD.....	120-89
3C1	CAB ROOF HEADLINER.....	90-28	3I12	CLEANING FAN SPEED CONTROL.....	120-93
1G4	CAB ROOF WIRING HARNESS.....	40-37	3B6	CLUTCH COVER.....	90-9
3B21	CAB SHIELDS.....	90-25	1F21	CLUTCH, ELECTRIC, SWITCH.....	40-31
3B19	CAB WINDOWS.....	90-23	1E23	CLUTCH, ELECTROMAGNETIC.....	40-8
1F6	CAB, REAR, HARNESS BRACKET.....	40-15	1H10	COIL, STARTER.....	40-67
2C8	CABLE AND LEVER, HYDRO. DRIVE CONTROL.....	50-33	1D11	COLD WEATHER STARTING AID.....	30-9
2C10	CABLE MOUNTING, HYDRO. DRIVE CONTROL.....	50-35	2F2	COLUMN AND WHEEL, STEERING.....	60-11
1D15	CABLE SUPPORTS, THROTTLE LINKAGE.....	30-13	1H9	COMMUTATOR END FRAME, STARTER.....	40-66
1D10	CABLE, FUEL SHUT-OFF CONTROL.....	30-8	3C10	COMPRESSOR HARNESS.....	90-37
3D21	CABLE, REVERSER CONTROL.....	110-25	3C11	COMPRESSOR MOUNTING AND SUPPORTS.....	90-39
2H2	CABLE, VARIABLE CYLINDER CONTROL.....	70-23	3C10	COMPRESSOR RELAY.....	90-37
2B4	CABLES AND MOUNTINGS, GEARSHIFT.....	50-5	3F9	CONCAVE ADJUSTING CONTROLS.....	120-17
1F10	CABLES, BATTERY.....	40-19	3F7	CONCAVE ADJUSTING SHAFT.....	120-15
2B13	CAM, SHIFTER.....	50-15	3E22	CONCAVE, OPEN-BAR.....	120-7
1B12	CAMSHAFT.....	20-16	3F4	CONCAVE, SPIKE-TOOTH.....	120-11
1B12	CAMSHAFT GEAR.....	20-16	3C13	CONDENSER.....	90-41
1D19	CAP, EXHAUST RAIN.....	30-17	1B14	CONNECTING RODS.....	20-18
2G6	CAP, HYDRAULIC OIL RESERVOIR.....	70-3	3B16	CONSOLE COVERS.....	90-19
2E2	CARRIER, FIRST PLANET (PRWD).....	50-74	3B16	CONSOLE PANEL.....	90-19
1C6	CENTER HOUSING, TURBOCHARGER.....	20-35	1F19	CONTROL BOX, LOW SHAFT SPEED MONITORING.....	40-29
2D1	CENTER SECTION, HYDROSTATIC DRIVE.....	50-49	2C8	CONTROL CABLE AND LEVER, HYDRO. DRIVE.....	50-33
3H18	CHAFFER.....	120-75	2C10	CONTROL CABLE MOUNTING HYDRO. DRIVE.....	50-35
3H22	CHAFFER FRAME.....	120-79	2C23	CONTROL HANDLE,HYDRO.DR.DISPLACEMENT.....	50-48
3I2	CHAFFER FRAME BRACKETS.....	120-81	2H14	CONTROL LEVER, HYDRAULIC REEL LIFT.....	70-37
3H22	CHAFFER FRAME COVER.....	120-79	2H14	CONTROL LEVER, PLATFORM LIFT.....	70-37
3I2	CHAFFER FRAME SWINGERS.....	120-81	1D13	CONTROL LEVER, THROTTLE LINKAGE.....	30-11
3D13	CHAIN GUIDES, FEEDER CONVEYOR DRIVE.....	110-16	2G18	CONTROL PLUG, FLOW.....	70-15
3F9	CHAIN, CONCAVE ADJUSTING CONTROLS.....	120-17	2E4	CONTROL VALVE (PRWD).....	50-76
3I19	CHAIN, CONVEYOR, CLEAN GRAIN ELEVATOR.....	120-100	2H16	CONTROL VALVE LINKAGE, REEL SPEED.....	70-39
3I5	CHAIN, CRANK SHOE.....	120-85	2E5	CONTROL VALVE SOLENOID (PRWD).....	50-77
3D12	CHAIN, DRIVE, FEEDER CONVEYOR.....	110-15	2C22	CONTROL VALVE, HYDRO. DRIVE DISPLACEMENT.....	50-47
			2I1	CONTROL VALVE, HYDROSTATIC DR. REEL FLOW...	70-47
			2H5	CONTROL VALVE, SECONDARY.....	70-27
			2E8	CONTROL VALVES, FLOW (PRWD).....	50-81

COMBINE - 8820 PC-1668 (27-FEB-79) LITHO IN U.S.A.

GRID	PAGE
1B13 EXHAUST VALVE	20-17
4B6 EXTENSIONS, GRAIN TANK	130-9

F

3D8	FALSE BOTTOM, FEEDER HOUSE.....	110-11
3I9	FAN HOUSING, CLEANING.....	120-89
2J5	FAN SHROUD.....	80-15
3I7	FAN, CLEANING.....	120-87
3I10	FAN, CLEANING, AIR DUCTS.....	120-91
3I12	FAN, CLEANING, SPEED CONTROL.....	120-93
1C20	FAN, RADIATOR.....	20-49
1C20	FAN, RADIATOR, DRIVES.....	20-49
2I15	FEED PLATE, SEPARATOR.....	80-1
3D12	FEEDER CONVEYOR BRACKET.....	110-15
3D11	FEEDER CONVEYOR CHAIN.....	110-1
3D12	FEEDER CONVEYOR DRIVE CHAIN.....	110-15
3D13	FEEDER CONVEYOR DRIVE CHAIN GUIDES.....	110-16
3D10	FEEDER CONVEYOR DRUM.....	110-13
3D12	FEEDER CONVEYOR IDLER.....	110-15
3D10	FEEDER CONVEYOR IDLER SHAFT.....	110-13
3D6	FEEDER HOUSE BOTTOM SHEETS.....	110-9
3E12	FEEDER HOUSE CHAIN (LONG).....	110-40
3E6	FEEDER HOUSE CHAINS (VARIABLE DRIVE).....	110-33
3E10	FEEDER HOUSE DRIVE BELTS (LONG).....	110-38
3E5	FEEDER HOUSE DRIVE BELTS (VARIABLE DR.).....	110-32
4C23	FEEDER HOUSE DRIVE IDLER.....	140-17
3E10	FEEDER HOUSE DRIVE SHEAVES (LONG).....	110-38
3E5	FEEDER HOUSE DRIVE SHEAVES (VAR. DR.).....	110-32
3D8	FEEDER HOUSE FALSE BOTTOM.....	110-11
3D8	FEEDER HOUSE FRAME.....	110-11
3D2	FEEDER HOUSE FRONT SHEETS.....	110-5
2I4	FEEDER HOUSE HYD. HOSE, VARIABLE DRIVE.....	70-50
3E10	FEEDER HOUSE IDLER (LONG).....	110-38
3E5	FEEDER HOUSE IDLERS (VARIABLE DRIVE).....	110-32
3D15	FEEDER HOUSE L.H. SHIELDS-VARIABLE DR.....	110-18
3E11	FEEDER HOUSE LOWER BELT TIGHTENER-LONG.....	110-35
1F16	FEEDER HOUSE LOWER SHAFT SPEED SENSOR-LG.....	40-25
3E7	FEEDER HOUSE LOWER SHAFT-LONG.....	110-35
3D23	FEEDER HOUSE LOWER SHAFT-VARIABLE DRIVE.....	110-27
3D23	FEEDER HOUSE LOWER SHEAVE-VARIABLE DRIVE.....	110-27
3D17	FEEDER HOUSE MIDDLE BELT IDLER,LH-VAR.DR.....	110-21
3D19	FEEDER HOUSE REVERSER GEAR BOX-VAR.DR.....	110-23
3E7	FEEDER HOUSE SHEAVE-LONG.....	110-35
3E9	FEEDER HOUSE SHEAVES (LONG).....	110-37
3D14	FEEDER HOUSE SHIELD (R.H.).....	110-17
3D16	FEEDER HOUSE SHIELD,L.H.-LONG.....	110-19
3D8	FEEDER HOUSE SIDE SHEETS.....	110-11
1F14	FEEDER HOUSE SPEED MONITORING HARNESS.....	40-23
3E9	FEEDER HOUSE SPROCKETS (LONG).....	110-37
3E12	FEEDER HOUSE SPROCKETS (LONG).....	110-40
3E4	FEEDER HOUSE SPROCKETS (VARIABLE DR.).....	110-31
3E6	FEEDER HOUSE SPROCKETS (VARIABLE DRIVE).....	110-33
3E10	FEEDER HOUSE TIGHTENERS (LONG).....	110-38
3E5	FEEDER HOUSE TIGHTENERS (VAR. DR.).....	110-32
3D4	FEEDER HOUSE TOP SHEETS.....	110-7
3E2	FEEDER HOUSE UPPER CTRSHAFT.SUPTS-VAR.DR.....	110-29
3E2	FEEDER HOUSE UPPER CTRSHAFT-VARIABLE DR.....	110-29
3E9	FEEDER HOUSE UPPER SHAFT (LONG).....	110-37
3E4	FEEDER HOUSE UPPER SHAFT (VARIABLE DR.).....	110-31
3D4	FEEDER HOUSE, TOP DOOR LEVER.....	110-7
1F15	FEEDER HSE.LOWER SHAFT SPD.SENSOR-REG.....	40-24
3D17	FEEDER HSE.MIDDLE IDLER BRACES,LH-VAR.DR.....	110-21
1G7	FIELD LIGHTS.....	40-41
3C4	FILTER AND HOUSING, CAB AIR.....	90-31
3C4	FILTER, CAB AIR.....	90-31

COMBINE - 8820 PC-1668 (27-FEB-79) LITHO IN U.S.A.

ALPHABETICAL INDEX - CONTINUED

GRID	PAGE	GRID	PAGE
3G21	HANDLE, STRAW CHOPPER KNIFE AND SUPPORT..... 120-54	1D22	HOUSING, FUEL INJECTION PUMP..... 30-21
4A22	HANDRAIL, GRAIN TANK..... 130-3	1E5	HOUSING, FUEL INJECTION PUMP GOVERNOR..... 30-26
3A22	HANDRAIL, OPERATOR'S PLATFORM..... 90-3	4C6	HOUSING, HORIZONTAL UNLOADING AUGER..... 130-35
3B2	HANDRAILS, OPERATOR'S PLATFORM (TRACKS)..... 90-5	2C18	HOUSING, HYDROSTATIC DRIVE PUMP..... 50-43
3C10	HARNESS, COMPRESSOR..... 90-37	2B23	HOUSING, INNER, FINAL DRIVE..... 50-25
1F14	HARNESS, FEEDER HOUSE SPEED MONITORING..... 40-23	2E3	HOUSING, KNEE AND MOTOR (PRWD)..... 50-75
1F3	HARNESS, LOW SHAFT SPEED MONITOR'S..... 40-11	3J2	HOUSING, LOADING AUGER..... 120-105
1H6	HARNESS, MAGNETIC PICK-UP..... 40-63	3J8	HOUSING, LOWER TAILINGS..... 120-111
1F8	HARNESS, SEPARATOR, RIGHT-HAND..... 40-17	1B19	HOUSING, OIL COOLER BYPASS..... 20-24
1G4	HARNESS, WIRING, CAB ROOF..... 40-37	1B19	HOUSING, OIL PUMP, COMPLETE..... 20-24
1F19	HARNESS, WIRING, INSTRUMENT PANEL..... 40-29	2B21	HOUSING, OUTER, FINAL DRIVE..... 50-23
1F14	HARNESS, WIRING, LEFT-HAND LIGHTS..... 40-23	2E1	HOUSING, PLANETARY (PRWD)..... 50-73
1F14	HARNESS, WIRING, OPERATOR'S PLATFORM..... 40-23	3H10	HOUSING, SHOE GRAIN SUPPLY AUGERS..... 120-67
1E19	HARNESS, WIRING, REAR HOOD..... 40-3	1H8	HOUSING, STARTER DRIVE..... 40-65
1E19	HARNESS, WIRING, SEPARATOR (L.H.)..... 40-3	3G16	HOUSING, STRAW CHOPPER..... 120-49
1E19	HARNESS, WIRING, UNLOADING AUGER..... 40-3	3J10	HOUSING, TAILINGS ELEVATOR..... 120-113
4D13	HARNES,WIRING,AUTOMATIC HDT.HGT.CTL..... 160-11	1D13	HOUSING, THROTTLE LINKAGE, CONTROL LEVER..... 30-11
1F10	HARNESSES, WIRING, ENGINE COMPARTMENT..... 40-19	2B12	HOUSING, TRANSMISSION..... 50-13
1B8	HEAD, CYLINDER..... 20-12	3J13	HOUSING, UPPER TAILINGS AUGER..... 120-116
1E23	HEADER ELECTROMAGNETIC CLUTCH..... 40-8	2D22	HOUSING, WHEEL HUB, AND MOTOR (PRWD)..... 50-71
3D9	HEADER LIFT HYDRAULIC CYLINDER..... 110-12	2F22	HOUSING,WHL.MOTOR-POWER REAR WHEEL DRIVE..... 60-31
2I5	HEADER LIFT OIL LINES AND HOSES..... 70-51	1C5	HOUSINGS, TURBOCHARGER..... 20-34
3C1	HEADLINER, CAB ROOF..... 90-28	2D22	HUB,MOTOR, AND HOUSING, WHEEL (PRWD)..... 50-71
3C15	HEATER CONTROL VALVE..... 90-43	2F20	HUB,REAR AXLE SPINDLES-HVY-DTY REAR AXLE..... 60-29
3C15	HEATER HOSES..... 90-43	2H9	HYD.OIL LINES AND HOSES,AUGER SWING..... 70-31
3C16	HEATER HOSES..... 90-44	2I7	HYDRAULIC BELT TENSIONING SYSTEM..... 70-53
1C11	HEATER, ENGINE COOLANT..... 20-40	2G14	HYDRAULIC CONTROL MAIN, RELIEF VALVE..... 70-11
2J9	HINGE, UPPER DOOR, ENGINE COMPARTMENT..... 80-19	2G16	HYDRAULIC CONTROL MAIN, RELIEF VALVE..... 70-13
2F17	HITCH, REAR AXLE SUPPORT..... 60-26	2G13	HYDRAULIC CONTROL VALVE POPPETS, MAIN..... 70-10
2I21	HOOD, REAR..... 80-7	2G15	HYDRAULIC CONTROL VALVE POPPETS, MAIN..... 70-12
1E19	HOOD, REAR, WIRING HARNESS..... 40-3	2G14	HYDRAULIC CONTROL VALVE SPOOLS, MAIN..... 70-11
4C4	HORIZONTAL UNLDG.AUGER DRIVE GEAR CASE..... 130-33	2G16	HYDRAULIC CONTROL VALVE SPOOLS, MAIN..... 70-13
4B4	HORIZONTAL UNLDG.AUGER SWIVEL SHROUD..... 130-7	2G13	HYDRAULIC CONTROL VALVE SPRINGS, MAIN..... 70-10
4C6	HORIZONTAL UNLOADING AUGER AND HOUSING..... 130-35	2G15	HYDRAULIC CONTROL VALVE SPRINGS, MAIN..... 70-12
4C2	HORIZONTAL UNLOADING AUGER SWIVEL..... 130-31	3D9	HYDRAULIC CYLINDER, HEADER LIFT..... 110-12
1F14	HORN..... 40-23	2I4	HYDRAULIC HOSE,VARIABLE DRIVE FDR.HOUSE..... 70-50
1F21	HORN SWITCH..... 40-31	2E8	HYDRAULIC HOSES (PRWD)..... 50-81
4D11	HOSE AND LINES, OIL COOLER..... 160-9	2H22	HYDRAULIC HOSES, REEL..... 70-45
2I4	HOSE,HYDRAULIC,VARIABLE DRIVE FDR.HSE..... 70-50	2E8	HYDRAULIC LINES (PRWD)..... 50-81
1C18	HOSES..... 20-47	2E9	HYDRAULIC LINES AND HOSES (PRWD)..... 50-83
2H9	HOSES AND LINES, AUGER SWING HYD. OIL..... 70-31	2G21	HYDRAULIC OIL HOSES..... 70-19
2I5	HOSES AND LINES, HEADER LIFT OIL..... 70-51	4D9	HYDRAULIC OIL LINE AUTO.HDR.HGT.CONTROL..... 160-7
2E9	HOSES AND LINES, HYDRAULIC (PRWD)..... 50-83	2G20	HYDRAULIC OIL LINES AND HOSES..... 70-17
2G20	HOSES AND LINES, HYDRAULIC OIL..... 70-17	2G23	HYDRAULIC OIL LINES AND HOSES..... 70-21
2G23	HOSES AND LINES, HYDRAULIC OIL..... 70-21	2G6	HYDRAULIC OIL RESERVOIR..... 70-3
2E11	HOSES AND LINES, HYDRAULIC OIL RETURN..... 50-85	2E11	HYDRAULIC OIL RETURN LINES AND HOSES..... 50-85
2F10	HOSES AND LINES,STEERING OIL-FRONT..... 60-19	1C20	HYDRAULIC PUMP DRIVE IDLER..... 20-49
2D6	HOSES AND OIL COOLER,HYDROSTATIC DRIVE..... 50-54	2H23	HYDRAULIC PUMP MTG.,REEL,HYDROSTATIC DR..... 70-46
2F12	HOSES AND OIL LINES,STEERING-REAR..... 60-21	2H18	HYDRAULIC PUMP, HYDROSTATIC DRIVE REEL..... 70-41
1C18	HOSES AND RADIATOR..... 20-47	2G8	HYDRAULIC PUMP, MAIN..... 70-5
3C15	HOSES, HEATER..... 90-43	2H14	HYDRAULIC REEL LIFT CONTROL LEVER..... 70-37
3C16	HOSES, HEATER..... 90-44	2I12	HYDRAULIC REEL LIFT DRIVE SHEAVES..... 70-58
2E8	HOSES, HYDRAULIC (PRWD)..... 50-81	2I13	HYDRAULIC REEL LIFT DRIVE SHEAVES..... 70-59
2G21	HOSES, HYDRAULIC OIL..... 70-19	2C18	HYDRO. DR. PUMP CYLINDER BLOCK ASSEMBLY..... 50-43
2H22	HOSES, REEL HYDRAULIC..... 70-45	2C20	HYDRO. DR. PUMP SERVO PISTON ASSEMBLIES..... 50-45
1F21	HOURLMETER..... 40-31	2C8	HYDRO. DRIVE CONTROL CABLE AND LEVER..... 50-33
3D6	HOUSE, FEEDER, BOTTOM SHEETS..... 110-9	2C10	HYDRO. DRIVE CONTROL CABLE MOUNTING..... 50-35
4B23	HOUSING AND AUGER, VERTICAL, GRAIN TANK..... 130-29	2C22	HYDRO. DRIVE DISPLACEMENT CONTROL VALVE..... 50-47
3C4	HOUSING AND FILTER, CAB AIR..... 90-31	2C23	HYDRO. DRIVE PRESSURE OVERRIDE VALVE..... 50-48
4B16	HOUSING AND SHIELD, SUMP, GRAIN TANK..... 130-21	2C23	HYDRO.DR.DISPLACEMENT CONTROL HANDLE..... 50-48
3I18	HOUSING, CLEAN GRAIN ELEVATOR..... 120-99	2C23	HYDRO.DR.DISPLACEMENT CTL.VALVE GASKET..... 50-48
3I14	HOUSING, CLEAN GRAIN LOWER AUGER..... 120-95	2C23	HYDRO.DR.DISPLACEMENT CTL.VALVE ORIFICE..... 50-48
3I16	HOUSING, CLEAN GRAIN LOWER AUGER..... 120-97	2C16	HYDRO.DR.PUMP FRONT COVER-BRG-SEAL ASSY..... 50-41
3I9	HOUSING, CLEANING FAN..... 120-89	2C19	HYDRO.DR.PUMP SWASHPLATE,BRGs,TRUNNIONS..... 50-44
1B6	HOUSING, CRANKSHAFT OIL SEAL..... 20-10	2C12	HYDROSTATIC DR. MOTOR MOUNTING & COUPLER..... 50-37
2B12	HOUSING, DIFFERENTIAL..... 50-13	2I1	HYDROSTATIC DR. REEL FLOW CONTROL VALVE..... 70-47
2C3	HOUSING, FINAL DRIVE (CRAWLER TRACKS)..... 50-28	2C6	HYDROSTATIC DR.BELT TENSIONING MECHANISM..... 50-31

COMBINE - 8820 PC-1668 (27-FEB-79) LITHO IN U.S.A.