

John Deere

CLICK ANYWHERE FOR MORE DETAILS

MODEL:

4239D and 4239T

Engines & Accessories

**PARTS
MANUAL**



JENSALES.COM
or Call **800-443-0625**

CLICK ANYWHERE FOR MORE DETAILS

THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
JOHN DEERE OR IT'S SUCCESSORS. JOHN DEERE AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

JD-P-PC3153

4239D and 4239T

**OEM Engines
and
Accessories**

CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

JENSALES®

purchase full manual at

JENSALES.COM

or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

John Deere Usine de Saran

PC-3153

R68462

SECTION INDEX

GENERAL INFORMATION	5
ENGINE	10
ENGINE ACCESSORIES	15
COOLING SYSTEM	20
FUEL SYSTEM	25
FUEL INJECTION PUMP	30
ELECTRICAL SYSTEM	85
NUMERICAL INDEX	95

MANUAL PREVIEW

JENSALES®

purchase full manual at

JENSALES.COM
or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

ALPHABETICAL INDEX

GRID		PAGE	GRID		PAGE
A					
F13	ADVANCE GROUP, FUEL INJECTION PUMP	30-37	D3	COVER, THERMOSTAT HOUSING (4239T)	20-6
F21	ADVANCE GROUP, FUEL INJECTION PUMP	30-46	B25	COVER, TIMING GEAR	10-26
G7	ADVANCE GROUP, FUEL INJECTION PUMP	30-56	B7	CRANKSHAFT (4239D)	10-14
G13	ADVANCE GROUP, FUEL INJECTION PUMP		B9	CRANKSHAFT PULLEY (4239D)	10-14B
	(4239T)	30-62	B11	CRANKSHAFT PULLEY (4239D) AND (4239T)	10-15A
C14	AIR INLET (4239D)	15-5	B10	CRANKSHAFT PULLEY (4239T)	10-15
C15	AIR INLET (4239T)	15-6	A17	CYLINDER BLOCK	10-2
G19	ALTERNATOR	85-3	B5	CYLINDER HEAD	10-12
H3	ALTERNATOR	85-6D	B6	CYLINDER HEAD (4239T)	10-13
H4	ALTERNATOR	85-7	A25	CYLINDER LINER (4239D)	10-8
G22	ALTERNATOR (35A)	85-4	A25	CYLINDER LINER O-RINGS (4239D)	10-8
G17	ALTERNATOR (4239D)	85-1	D		
G18	ALTERNATOR (4239D)	85-2	A24	DIPSTICK	10-6
G24	ALTERNATOR (4239D)	85-6	F7	DRIVE GROUP, FUEL INJECTION PUMP	30-31
G20	ALTERNATOR (4239T)	85-3A	E5	DRIVE, FUEL INJECTION PUMP	30-2
H2	ALTERNATOR (4239T)	85-6C	E14	DRIVE, FUEL INJECTION PUMP	30-11
G23	ALTERNATOR (55A)	85-5	E22	DRIVE, FUEL INJECTION PUMP	30-20
H1	ALTERNATOR (55A)	85-6B	F17	DRIVE, FUEL INJECTION PUMP	30-42
G20	ALTERNATOR WIRING HARNESS	85-3A	G3	DRIVE, FUEL INJECTION PUMP	30-52
H20	ARMATURE, STARTING MOTOR	85-17	H19	DRIVE, STARTING MOTOR	85-16
H8	ATTACHING PARTS, STARTING MOTOR	85-8A	E		
E10	AUTOMATIC ADVANCE, FUEL INJECTION PUMP	30-7	C10	ELBOW, EXHAUST (4239T)	15-3
E19	AUTOMATIC ADVANCE, FUEL INJECTION PUMP	30-16	B2	ENGINE BALANCER SHAFT	10-10
F3	AUTOMATIC ADVANCE, FUEL INJECTION PUMP	30-26	C7	ENGINE COOLING FLUID	10-33
B11	AUXILIARY FRONT DRIVE, PULLEY	10-15A	B20	ENGINE FLYWHEEL	10-21
B			A21	ENGINE FRONT PLATE	10-3
B2	BALANCER SHAFT, ENGINE	10-10	B5	ENGINE LIFT STRAP	10-12
B4	BEARING, MAIN	10-11	B6	ENGINE LIFT STRAP (4239T)	10-13
B4	BEARING, MAIN THRUST	10-11	C16	ENGINE MOUNTS	15-7
D4	BELT, FAN (4239D)	20-7	A16	ENGINE OIL	10-1
D6	BELT, FAN (4239T)	20-9	B18	ENGINE OIL COOLER (4239D)	10-20A
D4	BLADE, FAN (4239D)	20-7	B19	ENGINE OIL COOLER (4239T)	10-20B
D5	BLADE, FAN (4239T)	20-8	A24	ENGINE OIL DIPSTICK	10-6
A17	BLOCK, CYLINDER	10-2	C1	ENGINE OIL FILLER INLET	10-27
A19	BLOCK, SHORT	10-2B	A24	ENGINE OIL FILTER	10-6
A25	BUSHING, CONNECTING ROD (4239D)	10-8	B14	ENGINE OIL PUMP (4239D)	10-18
B1	BUSHING, CONNECTING ROD (4239T)	10-9	B15	ENGINE OIL PUMP (4239T)	10-19
C			C4	ENGINE OVERHAUL GASKET SET	10-30
B12	CAMSHAFT	10-16	C3	ENGINE TUNE-UP GASKET SET	10-29
C1	CAP, OIL FILLER	10-27	B22	ENGINE VENTILATING SYSTEM	10-23
B23	CAP, OIL FILLER (4239D)	10-24	C10	EXHAUST ELBOW (4239T)	15-3
B24	CAP, OIL FILLER (4239T)	10-25	C9	EXHAUST MANIFOLD (4239D)	15-2
C13	CENTER HOUSING, TURBOCHARGER	15-4B	B12	EXHAUST VALVE	10-16
H20	COIL, STARTING MOTOR	85-17	F		
C6	CONDITIONER, SUMMER COOLANT	10-32	D4	FAN BELT (4239D)	20-7
A25	CONNECTING ROD (4239D)	10-8	D6	FAN BELT (4239T)	20-9
B1	CONNECTING ROD (4239T)	10-9	D4	FAN BLADE (4239D)	20-7
C6	COOLANT CONDITIONER	10-32	D5	FAN BLADE (4239T)	20-8
B18	COOLER, ENGINE OIL (4239D)	10-20A	C23	FAN PULLEY (HIGH POSITION)	20-1
B19	COOLER, ENGINE OIL (4239T)	10-20B	C24	FAN PULLEY (4239D)	20-2
C7	COOLING FLUID, ENGINE	10-33	C25	FAN PULLEY (4239T)	20-3
H14	COVER KIT, STARTER SOLENOID SWITCH	85-12B	C1	FILLER INLET, OIL	10-27
F1	COVER, FUEL INJECTION PUMP	30-24	A24	FILTER, ENGINE OIL	10-6
C17	COVER, MUFFLER	15-8	D11	FILTERS, FUEL (4239D)	25-4
C2	COVER, OIL FILLER INLET	10-28	D13	FILTERS, FUEL (4239T) (60 KW AND 70 KW)	25-4B
B14	COVER, OIL PUMP (4239D)	10-18	D14	FILTERS, FUEL (4239T) (65 KW AND 76 KW)	25-5
B23	COVER, ROCKER ARM (4239D)	10-24	C7	FLUID, ENGINE COOLING	10-33
B24	COVER, ROCKER ARM (4239T)	10-25	B21	FLYWHEEL	10-22
D2	COVER, THERMOSTAT HOUSING (4239D)	20-5			

B7 IDLER GEARS (4239D) 10-14

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
D25	INJECTION NOZZLE, FUEL	25- 16	N		
E1	INJECTION NOZZLE, FUEL	25- 17	D25	NOZZLE, FUEL INJECTION	25- 16
D15	INJECTION PUMP (4239D)	25- 6	E1	NOZZLE, FUEL INJECTION	25- 17
D17	INJECTION PUMP (4239D)	25- 8	D15	NOZZLE, INJECTION PUMP (4239D)	25- 6
D21	INJECTION PUMP (4239T)	25- 12	D17	NOZZLE, INJECTION PUMP (4239D)	25- 8
C14	INLET, AIR (4239D)	15- 5	D21	NOZZLE, INJECTION PUMP (4239T)	25- 12
C15	INLET, AIR (4239T)	15- 6	O		
C1	INLET, OIL FILLER	10- 27	B18	OIL COOLER, ENGINE (4239D)	10- 20A
I3	INSTRUMENT PANEL KIT	85- 20	B19	OIL COOLER, ENGINE (4239T)	10- 20B
B12	INTAKE VALVE	10- 16	C1	OIL FILLER INLET	10- 27
K			C2	OIL FILLER INLET COVER	10- 28
B16	KIT, ENGINE OIL PUMP OUTLET TUBE REPLACEMENT	10- 19A	A24	OIL FILTER	10- 6
F5	KIT, FUEL INJECTION PUMP GASKET OVERHAUL	30- 28	C12	OIL LINES, TURBOCHARGER (4239T)	15- 4A
G2	KIT, FUEL INJECTION PUMP OVERHAUL	30- 51	A22	OIL PAN (4239D)	10- 4
I3	KIT, INSTRUMENT PANEL	85- 20	A23	OIL PAN (4239T)	10- 5
I2	KIT, LEAD WIRE	85- 19	B25	OIL PRESSURE RELIEF VALVE	10- 26
C17	KIT, MUFFLER	15- 8	B14	OIL PUMP, ENGINE (4239D)	10- 18
C18	KIT, MUFFLER	15- 9	B15	OIL PUMP, ENGINE (4239T)	10- 19
A16	KIT, OFF-SEASON STORAGE	10- 1	A16	OIL, ENGINE	10- 1
C13	KIT, TURBOCHARGER CENTER HOUSING	15- 4B	F5	OVERHAUL KIT, FUEL INJECTION PUMP	30- 28
B8	KIT, UNDERSIZE CRANKSHAFT	10- 14A	F15	OVERHAUL KIT, FUEL INJECTION PUMP	30- 40
L			P		
I2	LEAD WIRE KIT	85- 19	A22	PAN, OIL (4239D)	10- 4
B5	LIFT STRAP, ENGINE	10- 12	A23	PAN, OIL (4239T)	10- 5
B6	LIFT STRAP, ENGINE (4239T)	10- 13	A25	PIN, PISTON (4239D)	10- 8
A25	LINER O-RINGS, CYLINDER (4239D)	10- 8	B1	PIN, PISTON (4239T)	10- 9
A25	LINER, CYLINDER (4239D)	10- 8	A25	PISTON (4239D)	10- 8
D19	LINES, FUEL INJECTION	25- 10	B1	PISTON (4239T)	10- 9
D15	LINES, FUEL INJECTION (4239D)	25- 6	A21	PLATE, ENGINE FRONT	10- 3
D17	LINES, FUEL INJECTION (4239D)	25- 8	B9	PULLEY, CRANKSHAFT (4239D)	10- 14B
D21	LINES, FUEL INJECTION (4239T)	25- 12	B10	PULLEY, CRANKSHAFT (4239T)	10- 15
E9	LINKAGE GROUP, FUEL INJECTION PUMP	30- 6	B11	PULLEY, CRANKSHAFT (4239D) AND (4239T)	10- 15A
E18	LINKAGE GROUP, FUEL INJECTION PUMP	30- 15	C23	PULLEY, FAN (HIGH POSITION)	20- 1
F12	LINKAGE GROUP, FUEL INJECTION PUMP	30- 36	C24	PULLEY, FAN (4239D)	20- 2
F22	LINKAGE GROUP, FUEL INJECTION PUMP	30- 47	C25	PULLEY, FAN (4239T)	20- 3
F1	LINKAGE, FUEL INJECTION PUMP	30- 24	B14	PUMP, ENGINE OIL (4239D)	10- 18
G8	LINKAGE, FUEL INJECTION PUMP	30- 57	B15	PUMP, ENGINE OIL (4239T)	10- 19
C6	LUBRICANT, VALVE STEM	10- 32	D19	PUMP, FUEL INJECTION	25- 10
M			D15	PUMP, FUEL INJECTION (4239D)	25- 6
B4	MAIN BEARING	10- 11	D17	PUMP, FUEL INJECTION (4239D)	25- 8
B4	MAIN THRUST BEARING	10- 11	D21	PUMP, FUEL INJECTION (4239T)	25- 12
C9	MANIFOLD, EXHAUST (4239D)	15- 2	D23	PUMP, FUEL INJECTION (4239T)	25- 14
C10	MANIFOLD, EXHAUST (4239T)	15- 3	D8	PUMP, FUEL TRANSFER	25- 2
H5	MOTOR, STARTING	85- 7A	D9	PUMP, FUEL TRANSFER	25- 2A
H6	MOTOR, STARTING	85- 7B	C23	PUMP, WATER (HIGH POSITION)	20- 1
H7	MOTOR, STARTING	85- 8	C24	PUMP, WATER (4239D)	20- 2
H21	MOTOR, STARTING	85- 18	C25	PUMP, WATER (4239T)	20- 3
H22	MOTOR, STARTING	85- 18B	R		
C16	MOUNTS, ENGINE	15- 7	G19	REGULATOR, VOLTAGE	85- 3
C17	MUFFLER	15- 8	H3	REGULATOR, VOLTAGE	85- 6D
C18	MUFFLER	15- 9	H4	REGULATOR, VOLTAGE	85- 7
C17	MUFFLER COVER	15- 8	G17	REGULATOR, VOLTAGE (4239D)	85- 1
C13	MUFFLER COVER	15- 9	G18	REGULATOR, VOLTAGE (4239D)	85- 2
C17	MUFFLER KIT	15- 8	B16	REPLACEMENT ENGINE OIL PUMP OUTLET TUBE KIT	10- 19A
C18	MUFFLER KIT	15- 9	B20	RING GEAR, FLYWHEEL	10- 21
			A25	RINGS, PISTON (4239D)	10- 8

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE
B1	RINGS, PISTON (4239T)	10- 9
B23	ROCKER ARM COVER (4239D)	10- 24
B24	ROCKER ARM COVER (4239T)	10- 25
A25	ROD, CONNECTING (4239D)	10- 8
B1	ROD, CONNECTING (4239T)	10- 9
E15	ROTOR GROUP, FUEL INJECTION PUMP	30- 12
E6	ROTOR, FUEL INJECTION PUMP	30- 3
E22	ROTOR, FUEL INJECTION PUMP	30- 20
F9	ROTOR, FUEL INJECTION PUMP	30- 33
F20	ROTOR, FUEL INJECTION PUMP	30- 45
G5	ROTOR, FUEL INJECTION PUMP	30- 54

5

C4	SET, GASKET, ENGINE OVERHAUL	10-30
C3	SET, GASKET, ENGINE TUNE-UP	10-29
B2	SHAFT, ENGINE BALANCER	10-10
B12	SHAFT, ROCKER ARM	10-16
G17	SHIELD, ALTERNATOR (4239D)	85-1
G18	SHIELD, ALTERNATOR (4239D)	85-2
A19	SHORT BLOCK	10-2B
F14	SHUT-OFF FUEL INJECTION PUMP	30-38
F23	SHUT-OFF GROUP, FUEL INJECTION PUMP	30-48
E11	SHUT-OFF, FUEL INJECTION PUMP	30-8
E20	SHUT-OFF, FUEL INJECTION PUMP	30-17
G10	SHUT-OFF, FUEL INJECTION PUMP	30-59
I1	SOLENOID SWITCH	85-18F
H18	SOLENOID SWITCH (DELCO-REMY)	85-15
H14	SOLENOID SWITCH COVER KIT, STARTER	85-12B
H13	SOLENOID SWITCH KIT, STARTER	85-12A
H12	SOLENOID SWITCH, STARTER	85-12
H15	SOLENOID SWITCH, STARTER	85-12C
H21	SOLENOID, STARTING MOTOR	85-18
H5	STARTER	85-7A
H7	STARTER	85-8
H16	STARTER (DELCO-REMY)	85-13
H17	STARTER (DELCO-REMY)	85-14
H18	STARTER (DELCO-REMY)	85-15
H9	STARTER (JOHN DEERE)	85-9
H10	STARTER (JOHN DEERE)	85-10
H11	STARTER (JOHN DEERE)	85-11
H12	STARTER SOLENOID SWITCH	85-12
H15	STARTER SOLENOID SWITCH	85-12C
H14	STARTER SOLENOID SWITCH COVER KIT	85-12B
H13	STARTER SOLENOID SWITCH KIT	85-12A
H6	STARTING MOTOR	85-7B
H21	STARTING MOTOR	85-18
H20	STARTING MOTOR ARMATURE	85-17
H8	STARTING MOTOR ATTACHING PARTS	85-8A
H20	STARTING MOTOR COIL	85-17
H24	STARTING MOTOR COIL ASSEMBLY	85-18D
H25	STARTING MOTOR COIL ASSEMBLY	85-18E
H19	STARTING MOTOR DRIVE	85-16
H23	STARTING MOTOR DRIVE AND SWITCH	85-18C
H20	STARTING MOTOR HOUSING	85-17
H21	STARTING MOTOR SOLENOID	85-18
H19	STARTING MOTOR SWITCH	85-16
H5	STARTING, MOTOR	85-7A
H22	STARTING, MOTOR	85-18B
C6	STOP LEAK	10-32
B5	STRAP, ENGINE LIFT	10-12
B6	STRAP, ENGINE LIFT (4239T)	10-13
C6	SUMMER COOLANT CONDITIONER	10-32
H13	SWITCH KIT, STARTER SOLENOID	85-12A
H18	SWITCH, SOLENOID (DELCO-REMY)	85-15
H12	SWITCH, STARTER SOLENOID	85-12

GRID		PAGE
H15	SWITCH, STARTER SOLENOID	85-12C
H19	SWITCH, STARTING MOTOR	85-16
D19	SYSTEM, FUEL INJECTION	25-10
D23	SYSTEM, FUEL INJECTION (4239T)	25-14

T

D1	THERMOSTAT (4239D)	20-4
D1	THERMOSTAT (4239T)	20-4
D2	THERMOSTAT HOUSING (4239D)	20-5
D3	THERMOSTAT HOUSING (4239T)	20-6
B25	TIMING GEAR COVER	10-26
E7	TRANSFER GROUP, FUEL INJECTION PUMP	30-4
E16	TRANSFER GROUP, FUEL INJECTION PUMP	30-13
E24	TRANSFER GROUP, FUEL INJECTION PUMP	30-22
F10	TRANSFER GROUP, FUEL INJECTION PUMP	30-34
F18	TRANSFER GROUP, FUEL INJECTION PUMP	30-43
G4	TRANSFER GROUP, FUEL INJECTION PUMP	30-53
D8	TRANSFER PUMP, FUEL	25-2
D9	TRANSFER PUMP, FUEL	25-2A
B22	TUBE, ROCKER ARM COVER	10-23
C10	TURBOCHARGER (4239T)	15-3
C13	TURBOCHARGER CENTER HOUSING	15-4B
C13	TURBOCHARGER CENTER HOUSING KIT	15-4B
C12	TURBOCHARGER OIL LINES (4239T)	15-4A

L

B8 UNDERSIZE CRANKSHAFT KIT 10- 14A

✓

C6	VALVE STEM LUBRICANT	10-32
B12	VALVE, EXHAUST	10-16
B12	VALVE, INTAKE	10-16
B25	VALVE, OIL PRESSURE RELIEF	10-26
B22	VENTILATING SYSTEM, ENGINE	10-23
G19	VOLTAGE REGULATOR	85-3
H3	VOLTAGE REGULATOR	85-6D
H4	VOLTAGE REGULATOR	85-7
G17	VOLTAGE REGULATOR (4239D)	85-1
G18	VOLTAGE REGULATOR (4239D)	85-2

Y

C23	WATER PUMP (HIGH POSITION)	20- 1
C24	WATER PUMP (4239D)	20- 2
C25	WATER PUMP (4239T)	20- 3
G20	WIRING HARNESS, ALTERNATOR	85- 3A