



CLICK ANYWHERE FOR MORE DETAILS

MANUAL PREVIEW

Rumely
Parts Manual
B, E & F

purchase full manual at

Parts Manual

JENSALES.COM

or Call 800-443-0625



CLICK ANYWHERE FOR MORE DETAILS

THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
RUMELY OR IT'S SUCCESSORS. **RUMELY** AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

RU-P-B,E,F

CLICK ANYWHERE FOR MORE DETAILS

NO. 24

REPAIR PARTS LIST

FOR

B, E, and F

OIL PULL TRACTOR

ON ACCOUNT OF HIGH FREIGHT RATES, BRANCHES WEST OF
ROCKY MOUNTAINS WILL ADD 10% TO PRICES QUOTED IN
SUPPLEMENTARY LISTS. WE ADMIRE YOUR COOPERATION.

purchase full manual at

RUMELY

Rumely
TRACTOR
LA PORTE IND.

JENSALES.COM

or Call 800-443-0625

LaPORTE, . . INDIANA

CLICK ANYWHERE FOR MORE DETAILS

CLICK ANYWHERE FOR MORE DETAILS

Notes for Use of Price List

1st. Parts are arranged by assemblies. Thus all Exhaust parts are listed under "Exhaust"; all Pump Parts under "Pumps," etc. Assemblies appear in alphabetical order.

2nd. Illustrations in back of price list are arranged the same as text.

3rd. Do not order from illustrations without referring to Text to see if part was used on your Engine. The illustrations are merely a guide to refer you to the proper section of the Price List. The part you want may be a similar part but not interchangeable.

4th. The number of your Engine is stamped on the end of your Crank Shaft.

5th. In the construction of the OilPull Tractors four distinct series of numbers have been utilized. Therefore, there are a large number of parts on the latest Tractors which are wholly interchangeable with those on the older types, although they bear different symbol numbers. As it was found impractical to incorporate the information indicating just what parts were interchangeable in the general Text of the Price List, we formulated an index showing old and new symbol numbers and giving the page on which would be found the description. In preparing this list we have employed only the latest symbol numbers in describing parts. This will be found on pages 57 to 69 inclusive.

6th. All parts are described as being used on B. E. or F. OilPulls, the size of which are as follows:

B.
25-45

E.
30-60

F.
15-30 or 18-35

JENSALES.COM
or Call 800-443-0625

CLICK ANYWHERE FOR MORE DETAILS

Alphabetical Index to B, E and F OilPull Repairs List

Auxiliary Exhaust Parts	1
Air Heaters	9
Axles, Front	20
Axles, Rear	37
Air Starter	50
Air Starter, Hand	51

B	
Band Wheels	1
Bearings, Cam Shaft	4
Bearings, Connecting Rod	10
Bearings, Differential Shaft	15
Bearings, Idler Shaft	23
Bearings, Rear Axle	37
Bearings, Reversing Shaft	40
Bearings, Steering Spindle	46
Bolts, Carriage	51
Bolts, Coupling	51
Bolts, Machine	51
Bolts, Stove	52
Box, Tool	50
Brackets, Brake Shoe	3
Brackets, Cam Shaft	4
Brackets, Clutch	2
Brackets, Ignition Tripper	26
Brackets, Ignition Push Rod	25
Brackets, Lubricator	28
Brackets, Magneto	29
Brackets, Plunger Pump	35
Brackets, Reach Rod	21
Brackets, Steering Winding Spool	46
Brackets, Truss Rod	49
Brake Parts	3
Bushing, Band Wheel	1
Bushing, Connecting Rod	10
Bushing, Differential Bevel Gear	16
Bushing, Differential Bevel Pinion	16
Bushing, Exhaust Valve Bell Crank	18
Bushing, Exhaust Valve Cage	18
Bushing, Governor Bearing	22
Bushing, Inlet Valve Bell Crank	26
Bushing, Inlet Valve Cage	27
Bushing, Master Pinion	31
Bushing, Plunger Pump Eccentric Arm	35

C	
Cam Shaft and Parts	3
Canopy and Parts	5
Cap Screws	54
Carriage Bolts	51
Carburetor and Parts	6
Centrifugal Pump	33
Clutch Parts	1
Connecting Rod and Parts	10
Cotters	52
Counterbalance Weights	12
Coupling Bolts	51
Crank Case	10
Crank Shaft	11
Cylinders, Cylinder Heads, etc	14

D	
Differential Parts	15
Draw Bar or Plow Beam	32
Dreadnaught Steering Guide Parts	50

E	
Exhaust, Auxiliary and Parts	1
Exhaust Parts	18

F	
Fly Wheel	13
Frame Parts	47
Front Axle and Parts	20

G	
Gaskets, Auxiliary Exhaust Throttle Valve Body	1
Gaskets, Cam Shaft Reduction Gear Cover	5
Gaskets, Crank Case Manhole Cover	11
Gaskets, Cylinder Head	14
Gaskets, Exhaust Coupling Rod Stuffing Box	19
Gaskets, Exhaust Pipe Flange	20
Gaskets, Exhaust Valve Cage	18
Gaskets, Ignition Plug Body	24
Gaskets, Inlet Valve Cage	27
Gasoline Pump and Parts	35
Gasoline Tank	47
Gear, Cam Shaft Reduction	5
Gear, Differential Bevel	15
Gear, Differential Spur	17
Gear, Governor Bevel	22
Gear, Idler, twin	28
Gear, Magneto Bevel	29
Gear, Master	30
Gear, Pump Shaft	34
Gear, Reversing	41
Geared Fuel Pump	35
Governor and Parts	22
Guide, Dreadnaught Steering	50

H	
Hand Air Starter	50
Hubs, Extension Rim	40
Hubs, Front Wheel	22
Hubs, Rear Wheel	39

I	
Idler Parts	23
Ignition Parts	24
Inlet Parts	26

K	
Kerosene Tanks	47

L	
Lubricators and Parts	28
Lock Washers	56

M	
Machine Screws	55
Magnetos and Parts	29
Master Gear, Pinions, etc	30

N	
Nuts	53

P	
Pedestal Parts	31
Pinions, Clutch	1
Pinions, Crank Shaft Reduction	13
Pinions, Differential Bevel	16
Pinions, Governor Bevel	22
Pinions, Magneto	30
Pinions, Reversing (high and low speed)	41

R	
Radiators and parts	35
Reach Rods	21
Rear Axle and parts	37
Rear Wheels and parts	38
Reversing and parts	40
Rivets	53
Rod, connecting	10
Rod, Truss	49

or Call 800-443-0625

INDEX TO NO. OF PART OILPULL TRACTOR REPAIRS PRICE LIST

S

Screws, Cap.....	54
Screws, Machine.....	55
Screws, Set.....	55
Shaft, Cam.....	3
Shafting, Carburetor mixture control.....	7
Shafting, Crank.....	11
Shafting, Differential.....	17
Shafting, Front Axle.....	20
Shafting, Idler.....	23
Shafting, Ignition Spark Adjusting.....	25
Shafting, Magneto Coupling.....	30
Shafting, Pump (centrifugal).....	34
Shafting, Rear Axle.....	37
Shafting, Reversing.....	40
Shafting, Speed Changing.....	44
Shafting, Starting Lever.....	45
Shafting, Steering Spindle.....	45
Shield, Master Gear.....	31
Shield, Clutch Pinion and Reversing Gear.....	41
Speed Changing Parts.....	44
Spring, Carburetor Needle Valve.....	8
Spring, Crank Case Vent Valve.....	11
Spring, Exhaust Valve.....	18
Spring, Foot Brake Lever.....	3
Spring, Governor.....	22
Spring, Ignition Plug.....	24
Spring, Ignition Push Rod.....	25
Spring, Ignition Spark Adjusting.....	25
Spring, Ignition Tripper.....	26
Spring, Inlet Valve.....	26
Spring, Plunger Pump.....	35
Spring, Reversing and Speed Hand Lever.....	43
Spring, Reversing Hand Lever.....	43
Spring, Speed Changing Device Hand Grip.....	44

Spring, Speed Changing Device.....	44
Spring, Starting Device.....	45
Spokes, Extension Rim.....	40
Spokes, Front Wheel.....	22
Spokes, Rear Wheel.....	39
Starter, Air.....	50
Starter, Hand Air.....	51
Starting Device Parts.....	44
Steering Parts.....	45
Stove Bolts.....	52
Studs.....	55

T

Tanks, Gasoline.....	47
Tanks, Kerosene.....	47
Tanks, Water.....	47
Tool Box.....	50
Tractor Frame Parts.....	47
Truss Rods.....	49

V

Valves, Exhaust.....	18
Valves, Inlet.....	26

W

Washers, Spring, Lock.....	56
Washers, Standard, Wrought.....	56
Water Tanks.....	47
Weights, Counterbalance.....	12
Wheels, Band.....	1
Wheels, Fly.....	13
Wheels, Front.....	21
Wheels, Rear.....	38

purchase full manual at

JENSALES.COM
or Call **800-443-0625**

CLICK ANYWHERE FOR MORE DETAILS

Rumely B, E and F OilPull Repairs Price List

CODE	No. of Part	DESCRIPTION	Pcs.	Price	Dols.	Cts.
Oakenpin.....	3001	Auxiliary Exhaust Throttle Valve Body, R. H. Bored for 2 3/8" Throttle. Used on all B. E. and F. Oilpulls equipped with Auxiliary Exhaust, except "B" 1 to 42. Uses four S51 Studs and four S52 Nuts.		5.50		
Oakling.....	3002	Auxiliary Exhaust Throttle Valve Body, L. H. Bored for 2 3/8" Throttle. Used on all B. E. and F. OilPulls equipped with Auxiliary Exhaust, except "B" 1 to 42. Uses four S51 studs and four S52 nuts.		6.60		
Oakum.....	3003	Auxiliary Exhaust Throttle Valve Body Gasket. 2 used on all B. E. and F. OilPulls equipped with Auxiliary Exhaust.		.70		
Oarionem.....	3596	Auxiliary Exhaust Pipe Flange. 2 inch inside diameter. 2 used on all B. E. and F. OilPulls equipped with Auxiliary Exhaust except "B" 1 to 51.		2.20		
Oarsman.....	3678	Auxiliary Exhaust Pipe Flange Gasket. 2 used on all B, E and F OilPulls equipped with Auxiliary Exhaust.		.60		
Obadias.....	3004	Auxiliary Exhaust Throttle Valve Shaft. 2 used on all B and E OilPulls equipped with Auxiliary Exhaust.		.55		
Obadja.....	4000	Auxiliary Exhaust Throttle Valve Shaft. 1 used on all "F" OilPulls equipped with Auxiliary Exhaust.		.55		
Oxurique.....	7275	Auxiliary Exhaust Hole Cover, R. H. For use on all B, E and F OilPulls originally equipped with Auxiliary Exhaust, same being later discontinued.		1.10		
Oxyadene.....	7276	Auxiliary Exhaust Hole Cover, L. H. For B and E OilPulls. (See description above.)		3.05		
BAND WHEEL AND CLUTCH						
Obagitabat.....	5158	Band Wheel complete with Pinion and Bushing. Used on all B OilPulls.		170.50		
Oxyalmes.....	A2D287	Band Wheel Complete with Pinion and Bushing. Used on all E OilPulls.		170.50		
Oxyanthe.....	A2D93	Band Wheel Complete with Pinion and Bushing. Used on all F OilPulls.		121.00		
Obardescet.....	4003	Band Wheel Complete with Bushing. 1 used on all F OilPulls. 30" diameter, 9 1/2" face.		93.50		
Obarmabat.....	3013	Band Wheel Complete with Bushing. 1 used on all B and E OilPulls. 36" diameter, 11" face.		137.50		
Obarmabis.....	1B381	Band Wheel Bushing, 5 5/8" outside diameter. 1 used on first few B OilPulls.		16.50		
Obarni.....	3014	Band Wheel Bushing. 5 1/4" outside diameter. 1 used on B and E OilPulls except first few B OilPulls.		16.50		
Obarsimus.....	4004	Band Wheel Bushing. 1 used on all F OilPulls.		13.50		
Oxybaphon.....	A2D42	Clutch Complete. 1 used on all E OilPulls. (No band wheel).		99.00		
Oxybase.....	A2D86	Clutch Complete. 1 used on all F OilPulls. (No band wheel).		77.00		
Obarsit.....	3015	Clutch Diaphragm. Use C2D90.				
Obatratus.....	C2D90	Clutch Diaphragm with Pins. 1 used on all B and E OilPulls.		40.00		
Obaudiet.....	4005	Clutch Diaphragm with Pins. 1 used on all F OilPulls.		24.20		
Obaurati.....	GK133	Clutch Diaphragm Key, 7/8"x1/8"x9". 1 used on all B, E and F OilPulls.		.50		
Obbam.....	5001	Clutch Pinion, 11 1/2" diameter, 4" face, 7 1/2" bore, 21 teeth. 1 used on all B OilPulls. (Standard) speed 1.9 per hour.		55.00		
Obbarum.....	3018	Clutch Pinion, 12 1/2" diameter, 4" face, 7 1/2" bore, 23 teeth. 1 used on all E OilPulls. (Standard) speed 1.9 per hour.		55.00		
Obbedendo.....	1C265	Clutch Pinion, 12 3/4" diameter, 2 1/2" face, 6 1/8" bore, 35 teeth. 1 used on all F OilPulls 5001 to 5193.		40.00		
Obbedienza.....	4006	Clutch Pinion, 12 3/4" diameter, 3 1/2" face, 6 1/8" bore, 35 teeth. 1 used on all F OilPulls 5194 and since.		45.00		
Obbedirono.....	5157	Clutch Pinion, 14" diameter, 4" face, 7 1/2" bore, 26 teeth. This pinion used only in conjunction with 5156 Reversing Shaft Gear. Will speed tractor to 2 1/2 miles per hour. Furnished as special equipment for all B OilPulls.		60.00		
Obbeditore.....	3982	Clutch Pinion, 15" diameter, 4" face, 7 1/2" bore, 28 teeth. This pinion used only in conjunction with 3983 Reversing Shaft Gear. Will speed tractor to 2 1/2 miles per hour. Furnished as special equipment for all E OilPulls.		60.00		
	7560	Clutch Pinion, 17" diameter, 4" face, 7 1/2" bore, 32 teeth. This pinion used only in conjunction with 7561 Reversible Shaft Gear. Will speed tractor to 3 miles per hour. Furnished as special equipment for all E OilPulls.		65.00		

In ordering Repairs by Telegraph use Code Word.

PREPAY
TELEGRAMS

Always give the Machine Number