



Wabco
Parts Manual
101F Scraper

Parts Manual

JENSALES.COM

or Call 800-443-0625

JENSALES

THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF
WABCO OR IT'S SUCCESSORS. WABCO AND IT'S SUCCESSORS
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

WAB-P-101FSCPR

INDEX

DESCRIPTION	PAGE NO.
AIR CLEANER	10
AIR SYSTEM - SCRAPER	114
- TRACTOR	70
AXLE & HUB	118
- FINAL DRIVE	34
BATTERY BOX	116
BLADE	98,100
BODY	98
BOTTOM, ROLLING	100
BRAKE SYSTEM	42
BRAKE, WHEEL - SCRAPER	120
- TRACTOR	44
CAB	94E
- EMERGENCY BRAKE	94A
- PARKING BRAKE	94B
CASE, TRANSMISSION	22
CHAIN, ELEVATOR	104
CLUTCHES	32B
CONTROLS - HYDRAULIC	60
- SCRAPER	58
- STEERING	52
- TRANSMISSION	56
COOLING, TRANSMISSION	66
CONVERTER, HOUSING	18
CONVERTER LOCK UP	28
CONVERTER SECTION	30
CYLINDER - EJECTOR	128
- HOIST	126
- STEERING	82
DECK	6
DIFFERENTIAL	38
EJECTOR CYLINDER	128
ELEVATOR	104
ELEVATOR CHAIN	104
ELEVATOR DRIVE	102
ENGINE EXHAUST	12
ENGINE MOUNTING	14
FENDERS	4 & 134
FINAL DRIVE	34
FRAME	2
FUEL SYSTEM	112
GEARBOX, ELEVATOR	102
GRILLE	8
HEATER	94D
HOIST CYLINDER	126
HYDRAULIC CONTROL VALVE	76
HYDRAULIC CONTROLS	60
HYDRAULIC PIPING - SCRAPER	124
- TRACTOR	68
HYDRAULIC PUMP	92,94
HYDRAULIC TANK	50
INSTRUMENT PANEL	48
LIGHT - HEAD	72
- TAIL	132


INDEX

DESCRIPTION	PAGE NO.
MANIFOLD VALVE	86
MOTOR, ELEVATOR	102
MUFFLER	12
PIPING, AIR - SCRAPER	114
- TRACTOR	70
PIPING - ENGINE	62
- FUEL	112
- HYDRAULIC - SCRAPER	124
- TRACTOR	68
- TRANSMISSION	64
PLANETARY - FINAL DRIVE	34
POWER CLUSTER - SCRAPER	130
- TRACTOR	80
POWER TAKE-OFF	36
PUMP - CHARGING	24, 26
- HYDRAULIC	92, 94
RADIATOR	8
REFLECTOR	132
ROLLER - EJECTOR	108
- IDLER	106
- ROLLING BOTTOM	108
- TAIL	106
ROPS	94C
SCRAPER	96 thru 132
SCRAPER CONTROLS	58
SPINDLE	98
SEAT	46 & 94H
STEERING	52
STEERING CONTROL	54
STEERING CYLINDER	82
TAILGATE	100
TAIL LIGHT	132
TIRE INFLATION	94G
TRACTOR	2 thru 94
TRANSMISSION	18 thru 32
TRANSMISSION COOLING	66
TRANSMISSION MOUNTING	16
VALVE - COMPRESSOR UNLOADER	84
- CONTROL	76, 78
- ELEVATOR CONTROL	88
- LOCK-UP	32A
- MANIFOLD	86
- POPPET	90
- PRESSURE RELIEF	90
- REGULATOR	32
- TRANSMISSION CONTROL	24
- TREADLE	74
WHEEL - SCRAPER	122
- TRACTOR	40
WINDSHIELD WIPER	94F
WIRING - BATTERY	116
- GENERAL	72
YOKE	96

CLICK ANYWHERE FOR MORE DETAILS

CLICK ANYWHERE FOR MORE DETAILS

CLICK ANYWHERE FOR MORE DETAILS



CLICK ANYWHERE FOR MORE DETAILS



FIG. 5342

RADIATOR & GRILLE

FIGURE 5342

RADIATOR & GRILLE

Ref. No.	Part No.	Qty.	Description
1	VY6479	4	JOINT, BALL
2	TR5445	12	LOCKWASHER - 1/2"
3	C1524	4	NUT - 1/2" - 20NF
4	DA1103	2	ROD, THREADED
5	H0749	2	NUT, JAM - 1/2" - 20NF
6	TV1085	1	CAP, RADIATOR
7	TV5751	1	CHAIN
8	DA2009	1	RADIATOR ASSEMBLY
9	VY8010	1	SHROUD
10	DA2550	1	BAFFLE, TOP
11	C1601	11	CAPSCREW - 3/8" - 16NC X 3/4"
12	C0312	10	LOCKWASHER - 3/8"
13	DF3042	10	FLATWASHER - 3/8"
14	DA1043	1	BAFFLE - L.H.
15	VY8009	1	BAFFLE, BOTTOM - L.H.
16	VY6678	1	GRILLE
17	VC1387	6	CAPSCREW, SPECIAL
18	VY8008	1	BAFFLE, BOTTOM - R.H.
19	VY5283	4	MOUNT, RUBBER
20	VN9779	4	FLATWASHER - 9/16"
21	C1619	2	CAPSCREW - 1/2" - 13NC X 2 3/4"
22	DD5640	2	FLATWASHER - 1/2"
23	C1523	2	NUT - 1/2" - 13NC
24	DA1042	1	BAFFLE - R.H.
25	HC1851	1	COCK, DRAIN
26	R3868	8	CAPSCREW - 5/16" - 18NC X 1/2"
27	C1538	8	LOCKWASHER - 5/16"
28	TF7161	8	FLATWASHER - 5/16"



AIR CLEANER